

FONE-1

User's Manual



(GSM dual band digital mobile phone)

Preface

Dear mobile phone users,

Thank you very much for your selecting mobile phone PF835 of our company!

This mobile phone complies with the international communication industry standard, and has been approved to be used for GSM network. The GSM network is an internationally standard global cellular communication system. Your phone can enter a variety of international networks. It allows you to make and answer international calls, just like using the phone at home.

In consideration of the network configuration of the mobile phone and the services provided, some functions may not be permitted to use. Please consult the dealer or your network operator.

Table of Contents

User Manual	1
1. Safety Precautions	6
2. Description.....	8
2.1 Icon.....	9
3. Before You Get Started	10
3.1 SIM card installation and out	10
3.2 Power on/ Power off	11
3.3 Install / Put out the memory card.....	12
3.4 Charge Battery	12
3.5 The Use Of Headset	14
3.6 Safety Password	14
3.6.1 PIN Code	14
3.6.2 PUK Code	14
3.6.3 Phone Password	15
4 Function Menu	16
4.1 Message.....	16
4.1.1 Create new	16
4.1.2 Inbox.....	17
4.1.3 Draft	17
4.1.4 Out box.....	18
4.1.5 Sent	18
4.1.6 Template	18
4.1.7 Voice mail	18
4.1.8 Cell broadcast.....	20

4.1.8 Settings	19
4.1.9 Memory status	19
4.2 Phonebook	19
4.2.1 phone	20
4.2.2 Groups.....	20
4.2.3 SIM	21
4.2.4 Blacklist	21
4.3 Call history.....	21
4.3.1 All calls	21
4.3.2 Missed calls.....	22
4.3.3 Received calls	22
4.3.4 Dialed calls	23
4.4 Media tools	23
4.4.1 Camera.....	24
4.4.2 Camcorder.....	23
4.4.3 Music	错误！未定义书签。
4.4.4 Video player.....	24
4.4.5 Photo viewer.....	24
4.4.6 FM radio	25
4.4.7 Voice memo.....	25
4.5 File manager	25
4.6 TOOLS.....	26
4.6.1Calendar.....	26
4.6.2Audiphone.....	26
4.6.3Alam.....	26

4.6.4 Calculator	27
4.6.5 stopwatch	27
4.6.6 Timer	27
4.6.7 World Clock	27
4.6.8 Sim	错误！未定义书签。
4.8 Settings	28
4.8.1 General	28
4.8.2 Phone	30
4.8.3 Connection	32
5. Quick start	33
5.1 Call functions	33
5.1.1 Make call	33
5.1.2 Dial-up status	34
5.1.3 Call status	35
5.1.4 Answer call	35
5.1.5 Domestic telephone call	35
5.1.6 Fixed telephone call extension	36
5.1.7 Dial international calls	37
5.1.8 Call Options	37
5.1.9 Adjust The Volume	38
5.2 Input Method Description	38
6 Common questions and solutions	38
7 Notices	41

1. Safety Precautions

Please read and observe the following concise rules to avoid danger or irregularity. This Manual provides detailed information about safety.

Traffic Safety First



When driving a car, do not use the mobile phone without a vehicle mounting device. If you do want to use the phone, you should stop the car first.

Power off the phone when refueling the car



Do not use the mobile phone when you are at a gas station or near flammable objects or chemicals.

Power off the phone when on the plane



When you are on the plane, you must switch off your mobile phone, since it is illegal to use mobile phones on

the plane.

Power off the phone when in the hospital



Please observe the relevant regulations phone when you are near the medical equipment (such as pacemakers and hearing aids).

Interference



The communication quality of all the mobile phones may be influenced by the interference of radio wave.

Reasonable Use



Use the mobile phone only at the regular position (against the ear).

Professional Services



Only professional technicians are permitted to update software or repair the phone.

Connect to Other Devices



When you want to connect this phone to other devices, please read the user manual of the device to get the detailed safety instructions. Do not connect the products that do not match the phone.

Accessories



Please use only the specified battery and accessories, otherwise, the phone may be damaged.











Children's Safety



Put the phone and its accessories in a place out of the reach of children.

2. Description

2.1 Icon

Icon	Description
	Show SIM Network signal strength.
	Show the battery capacity.
	Alarm clock
	SIM unread SMS or memory full
	Music
	Bluetooth
	FM
	Earphone mode
	Meeting mode
	Flight mode

3. Before You Get Started

3.1 SIM card installation and out

Turn the phone upside down, locate the SIM card socket, slide the SIM card fully into the socket.

When inserting the SIM card, make sure the metal portion of the SIM card is facing down, and the chamfer is at the left top corner.

Battery installation

Insert the battery into the back of the phone with the end that is near top of the phone first, press down the battery into place, then slide the back cover to be locked.

Remove Battery

Make the back of phone face you, push outward and then lift one end of the battery at the bottom of the phone to remove the battery.

3.2 Power on/ Power off

Power on or Power off, please long press the off key.
Long press End/Power key to power on the phone.

If you power on the phone, but no insert the SIM card, it will show “insert SIM card”—it means no SIM card, but can make emergency call like 112.

“phone locked”—If you set the phone lock and SIM card password.

After insert SIM card, the phone can automatically test this SIM card usable or not, then will show below info:

1. “Enter the phone lock code” —If you have set up the phone lock code.
2. “Enter PIN”— If you have set up the SIM card password.
3. “Call dial emergency call”—show registration of other networks, just allow to call 112.
4. “Search”—Phone will search till find a suitable network.

3.3 Install / Put out the memory card

This phone supports T-Flash card, T-Flash card is a kind of memory used in mobile phones to expand memory. This is a relatively small card, When install or remove, you need to be careful & cautious, so as not to damage it.

3.4 Charge Battery

1. Insert the charging plug of the charger with an arrow symbol on one side into the charge interface at the bottom of the phone.
2. When the charging plug has been inserted, the stripes of the battery power icon on the right side of the screen will scroll, which indicates the charging progress. If it stops scrolling, it indicates that the charging of the battery has completed. After charging, press the buttons on both sides of the charger to remove the plug.
3. When the power is not enough, the screen of the phone will display a warning message. When the power is too low,

the phone will power off automatically. Please do not let the battery be in the status of low battery for a long time, otherwise, the quality and use life of the battery will be shortened. To ensure the phone can work properly, be sure to use the specified charger.

4. If the charge had been shut down, Screen will appear animation charge, showing charging.

5. If the phone use up the battery, it may take a while to appear on the screen rechargeable symbols;

6. At the upper right corner of the screen when the power symbols indicate full instructions, and no longer flashing, it means charging has been completed. If charge when power off, the screen will show "Charge has been completed" words.

7. During the charging, battery, cell phone and charger will be fever, is a normal phenomenon;

8. Upon completion of charge, please disconnect the charger.

3.5 The Use of Headset

When you insert a cell phone headset on the bottom of the headphone jack, the phone will automatically switch mode to headset mode. This phone can only use the designated headphones, by setting up automatically answering call, you can listen to music or FM radio through headset or the phone.

3.6 Safety Password

3.6.1 PIN Code

PIN Code (Personal Identification Number) Can prevent others without your permission to use your SIM card. Default password is provided with the SIM card.

3.6.2 PUK Code

Into the "call accounting" and "fixed dial-up", please

contact with the network operators, to determine whether your SIM card support these functions, If you input three times the wrong PIN code, PIN code will be locked, only enter the correct PUK code can unlock the PIN, PUK code may be provided with the SIM card.

3.6.3 Phone Password

The Recover Password is 0000 for setting mobile phone locked.

4 Function Menu

4.1 Message

4.1.1 Create new

You need short message services, entry the SMS menu.

- SMS

Enter the message interface, after the completion of the preparation of options, the following will be set up:

Add recipient Insert the sending phone name.

Insert Insert in new picture、Audio、Video、
Template、vCard、v Calendar(will auto
change MMS).

Convert to MMS Manual conversion for MMS.

Input Method Select the input method you need

- MMS

Reference to the SMS.

4.1.2 Inbox

After enter Inbox, select the name of the sender, show Short Message, choose to return to the SMS interface. And can choose options, access to information menu allows you to read text message received. Select a text Message, enter following options:

Open: View SMS messages content;

Write message (Reply): You can reply to the sender message;

Delete: Delete this message;

Copy: You can copy this message to phone;

Mark: Mark one or all;

View details : To view this message of detailed information;

4.1.3 Draft

Shown here store information, please refer to your inbox

4.1.4 Out box

Shown here sends out the failure information, please refer to your inbox

4.1.5 Sent

Shown here send successful information, please refer to your inbox

4.1.6 Template

In Template can set some often use of phrases, with convenient use.

4.1.7 Voice mail

Voice mail needs Network's support. You must set up the mailbox number first to receive messages.

4.1.8 Cell broadcast

Cell broadcast is a service which the Mobile operators transmitting real-time and dynamic classification information

to Mobile Client by region and channel. It will make your mobile phone as radio, whenever and wherever possible, can receive your interested channel content

4.1.9 Settings

You can set the SMS, MMS, Cell broadcast and Voice mail

You can set models, the status, the capacity of information, storage location in the SMS settings.

4.1.10 Memory status

View all kinds of information of the phone memory footprint.

4.2 Phonebook

Phone cards can use this v-card type address book, phone can store 2000 numbers, SIM card number can be stored depends on the number of SIM. IP dial-up support.

4.2.1 Phone

In check telephone interface, By pressing the up and down the direction key, select a specific contacts, enter the options menu.

View:	Check the contacts.
Send:	You can send SMS or MMS.
New:	Add new contacts.
Delete:	Delete the contacts.
Mark:	Mark one or all.
Assign to group:	Increase the contacts to Group or Blacklist.
vCard:	Can send CARDS, introduction, and backup contact information.
Memory details:	Check the mobile phone, SIM memory footprint information.

4.2.2 Groups

You can create new group or adding contacts to the existing group.

All the options and phone options are basically the same.

4.23 SIM

This function displays preservation SIM card on the contact information.

All the options and phone options are basically the same.

4.2.4 Blacklist

Can set blacklist number to prevent other number of incoming.

4.3 Call history

4.3.1 All calls

It shows here all the calls information. Fluctuation direction can choose the communications, information, press left soft

key can enter options:

View: Check call information.

Save: Save the call information contact number to phone

Delete: Delete the call information.

Delete all: Delete all the call information.

Call timer: In telephone records in enter call timer, you can check the Last call, Received calls, Dialed calls and Reset.

Call cost: In telephone records in enter call cost, you can check Last call, Total call cost, Credit and Reset total cost.

4.3.2 Missed calls

The red icon indicates.

4.3.3 Received calls

The green icon indicates.

4.3.4 Dialed calls

The blue icon indicates.

4.4 Media tools

4.4.1 Camera

Press left softkey button enter to the setting mode .
press right softkey button enter to quit. Press OK button to
photograph. the up key is to enlarge, the down key is to
narrow.

4.4.2 Camcorder

Select the video recording device into the video recording
screen, press the Record button can be recorded, and then
stop button to end the recording will be prompted to save the
function, select "Yes" to save the video, "No" to not save.
Reference to the Camera.

4.4.3 Music

In this menu can view video files list and press "OK" to Play,

Press up/down navigation key to adjust volume. Press left/right navigation key to adjust schedule.

Press right soft key to play list.

4.4.4 Video player

In this menu can view video files list and press "OK" to Play

Press up/down navigation key to adjust volume. Press left/right navigation key to adjust schedule.

Press "#" key all-screen broadcast.

4.4.5 Photo viewer

Select the photo viewer entered the card memory interface, switch card memory entered the photo viewer, press "OK" to viewer the photo, Press left/right navigation key to viewer photo, press left soft key to option interface

4.4.6 FM radio

The phone support radio function, insert an earphone to open this function. In the radio menu, press “OK” key to on or off, press left/right navigation key to search channel auto until searched a channel. Close the auto search function, you could search a channel what you want by manually.

4.4.7 Voice memo

In Voice memo interface, press “OK” key to recording, press “OK” or right soft key to quit recording, and auto save the voice.

Press “OK” key again, will broadcast voice.

4.5 File manager

You can manage the files in the phone or memory.

4.6 Tools

There are many tools there are many options in the menu.

4.6.1 Calendar

Select the calendar; you can enter the month of the calendar interface. Select the option to view the schedule for new issues, view the memorandum, go to the designated date, such as the Lunar and Operation.

4.6.2 Audiphone

Help to improve their hearing disability, hearing impairment, and to improve communication skills with others, conversation tools, equipment, devices and instruments.

4.6.3 Alarm

Select an alarm clock, alarm clock into the interface, a total of six alarm clocks, are equipped with a default value for the closure. Select one of the alarm clock, choice of editors,

can be related to setting.

4.6.4 Calculator

Simple math: addition, subtraction, multiplication, division.

4.6.5 Stopwatch

OK button to start and pause, Left key is clear or record, Right key is quit.

4.6.6 Timer

First enter time is from keyboard, then press "OK" start.

4.6.7 World clock

Left key and right key choose the city, and the view the world clock.

4.6.8 SIM

If only insert sim1, then show sim1 menu, if only insert sim2, then show sim2 menu . if insert sim1 and sim2 , then show sim1 menu and sim2 menu.

4.7 Settings

4.7.1 General

- Personalization
 - ✧ Display: Can set the main menu style, screens effect, backlit, the main menu effects.
 - ✧ Standby mode : Can set standby pictures, operators name, the direction key.
 - ✧ Ringtone settings: Can set vibration mode, the volume level, phone ring, boot ring, shutdown ring,

information, calendar, clock, omissions reminder, buttons sound.

- ✧ Display language : Can set phone language, writing information language and default input method.

- Date/Time

Can set the date and time and the date and time format.

- Profiles

Select the profile. Scene mode options are: General, Meeting, Outdoor, Silent, Personal, Headset, these modes have default setting; you can change the custom settings.

Note: After inserting the headset, the phone will be automatically transferred to the headset status.

- Power on/off

Can set timing automatic switch machine.

- Information

To view the identifier, mobile phone memory information, software version information.

- Security

Can set or modify the PIN code, mobile phone SIM card

lock, lock, automatic locking keyboard time.

- Restore settings

This function can be part of the cellular phone function setting recovery for factory Settings.

This function need to input the correct password, just can operate.

Note: factory default password for 0000.

4.7.2 Phone

- Call settings

Call waiting: Setting call waiting state

Caller identity: Send this machine number of setting state.

Any key answer: Mobile phone calls on the answer way

Minute reminder: Set in the process of voice call time.

Remind

Auto redial : When the opposite no answer, will automatically heavy dial

Answer reminder : Open or closed cell phone the

reminder of the sound

Cost settings: Can install the unit

User group : Can unite Settings of group status,
Numbers and outside calls

- Call divert
 - All: Different conditions call divert
 - Voice: Different conditions call divert
 - Data: Different conditions call divert
 - Fax: Different conditions call divert
- Call barring
 - All: Different conditions call barring
 - Voice: Different conditions call barring
 - Data: Different conditions call barring
 - Fax: Different conditions call barring
- Network settings
 - Preferred list: Set preference network
 - Net selection mode: Set up network operators
 - Airplane mode: set flight mode
- Switch mode

Enable SIM or disable SIM

- Speed dial
Set up voice mail number and quick dialing the number

4.7.3 Connection

- Data accounts
Can set Data account networking when network
- MMS settings
Can set MMS account networking when network
- Bluetooth
Turn on: Open or close the BT.
Paired devices: Display is connecting the devices.
Search devices: Search new devices.
Settings: Can set the devices visibility, name, receive folder, information.
(Note: when a bluetooth headset, first to activate the bluetooth, and bluetooth headset must as "open" condition, And then click search exemption

hold device, according to the mobile phone hints
step by step operating down. General bluetooth
headset initial password for 0000)

5. Quick start

5.1 Call functions

5.1.1 Make call

Signal information that displayed in the upper left corner shows the network signal strength, be more signals revealed that the network signal stronger. The quality of the call impacted relatively by the obstacles, so in a small area can effectively increase the signal strength.

Dial calls by several ways:

through a direct dial telephone number: in the standby interface press the phone number directly, and then press dial-up bottom.

Call the number in the phone book: in standby mode, enter the telephone directory menu , Look through the telephone number into the view of the contact interface, and then press dial-up button.

Call the number by phone records: In standby mode, enter the main menu, then select “call records”, choose “missed calls” and “answered calls” and “Dialled calls” list interface, selecting the records directly then press the dial-up button.

5.1.2 Dial-up status

According to the number keys to enter a dial-up interface, that is dial-up state, at this time still show the signal power, as well as other instructions icon.

When input dial number, you can do the following:

Clear Delete the former characters.

Save Save the phone number.

Handing-up key Quit dial-up status.

Dial-up key: Call the phone by inputting numbers.

5.1.3 Call status

In the dial-up interface, enter the number then press dialing keys. The screen showed: signal and power instructions; if the numbers not in address list, will display the dialing numbers, or display the names of the dialing number; when calling, press the hang-up key, hang up the current call.

5.1.4 Answer call

When get the call, enter the coming call interface, if set up any key to answer the phone, then press any key to answer the call. If you plug in the headphones already, you can also use the headset button to answer the call. IF you do not want to answer the phone, you can hang by refusing key.

5.1.5 Domestic telephone call

The easiest way to call is to press the number keys (if domestic phone number, plus area code), then dial the call

button to start. If you need to change the phone number, please remove the precursor to delete a number or move the cursor to the location to clear.

After the call, please hang up by the end call button.

Domestic telephone call: +area code+ telephone number+ dials up.

5.1.6 Fixed telephone call extension

Some fixed-line extension cannot dial directly; you need to dial the switchboard first, then dial extension. If you enter a phone number, the switchboard number and extension symbols inserted between the suspension of characters "P", the phone will dial-up automatic extension. The way to enter "P": in the dial-up interface, after enter the number, press 3 "0" key to enter the "P".

Fixed-line calls for extension:

Host area code+ number+"P"+ extension+ dial up

5.1.7 Dial international calls

In the dial-up interface, press "*" key 2 times to enter the "+", appeared on the screen of the international long-distance telephone prefix symbol "+", which will allow you to dial calls that do not know the international telephone number prefix(for example, is 00 in China).

Enter the prefix number, and then enter your area code and the complete telephone number to call number.

Fixed-line call: + country code+ phone number+ dial-up

5.1.8 Call Options

In the calling interface, select the option to enter a call option. The calling option only show when in calling process, and " forwarding call" and "multi-call" and "maintain call" and "call waiting" and other functions required to supported by the network, you can contact your network vendor.

5.1.9 Adjust The Volume

Adjust the volume by the up/down keys when calling.

5.2 Input Method Description

Total 4 input method: English, French, Arabic, Persian.

6 Common questions and solutions

If something problem when use the phone, please solve as following:

FAQ	Causes and solutions
Can not power on	Press the power on button more than one second; Check if the battery is bad or not, please remove and then re-install, try to power on again; Check whether the battery has run out, if so, please charge;
Unable to connect networks	Weak signals, try to move to places with stronger signal; Exceed the network service provider's network covers areas;

	SIM card invalid, contact your network vendor;
Power on, display the information	<p>Check SIM card, install the SIM card is correct or not;</p> <p>Lock, enter the password of phone before select automatic locking function;</p> <p>Enter PIN, select the function that when power on need enter the PIN, must enter a PIN code;(for the first time the use, it is important to enter the PIN code that show on the SIM card)</p> <p>Enter PUK code: the cell phone will be locked by three time enter the wrong PIN code, please enter the PUK code that the network operators offer;</p>
Poor quality of call	<p>Please check whether is the inappropriate of the volume adjust;</p> <p>The mobile phones in non-performing areas, such as high-rise near or in the basement, radio waves can not effectively communicate;</p> <p>In the period of call intensive, as work time, the line is congestion to pass;</p>

Standby time shorter	Stand-by time is related by the network system, probably in a bad reception area. Can not get the signal, the phone will be launched to look for base stations, consume a large amount of battery power, resulting in shorter standby time. Please move to the local that signals stronger or temporary closure of the mobile phone; The need to replace the battery, battery replacement;
SIM card error	There are some dirt in the metal surface of the SIM card, use a clean cloth to wipe the metal points of SIM card; SIM card is not installed; SIM card damaged, contact your network service provider;
Can not call out	Make sure whether press the dial key to dial-up; Please confirm whether or not prohibited as a result of arrears; Please confirm the validity of SIM; Please confirm whether or not has set a limit function; Please confirm whether or not has set a fixed dial-up function;

Call could not contact	Make sure that the phone has been power off, and network connectivity; Please confirm whether the arrears have been prohibited as a result of incoming; Make sure that the SIM card validity; Please confirm whether or not has set a limit function; Please confirm whether or not has set a fixed dial-up function;
Can not charge	Check whether the plug connect or not; If in environment with less than -10℃ or higher than 55℃, it is unable to charge; Battery or charger damaged, to be replaced;
Some features can not be set up	Operation mistake; Network providers do not support this feature, or you do not apply this feature.

7 Notices

1. It's strictly prohibited to charger the mobile phone when the battery is not equipped in the phone.
2. To be in charge of ventilation and cooling a good environment, away from flammable and explosive goods.
3. Mobile phone users can not be demolished if the phone broke down, with the vendor. Removable phone on its own

will not be entitled to after-sales service.

4. Non-original accessories and spare parts, is not eligible for warranty.
5. To ensure that no mobile phone contact with any liquid, in the event of such a case, and contact with the battery vendor...
6. Avoid too high or too low temperature environment, the use of mobile phones, mobile phones to avoid exposure to strong sunlight or high humidity environment.
7. Can not use strong detergents containing liquid or a wet cloth to clean the phone.
8. Loading data has been strictly prohibited the destruction of images, ring tones and other documents, due to malicious carry phone use led to the unusual, the company does not bear any responsibility.
9. If the use of non-original battery charger, or potentially dangerous, the company will not have any liability.

CE Notes:

Manufacturer: Amercian Fone Company Ltd

Address: 1461 First Avenue, # 360 New York, NY 10075-2201
USA

declare that this **FONE-1** are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the DoC may be obtained through the address above.

CE 0678

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types FONE-1 (FCC ID: A4FFONE-1) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.599W/kg and when properly worn on the body is 0.517W/kg. This device was tested for typical

body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is

subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.