



TWO-MAN DELUXE CHAIR BLIND

Instruction Manual



Model # 885
Realtree® AP HD™

Be sure to follow these guidelines for using your Product.
READ AND UNDERSTAND ALL INSTRUCTIONS and WARNINGS FIRST

! CHOKING HAZARD - MAGNETS ENCLOSED. Keep Small Parts Away From Children. Do Not Ingest or Inhale Magnets. Attraction of Magnets in the Body May Cause Serious Injury and Require Immediate Medical Care.

Any questions or confusion regarding the use of this product contact our Customer Service Department.



Step 1: Remove your Blind from Back Pack.



Step 2: Unsnap the cinch strap (fig 1 and 2) and open chair. (fig 3).



Step 3: Grab steel bands from behind chair and pull forward until blind is fully covering the chair (shown in figs 4, 5, 6)



Step 4: Tent stakes are included with your chair blind to help secure the blind to the ground (fig 7).



! Tip

Be sure to remove all native brush, dirt and debris **BEFORE** beginning take down. Remove Ground Stakes.



fig 2



fig 3



fig 4

Step 1: Once out of the blind, lift the blind up and over the back of the chair so that the blind cover falls to behind the chair.

Step 2: Close the chair by pulling up on the seat and bring legs together (fig 4).



fig 5



fig 6

Step 3: Place cinch strap around the blind and snap together to keep Chair Blind closed.

Step 4: Place Chair Blind into backpack.



TWO-MAN CHAIR BLIND FEATURES • SAFETY AND STORAGE

THE TWO-MAN CHAIR BLIND

Models #885

PARTS LIST

- 1 Ameristep® 2-MAN Chair Blind (61" Wide x 52" Deep x 60" Tall)
- Model #885 Realtree® AP™
- 1 Chair (56" Wide x 21" Deep)
20" High to Seat and 37" High to Seat Back
- 1 Carrying Case
- Tent Stakes



FEATURES

- Packed: 20" x 40" Long
- Six Windows
- Weight: 17 lbs.
- Rated For: 500 lbs.



STORAGE AND TIPS

- Store your Blind in a cool dry place - free native brush, dirt and any debris
- Never store your Blind wet or damp
- Avoid leaving your Blind outdoors for any extended period of time
- To stop any leakage, use seam sealer on all seams and silicon spray on seams/sidewalls.
- To store your TSC windows and/or Shoot-Through Mesh (if included with your Blind or purchased separately), avoid wrinkles and creases that could significantly reduce visibility
- To aid in folding blind be sure the window curtain is all the way up

WARNING

⚠ WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM TENT FABRIC.

The fabric will burn if left in continuous contact with a flame source. It is not fireproof. Do not use candles, matches or op kind in or near a tent; do not cook inside a tent; do not smoke in a tent; do not store flammable liquids inside a tent; build wind and several meters away from a tent and be sure to fully extinguish campfires before leaving a campsite or before retiring exercise extreme caution when using fuel-powered lanterns or heaters inside a tent and use battery operated lanterns whenever p do not refuel lamps, heaters or stoves inside a tent; extinguish or turn off all lanterns before going to sleep.

⚠ Warning ⚠ Warning ⚠ Warning ⚠

THINK SAFETY !

- NEVER USE A HEATER IN YOUR AMERISTEP® BLIND - UNVENTED FUMES COULD CAUSE SICKNESS OR DEATH
- NEVER EXPOSE YOUR BLIND TO ANY OPEN FLAME. THIS PRODUCT **IS NOT FIREPROOF**
- NEVER SHOOT THROUGH THE TSC WINDOWS WITH A FIREARM SPARKS OR FLAME FROM THE MUZZLE COULD IGNITE THE MATERIAL
- NEVER SHOOT EXPANDABLE BROADHEADS THROUGH THE TSC WINDOWS - THE MESH MAY CAUSE PREMATURE OPENING OF THE BLADES. USE FIXED BLADE BROADHEADS ONLY
- FOR BEST ARROW FLIGHT THRU TSC WINDOWS, ALIGN BROADHEAD BLADES WITH FLETCHING
- NEVER ALLOW CHILDREN TO PLAY WITH THIS PRODUCT WITHOUT ADULT SUPERVISION
- NEVER ALLOW MATERIAL TO COVER YOUR FACE. IT CAN CAUSE SUFFOCATION AND DEATH
- NEVER ALLOW ANYONE TO USE LIGHTED CANDLES, MATCHES OR OTHER SOURCES OF FIRE NEAR THIS PRODUCT

! CHOKING HAZARD - MAGNETS ENCLOSED. Keep Small Parts Away From Children. Do Not Ingest or Inhale Magnets. Attraction of Magnets in the Body May Cause Serious Injury and Require Immediate Medical Care.

- **UV (ULTRAVIOLET LIGHT) WARNING:**
Ultraviolet light breaks down lightweight fabric fibers (and almost any synthetic material). The material will fade (discolor), lose strength and eventually disintegrate if left in prolonged sunlight. To extend the life of your Ameristep® product avoid leaving it out in direct sunlight. Set up your portable ground blind or accessory in a shady spot whenever possible to extend the product life.