



User Manual

Soundcore Flare+ A3162

What's Included



At a Glance



1 Volume Buttons for Volume Control

2 *Bass Up Button*

3 Multi-function Button

4 Light Effects Button

5 Bluetooth Button

6 Power Button


7 3.5mm Audio Input Port

8 micro USB Port

9 USB port


Using Your Soundcore Flare+






1. Turn On / Off




ON	Press
OFF	Press and hold for more than 2 seconds











a. Bluetooth mode




 Flashing White	Bluetooth Pairing Mode
 Solid White	Connected to a device
	Enter True Wireless Stereo Group Mode / Disconnect True Wireless Stereo
 Double Flashing White	True Wireless Stereo Group Mode
 Solid White	Connected to True Wireless Stereo








With True Wireless Stereo technology, you can pair your Soundcore Flare+ with another Soundcore Flare+ to explore the best sound effects with left and right sound channels separated on both speakers.

	Play / Pause
	Play Next Song
	Play Previous Song
	Press to turn Bass Up on and off
	Press and hold for 2 seconds to reset Equalizer settings
	Answer Call / End Call
	Reject Call / Switch between a call on hold and an active call
	End current call and answer incoming call / End current call and switch to call on hold
	Switch audio source between Speaker and Phone
	Put current call on hold and answer incoming call

	<p>Activate Siri / Other Voice Control Software</p>
---	---

	<p>Volume Up / Down</p>
---	-------------------------

<p> Solid White</p>	<p>On a Call</p>
<p> Flashing White</p>	<p>Incoming Call</p>

	<p>Press and hold for 2 seconds to turn Light Effects Off</p>
	<p>Press to turn Light Effects On</p>
	<p>Press once to switch between Light Effect modes</p>

<p> When turned on, Soundcore Flare+ will automatically connect to the last connected</p>
--

device if available. If not, press the Bluetooth pairing button to activate pairing mode.

To pair a different device, press the Bluetooth button to re-enter pairing mode. Then repeat the pairing steps.

Having connection problems? Remove Soundcore Flare+ from your device's Bluetooth history and ensure it's less than 3 feet away. Then try pairing again. To get the best sound quality, make sure there is a clear line of sight between the connected device and your speaker.

b. AUX-In mode


*SoundLine AUX cable sold separately.





Plugging in an audio cable will automatically switch to AUX mode.


When using AUX mode, control audio playback via the connected device.


3. Charging your Soundcore Flare+



 Slow Flashing Red	Low Battery
--	-------------

 Solid Red	Charging
Off	Fully Charged

 **Use the included USB cable to charge your Soundcore Flare+ and make sure it is fully charged before its first use.**

 **Disconnect your speaker from the charger when fully charged. Do not charge your speaker for extended periods.**

 **When not in use, store your speaker in a cool place.**

Specifications

***Specifications are subject to change without notice.**

Input	5 V □ 2 A
USB output	5 V □ 1 A
Audio output	10 W x 2

Charging time	4.0 hours
Play time (varies by volume level and music content)	14.5 hours
Size	100 x 100 x 182 mm
Weight (without packaging)	853 g / 30.1 oz
Bluetooth version	V5.0
Bluetooth range	20 m / 66 ft

Soundcore App



- Light effect
- Update firmware
- Wave Equalizer
- Stereo or Boost mode
- Rename
- More



Product Number A3162 Bluetooth Speaker / Soundcore Flare+

Important Safety Instructions

- 1) Avoid dropping.
- 2) Do not disassemble.
- 3) This product is exclusively for indoor use only.
- 4) Do not install near any heat sources.
- 5) Do not place any sources of danger on this device(e.g. liquid filled objects, lit candles).
- 6) Use original or certified cables.
- 7) Clean with a dry, soft lint-free cloth. Do not use any corrosive cleaner or oil.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The following importer is responsible party

Company Name: Fantasia Trading LLC

Address: 9155 Archibald Ave ste 202, Rancho Cucamonga, CA 91730, US

Telephone: +1 (909)484-1530

IC NOTICE TO CANADIAN USERS This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. This Class B digital apparatus complies with Canadian ICES - 003 (Cet appareil numérique de la Classe B conforme à la norme NMB - 003 du Canada).

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-3 (B) / NMB-3 (B)

Declaration of Conformity

Hereby, Anker Innovations Limited declares that the product type A3162 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<https://www.soundcore.com>

Maximum output power: 2dBm

Frequency band: 2.4G band(2.4000GHz-2.4835GHz)

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Anker Innovations Limited is under license. Other trademarks and trade names are those of their respective owners.