


User Manual

Soundcore Rave A3391


Safety Instructions

- ① Avoid dropping.
 - ② Do not disassemble.
 - ③ Avoid extreme temperatures.
 - ④ Do not use the device outdoors during thunderstorms.
 - ⑤ Use original or certified cables.
 - ⑥ Do not use any corrosive cleaner / oil to clean.
-

What's Included



At a Glance



① Central Volume Knob (For speaker volume control)

② Power Button / Power Indicator

③ Source Input Button / Source Input Indicator

④ Bluetooth Button / Bluetooth Indicator

⑤ Previous Track Button

⑥ Multi-function Button

⑦ Next Track Button

⑧ Light Effects Button / Light Effects Indicator

9 *Bass Up Button / Bass Up Indicator*

10. MIC ECHO Volume Knob (For microphone volume control)


11. AC Power Input

12. Reset Hole

- 13. Mic Input
- 14. Audio IN
- 15. Audio OUT
- 16. USB Port
- 17. Power IQ USB Port


Using Your Soundcore Rave

- 1. Turn On / Off







ON	Press and hold for 1 second
OFF	Press and hold for more than 2 seconds


a. Bluetooth Mode





Note: Soundcore Rave can pair up to 2 mobile devices via Bluetooth(Dual Bluetooth Connection).







 <p>Flashing Blue</p>	<p>Bluetooth Pairing Mode</p>
 <p>Solid Blue 改图：实心黑圈</p>	<p>Connected to a device</p>
	<p>Enter True Wireless Stereo Group Mode / Disconnect True Wireless Stereo</p>

 <p>Double Flashing Blue</p>	<p>True Wireless Stereo Group Mode</p>
<p>○ Solid Blue</p> <p>改图：实心黑圈</p>	<p>Connected to True Wireless Stereo</p>




 **With True Wireless Stereo technology, you can pair your Soundcore Rave with another Soundcore Rave to explore the best sound effects with left and right sound channels separated on both speakers.**

 <p>× 1</p> <p>改图：</p>	<p>Play / Pause</p>
-----------------------------------------------------------------------------------------------------------	---------------------

	Play Next Song
	Play Previous Song
	Press to turn Bass Up on and off
	Press and hold for 2 seconds to switch between Indoor / Outdoor modes.
	Activate Siri / Other Voice Control Software
	Volume Up / Down

Check available Light Effects modes on Soundcore App.



When turned on, Soundcore Rave will automatically connect to the last connected device if available. If not, press the Bluetooth pairing button to activate pairing

mode.

To pair a different device, press the Bluetooth button to re-enter pairing mode. Then repeat the pairing steps.


Having connection problems? Remove Soundcore Rave from your device's Bluetooth history and ensure it's less than 3 feet away. Then try pairing again. To get the best sound quality, make sure there is a clear line of sight between the connected device and your speaker.

b. Source Input




Plug in an audio cable or insert USB drive, then press the source input button to switch between AUX in mode and USB mode(support FAT32 / MP3 / WMA formats).

<p>● Solid Green(Source input indicator)</p>	<p>AUX in mode</p>
----------------------------------------------	--------------------


 <p>Solid White(Source input indicator)</p>	<p>USB mode</p>
-------------------------------------------------------------------------------------------------------------------------------------	-----------------

***SoundLine AUX cable sold separately.**




When using AUX mode, control audio playback via the connected device.

c. Connect Multiple Rave Speakers




Soundcore Rave can connect to other Soundcore Raves via RCA cables to form a wired party chain.

d. Microphone Connection







Connect the microphone to MIC IN port. You can adjust the microphone volume by turning the MIC ECHO volume knob.

3. Charging your Soundcore Rave





	Battery level <10%
	Battery level <25%

	Battery level 25%~55%
	Battery level 51%~75%
	Battery level 75%~100%

 <p>Slow Flashing White(Power indicator)</p>	Charging
--------------------------------------------------------------------------------------------------------------------------------------	----------

You can charge your mobile device through the Power IQ USB port on Soundcore Rave.





 Use the included AC power cable to charge your Soundcore Rave and make sure it is fully charged before its first use.



Disconnect your speaker from the charger when fully charged. Do not charge your speaker for extended periods.

4. Beat-Driven Light Show



	Press to turn Light Effects On / Off
-------------------------------------------------------------------------------------	--------------------------------------

Note: Flash can be turned off in Soundcore app individually.

5. Soundcore App

Download the Soundcore app for an enhanced product experience. Follow onscreen instructions to set up Soundcore app.



When not in use, store your speaker in a cool place.

Please note that your rights under applicable law governing the sale of consumer goods remain unaffected by the warranties given in this Limited Warranty.

Declaration of Conformity

Hereby, Anker Innovations Limited declares that the radio equipment type A3391 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<https://www.anker.com/products>

Maximum output power: 0dBm

Frequency band: 2.4G band (2.4000GHz-2.4835GHz)


Specifications

***Specifications are subject to change without notice.**



Input	100V-240V AC, 50~60Hz
Charge out	5 V □ 2 A
Audio output	160W
Battery capacity	max. 20000 mAh
Charging time	4.0 hours
Playtime (varies by volume level and music content)	24 hours

Size	255 x 245 x 505 mm
Weight (without packaging)	8.37 kg / 295.2 oz
Bluetooth version	V5.0
Bluetooth range	20 m / 66 ft

Soundcore App



- Light effect
- Update firmware
- Wave Equalizer
- Stereo or Boost mode
- Rename
- More

Apple and the Apple logo are trademarks of Apple Inc.
Google Play and the Google Play logo are trademarks of Google Inc.

Product Number A3391
Bluetooth Speaker / Soundcore Rave

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

The following importer is the responsible party

Company Name: Fantasia Trading LLC

Address: 9155 Archibald Avenue, Suite 202, Rancho Cucamonga, CA, 91730, US Telephone: +1 (909) 484 1530

IC NOTICE TO CANADIAN USERS This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.”

ce matériel est conforme aux limites d'exposition aux rayonnements rf de ic énoncés dans un aut

re environnement. ce matériel doit être installé et exploité à une distance minimale de 20 cm entre le radiateur et votre corps.

Important Safety Instructions

1. Please read this owner's guide carefully and save it for future reference.
2. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
3. Do not place naked flame sources, such as lighted candles, on or near the product.
4. Do not use this apparatus near water.
5. Clean only with a dry cloth.
6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
7. Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus.
8. Protect the power supply or cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
9. Only use attachments/accessories specified by the manufacturer.
10. Unplug this apparatus during lightning storms or when unused for long periods of time.
11. The maximum ambient temperature during use of the appliance must not exceed 45° C.
12. Only suitable for safe use in areas below 2000m above sea level.
13. Do not make unauthorized alterations to the product; doing so may compromise safety, regulatory compliance, system performance, and may void the warranty.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way: such as power supply or cord is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. The product contains battery pack, so shall not be exposed to excessive heat such as sunshine, fire or the like.