

Welcome Guide

TC930

Bluetooth Keyboard Cover for iPad Air

ANKER[®]


Package Contents

Anker TC930 Bluetooth Keyboard Cover for iPad Air
USB charging cable
4 foot pads
Welcome guide

Features

- Automatic pop-up stand triggered by setting down your tablet in the stand groove.
- Opening and closing the cover turns the keyboard on and off automatically.
- The keyboard automatically connects to your iPad Air.
- Rechargeable lithium battery with an industry-high capacity lasts for 6 months between charges (basing on 2 hours use per day).
- Low-profile, quiet keys enhance the typing experience.
- Stylish, super-slim body fits securely onto your iPad Air and easily into your bag.
- Great for writing messages and emails when you're on the go.

Product Overview



 Back to Home	 Previous Song
 Brightness Down	 Play / Pause
 Brightness Up	 Next Song
 Keyboard Display	 Mute
 Copy	 Volume Down
 Paste	 Volume Up
 Switch Input Language	 Screen Lock / Unlock

- ① Magnet
- ② Stand Groove
- ③ Pop-up Stand Trigger
- ④ Caps Lock Indicator
- ⑤ Bluetooth Indicator
- ⑥ Power Indicator
- ⑦ Power Switch

Specifications

Bluetooth Specification	Bluetooth 3.0
Product Dimensions	240 × 175 × 7.4mm / 9.4 × 6.9 × 0.3in
Product Weight	328g / 11.6oz
Operating Range	Up to 10 meters / 33 feet
Modulation System	GFSK
Standby Time	300 days
Charge Time	5 hours
Uninterrupted Work Time	300 hours
Working Temperature	-10 - +55 °C
Lithium Battery Capacity	800mAh
Battery's Lifespan	400 charge cycles
Key Life	5 million clicks

Pairing Instructions

1. Push the Power Switch to the ON position to turn on the keyboard, then place your device onto the Stand Groove.
2. Press Fn and C keys together to enter pairing mode. The blue Bluetooth Indicator will start to rapidly flash.
3. Activate your device's Bluetooth function and search for the keyboard cover.
4. Once the Bluetooth keyboard cover has been found, click on its name to connect.

5. Enter the password code as displayed on the screen.
6. Once the Bluetooth keyboard cover has successfully connected to your device, the Bluetooth Indicator will turn off.

After pairing for the first time, your device will connect to the keyboard automatically when opening the keyboard.

Note:

In case of connect failure, delete the pairing record from your device, and try the above procedures again.

Power Saving Mode

The keyboard cover will enter sleep mode after being idle for 15 minutes. To activate it, press any key and wait for 3 seconds.

Charging Instructions

When the battery power is low, the Power Indicator will turn red, indicating that it is time to recharge the keyboard cover.

1. Connect the micro end of the USB power cable to the micro USB port on the keyboard cover.
2. Connect the other end of the cable to a power adapter or computer USB port.

3. The Power Indicator will go steady on while the keyboard cover is charging. Once it is fully charged, the Power Indicator will turn green.

Usage Tips

- Do not place heavy objects on the keyboard cover.
- Do not knock or dismantle the product.
- Keep the product away from oil, chemicals, and organic liquids.
- Clean the keyboard by lightly rubbing it with a slightly damp cloth.
- Dispose of batteries according to local laws.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty

Our company provides customers with warranty of **18 MONTHS** from the date of purchase.

Contact Us

For any inquiries or comments concerning our products, please send an email to support@ianker.com, and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a REPLACEMENT OR REFUND by submitting a request form at www.ianker.com/support.

Statement

- We're only able to provide after-sales service for purchases made directly from Anker. If you purchased through a different retailer, please contact them for any exchange or refund requests.
- Please note that unauthorized reselling of Anker products is prohibited.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

ANKER[®]

1-800-988-7973 (U.S.) Mon-Fri 9:00-5:00 (PST)
069-9579-7960 (DE) Mon-Fri 6:00-11:00
03-4455-7823 (日本) Mon-Fri 9:00-17:00

www.ianker.com
support@ianker.com