

USER MANUAL



Model No.: SUGARCUBE

Dear customer, thank you for purchasing our product SUGARCUBE. Please read this user manual carefully before using it.

Warm Reminding:

1. In order to extend the life of the speakers and your physical and mental health, please do not play music in large volume mode for a long time.
2. Please select headphone output mode to listen music in public place, so as not to disturb others.

3. If a fault occurs, please turn off the power switch immediately, and unplug the USB plug to prevent speaker and other component failure.

Specification

Output power : 3W(RMS)
Frequency response: 90Hz~18kHz
Impedance: 4OHM
Sensitive: 80dB±2dB
S/N Ration: ≥70dB
Distortion: ≤0.3%
Input power: USB 5V

Product Features


1. Bluetooth version: 3.0EDR (10M distance)
2. With handfree function, one button to answer or hang up the coming phone call. And the High anti-interference of the microphone makes the perfect sound quality.
3. With Aux in, compatible with all 3.5mm audiodevices.
4. Portable design with delicate and small appearance, very convenient to carry.

5. Power supply: 500mA Li-Battery and micro USB 5V charging

Then attachments


- | | |
|---------------------------|-----|
| 1.USB charge cable ----- | 1PC |
| 2.User Manual ----- | 1PC |
| 3.QC Certification ----- | 1PC |
| 4.3.5mm audio cable ----- | 1PC |

Function Identification



AUX in jack USB charge jack

Function Identification



Power ON/OFF

Bluetooth Mode

1. Power on the unit, the front blue indicator will flash quickly and you can hear the the "beep" sound to inform you the speaker is in default Bluetooth mode.
2. Use your mobile phone or computer to search the Bluetooth device name of "M20 ". After connect it successfully, you can hear the "beep" sound and see the light flash slowly. Then play the music in the mobile phone or computer. And you can control the music by the keys on the top of the speaker.

Remarks: Some audio devices may need to enter the password (it's"0000") to connect the speaker.

AUX Mode

1. In Aux mode, the front indicator blue light.

Charging

This unit is used the built-in lithium battery. In these situations such as the volume of unit is low/ sound of that is not stable/ display is blinking/automatically shut down, it means that the battery is out of power and need to be charged timely.

Made in China