## ck Start

eless Ande Magic Trackpad uses Bluebas and a brook ligy to connect to your light come. The two AA batteries is scaled field that a structions to update your spleam about the indicator lights, scaled field to be ackpad, and replace the

## **Magic Trackpad**

## ting Your Software

Our Apple Magic Trackpad and us and assessment as a update your Mac to X version 10.6.3 or later, and then made has a ckpad software.

te to the latest version of Mac OS X choose Apple (%) > Software Update from its bar, and follow the onscreen instructions

stallation is complete and you restart your Mac, use Software Update again to re all available updates are installed.

# **Quick Start**

Your wireless Apple Magic Trackpad uses Bluetooth® technology to connect to your Mac and comes with two AA batteries installed. Read these instructions to update your software, learn about the indicator light, pair and use your trackpad, and replace the batteries.

### **Updating Your Software**

To use your Apple Magic Trackpad and its full range of features, update your Mac to Mac OS X version 10.6.3 or later, and then install the latest trackpad software.


To update to the latest version of Mac OS X, choose Apple ( $\spadesuit$ ) > Software Update from the menu bar, and follow the onscreen instructions.

When installation is complete and you restart your Mac, use Software Update again to make sure all available updates are installed.

### About the Indicator Light

The indicator light displays the status of your Apple Magic Trackpad and the batteries.

- When you first turn your trackpad on, the indicator light glows steadily for 2 to 3 seconds, indicating the batteries are good.
- If your trackpad isn't paired with a Mac, the light blinks, indicating your trackpad is in discovery mode and ready to pair (pairing means connecting your trackpad and Mac to each other wirelessly).
- If you don't pair your trackpad with your Mac within 3 minutes, the light and trackpad turn off to preserve battery life. Press the On/off button on your trackpad to turn it on again, allowing you to pair it with your Mac.
- When your trackpad is on and connected, the indicator light turns off to conserve power.



### **Turning on Your Trackpad**

To turn your trackpad on, press and hold the on/off button.

### Pairing Your Apple Magic Trackpad

To use your Apple Magic Trackpad with your Mac, you have to pair them so they can comunicate wirelessly.

#### To pair your trackpad:

- 1 Choose Apple ( > System Preferences, and then click Trackpad.
- 2 Click "Set Up Bluetooth Trackpad ..." in the lower-right corner.
- 3 Press the On/off button on your trackpad to turn it on.
- 4 Click Continue when your trackpad is detected.

Once your trackpad is paired with your Mac, use Software Update again to make sure you have the latest software installed.

### Removing a Pairing

After you pair your Apple Magic Trackpad with a Mac, you can pair again with a different Mac. To do this, remove the existing pairing, and then pair the trackpad again.

#### To pair with a different Mac:

- 1 Choose Apple ( ) > System Preferences, and then click Bluetooth.
- 2 Select your trackpad in the Bluetooth preferences pane.
- 3 Click the Delete (-) button in the lower left corner.

To pair your trackpad again, see "Pairing Your Apple Magic Trackpad."

## Using Your Apple Magic Trackpad

Your Apple Magic Trackpad has a Multi-Touch surface for moving the cursor and performing gestures. To set up gestures and other options, choose Apple (\*) > System Preferences, and then click Trackpad.

Trackpad gestures work in many applications. When you perform these gestures, slide your fingers lightly on the trackpad surface.

#### Here are some ways to use your Apple Magic Trackpad:

- Drag two fingers up, down, or sideways to scroll in an active window.
- Secondary click (right-click) to access shortcut menu commands.
- Use two-finger pinching to zoom in or out on PDFs, images, photos, and more.
- Use two-finger rotating to rotate photos, pages, and more.
- Swipe three fingers to rapidly page through documents, move to the previous or next photo, and more.
- Swipe four fingers left or right to activate Application Switcher so you can cycle through open applications. Four-finger swipe works in the Finder and all applications.
- Swipe four fingers up or down to show the desktop or display all open windows in Exposé.

For more information, see Trackpad preferences or choose Help > Mac Help and search for "trackpad."

### Renaming Your Apple Magic Trackpad

Your Mac automatically gives your Apple Magic Trackpad a unique name the first time you pair it. You can rename it in Bluetooth preferences.

#### To rename your trackpad:

- 1 Choose Apple ( ) > System Preferences, and then click Bluetooth.
- 2 Select your trackpad in the Bluetooth preferences pane.
- 3 Choose Rename from the Action (\*) pop-up menu in the lower-left corner.
- 4 Enter a name and click OK.


### Replacing the Batteries

Your Apple Magic Trackpad comes with two AA batteries installed. You can replace them with alkaline, lithium, or rechargeable AA batteries.

*Important:* Dispose of batteries according to your local environmental laws and guidelines.

#### To replace the batteries:

1 Use a coin to remove the battery compartment cover.



2 Insert the batteries into the battery compartment as shown here.



3 Replace the battery compartment cover.

WARNING: Replace both batteries at the same time. Don't mix old batteries with new batteries and mix battery types (for example, alkaline and lithium batteries). Don't open or puncture the batteries, install them backwards, or expose them to fire, high temperatures, or water. Don't charge nonrechargeable AA batteries. Keep batteries out of the reach of children.

#### **Battery Level Indicator**

To check the battery level, choose Apple ( ) > System Preferences, and then click Trackpad. The battery level indicator is in the lower-left corner.

*Note:* When you aren't using your trackpad, it goes to sleep to conserve battery power. If you won't be using your trackpad for an extended period, turn it off.

### Cleaning

To clean the outside of your trackpad, use a lint-free cloth. Don't get moisture in any openings or use aerosol sprays, solvents, or abrasives.

### **Ergonomics**

For information about ergonomics, health, and safety, visit the Ergonomics website at www.apple.com/about/ergonomics.

#### More Information

For more information about using your trackpad, open Mac Help and search for "trackpad."

For support and troubleshooting information, user discussion boards, and the latest Apple software downloads, go to www.apple.com/support.

electronic s