



THE SENTRY

QUICK START GUIDE




★ Setting Up Your Phone

Welcome. This guide will show you how to set up and use your phone, access features, and find help.

Optional: Insert the microSD Card*

If you have a microSD card, open the SIM/microSD card slot cover, and carefully slide it into the slot with the gold contacts facing down. Replace the cover; making sure that it is completely closed.



* The microSD card is sold separately.

Optional: Replace the SIM Card

Your phone comes with the SIM card already installed. If you need to replace it, follow these steps.

1. Open the SIM/microSD card slot cover, located on the right side of the phone.
2. Using the included SIM/SD tool, press to release the SIM card, then gently pull it out of the slot.
3. Carefully press the new SIM card into the slot with the gold contacts facing down.
4. Replace the cover; making sure that it is completely closed.



WARNING! Failure to completely reseal the SIM/microSD card slot cover may lead to water or other liquids entering the casing, which may cause damage to the phone.


★ Setting Up Your Phone

Charge the Phone

Your phone comes with a pre-installed, non-removable battery. Before turning on your phone, charge it fully.

Your phone comes with a USB/Charger Adapter and a USB cable that connect together to charge your phone.

Carefully slide your USB charging cable into the port on the bottom right side of your phone.



WARNING! Please use only an approved charging accessory to charge your phone. Improper handling of the USB/Charging Port, as well as the use of an incompatible charger may cause damage to your phone, and void the warranty.

- Connecting the charger improperly may cause serious damage to the phone. Any damage caused by misuse is not covered by the warranty.
- Ensure that there is no foreign material, such as sand or dust near the USB/Charging Port.
- Be careful not to damage or detach the SIM/microSD card slot cover. A damaged or missing cover can result in water damage to the device.

★ Device Overview

The Sentry was designed specifically to appeal to U.S. armed forces members and their families. From the cockpit inspired rear camera, to the chevron back panel, this device combines style with toughness.



NOTE: Devices and software are constantly evolving – the screen images and icons you see here are for reference only.

★ Using Your Phone

Turning Your Phone On/Off

- To turn ON, press and hold the Power/Lock Key.
- To turn OFF, press and hold the Power/Lock Key and follow the instructions.

Locking and Unlocking Your Phone

Prevent accidental key presses by locking your phone.

- To LOCK, press the Power/Lock Key.
- To UNLOCK, press the Power/Lock Key and then swipe your finger up, to unlock.

Using the Touch Screen

Use touch gestures to move around the screen, open menus, select items, zoom in or out on web pages, and more.

Swipe – Swipe by quickly sliding your finger in any direction.

Drag – Drag by touching an item and sliding it to a new position.

Double-Tap – Tap two times rapidly to zoom in or out on a web page or picture.

Multi Touch – Pinch or spread your thumb and index finger to zoom in or out.

★ Customer Information

Your Wireless Device and Third Party Services

Many services and features offered through this wireless device are provided by or in conjunction with third parties. Your wireless service provider or the phone retailer, are not responsible for your use of this wireless device or any applications, services and products including any personal information you choose to use, submit or share with others. Specific third party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing Aid Compatibility Information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult the phone retailer.

©2016 Project Freedom. Project Freedom, Sentry and their respective design marks are registered trademarks of Project Freedom, LLC. All rights reserved. Screen images simulated. Appearance of the device may vary. LTE is a trademark of ETSI.



★ Using Your Phone

Making a Call

1. From the Home screen, tap the Phone icon.
2. Enter the number you want to call, and tap the Phone icon to place the call.

Receiving a Call

- Tap ANSWER to accept the incoming call.
- Tap DISMISS to ignore the incoming call.

Setting Up Voice Mail

1. From the Home screen, tap the Phone icon.
2. Dial *86 and tap the Phone icon to place the call.
3. When you hear the greeting, tap # to interrupt.
4. Follow the instructions to set up your voice mail.

NOTE: Voice mailboxes not setup within 45 days will be canceled. Your voice mailbox is not password protected until you create a password by following the setup instructions.

Sending a Text

1. From the Home screen, tap the Message icon.
2. Tap the Compose icon to start a new message.
3. Enter a contact's name or number in the To field and enter your message in the text field.
4. To add an attachment to your message, tap the Paperclip icon.
5. Tap the Send icon to send your message.

★ Using Your Phone

Taking Photos

1. From the Home screen, tap Camera.
2. Tap the Shutter icon to take a picture (if shown) or just tap the screen.

TIP: From the Lock screen, press the Power/Lock key twice to open the Camera app.

Setting Up Email

1. From the Home screen, tap Apps > Settings > Accounts.
2. Select the desired email provider.
3. Enter your email address and password and any other necessary information.

Installing Apps

Hundreds of thousands of apps are available to download from the Google Play Store.

1. From the Home screen, tap the Play Store icon.

Viewing Apps

To view preloaded or downloaded apps on your phone, from the Home screen, tap the Apps icon.

Uninstalling Apps

1. From the Home screen, touch and hold the downloaded app icon you would like to remove.
2. Drag it to X Remove, and when the font turns red, release your finger to uninstall.

★ Support & More

Get Help Using Your Phone

- From your computer, visit:
www.projectfreedom.com/Support

Customer Service

Call (800) 467-5842

More Information

Download a User Guide from www.projectfreedom.com or call (800) 467-5842 to order a copy.

★ Activate Your Device

Activate Online:

- Before you start, please have your IMEI and SIM Card ICCID on-hand. This information can be found on the retail box label.
- Go to <http://www.verizonwireless.com/certifieddevice>
- Follow the instructions on the website to add your smartphone to your existing wireless account or to create a new account.