材质: 80g 铜版纸 尺寸: 97*97mm 风琴折页 (双面印刷) 印刷颜色: 单黑

AIHOOS

AIHOOR A1 USER MANUAL

Model: A1 AUSOUNDS Intelligence, LLC. www.aihoor.net | info@aihoor.net Designed by AUSOUNDS In California USA

CE F© RoHS & Z


FCC ID: 2AZLD-ARA1

user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number. Package Contents Charging Case ● Four Pairs of Ear-Tips (XS/S/M/L) ● USB-A to C Cable Ouick Start Guide **Product Diagram**

Thank you for purchasing the AIHOOR A1 True Wireless Earbuds. Please read this

Specifications Earbuds AIHOUR AI A2DP, HFP, HSP, AVRCP 1 x 10mm / 0.3" speaker driver 101dB ±3dB 20Hz – 20kHz 32 ohm MEMS mic (microphone chip)

• The earbuds should be stored in the case when not in use. - 03 -



Turn on the Bluetooth of your mobile phone.

take it out again to enter pairing mode.

repeat the previous pairing steps.

AUTOMATIC CONNECTION

- 2. Open the charging case, they will automatically turn on and enter the pairing
- 3. Turn on the pairing function on the device to be paired with the earbuds. 4. From the list of available devices, Find and select "AIHOOR A1" from the list of available devices.
- 5. If a code or PIN code is required for pairing, please enter " 0000".

- When you turn on the earbuds, they will automatically reconnect to the
- last-paired device or enter pairing mode if no paired device is found.

 To clear the pairing list, take either of earbuds out of the charging case, and then tap touch-sensitive panel for 7 times, After that, put the earbud back in and
- In pairing mode, the earbuds will automatically turn off after 5 minutes if no
- If one of the earbuds has no sound output, put both earbuds back into the
- If one of the earboas and sold of the charging case and take them out again.
 The maximum wireless operating range is 10m (33ft). If you exceed this range, the earbuds will disconnect from your paired device. The connection will be re-established if you re-enter the wireless range within 5 minutes. The earbuds will automatically reconnect to the last-paired device. To connect with other devices,

Controls & LED Indicators

Streaming Audio
Once paired, you can wirelessly stream audio from your device to the earbuds. Music will automatically pause when you receive an incoming phone call and resume once the call has ended.

Skip to next track

Active Noise Canceling

Active noise canceling funct earbuds. onality requires the use of both

Turn on / off

Taking Calls

I akiliy Calis	
Answer or end a call	Tap the touch-sensitive panel on either earbud to answer a call, and touch and hold for 2 seconds to end the call.
Reject an incoming call	Touch and hold either earbud for 2 seconds
Use Siri or other voice assistants	While your device is connected, triple-tap either earbud

The earbuds are on, but not connecting to my device For the earbuds and your device to establish a connection, you need to put them both in pairing mode. Please follow the instructions in the Pairing section of this manual.

I've connected the earbuds with my smartphone but can't hear any sound

Double-check the volume level on your smartphone and the earbuds. Some
smartphones require you to set up the earbuds as an audio output device before the audio can be transmitted. If you're using a music player or other device, please make

The sound isn't very clear or the caller can't hear my voice clearly
Adjust the volume on your smartphone and the earbuds. Try moving closer to your smartphone to rule out the possibility of interference or wireless range related issues.

What's the wireless range of the earbuds?

The maximum range is 10m (33ft). However, the actual range depends on environmental factors. For optimal performance, keep your device connected within a range of roughly 4m to 8m and make sure that there are no major obstacles (like reinforced steel walls) between the earbuds and your device.

Try charging the earbuds for a while. If the earbuds still won't power on, please contact our support team at the email address given in 'Warranty & Customer

I put the earbuds back in the charging case, but the earbuds are still

The charging case is probably out of power. Try charging it.

Product Care & Use

Keep away from liquids and extreme heat. Don't use the earbuds at high volume for extended periods, as this may cause.

Warranty & Customer Support

For questions, support, or warranty claims, contact us at the address below that corresponds with your region. Please include your Amazon order number and product model number.

- 07 -

Amazon EU orders: info@aihoor.net Amazon CA orders: info@aihoor.net Amazon JP orders: info@aihoor.net

*Please note, AIHOOR can only provide after sales service for products purchased directly from AIHOOR. If you have purchased from a different seller, please contact them directly for service or warranty issues.

FCC Information for UsersChanges or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect thee quipment into anoutlet on a circuit different from that to which
- the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CE Statement Max RF power level:

Max RF power level:
BT classic (2402–2480MHz): 2.281dBm
RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation (1999/519/EC).
CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT

TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

- 09 -

Excessive sound pressure from earphones and headphones can cause hearing



Hereby, Shenzhen Ausounds Intelligent Co.,Ltd.A1. declares that the radio equipment type (True Wireless Earbuds, A1) is in compliance with Directive



Notice: This device may be used in each member state of the EU.

WARRANTY CARD DATE OF ORIGINAL PURCHASE DESCRIPTION OF PROBLEM - 12 -