

STANLEY Model 28401 Keyfob Setup Instructions

Congratulations on your purchase of the Stanley® SilvereWeb™ Door System. The keyfob remote control (Model 28401) lets you turn your entry lights on and off by remote control as you approach your home, and also lets you lock and unlock your entry door by remote control.

To turn your entry lights on, press the button with the solid light bulb on it.

To turn your entry lights off, press the button with the outline of a light bulb on it.

To lock your door, press the LOCK button.

To unlock your door, press the UNLOCK button.

To flash your entry lights (if there is an emergency) press the PANIC button (press the lights on or lights off button to stop the flashing).

If you have more than one SilverWeb door installed, press and hold the 2nd button then press any of the other buttons to control the second door.

Product warranty

If you haven't already done so, take a moment right now to fill in the product warranty card and drop it in the mail. Sending us your card will help us keep you informed when new Stanley products and product enhancements become available.

F.C.C. CAUTION • THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

This equipment generates and uses radio frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturers instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for remote control security devices in accordance with the specifications in Sub-Part B of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by unplugging the equipment, try to correct the interference by one or more of the following measures.

- Reorient the antenna of the radio/TV experiencing the interference.
- Relocate the Home Automation Interface with respect to the radio/TV.
- Move the Home Automation Interface away from the radio/TV.
- Plug the Home Automation Interface into an outlet on a different electrical circuit from the radio/ TV experiencing the interference. If necessary, consult your local Dealer for additional suggestions.

NOTE: No changes or modifications may be made to this unit. Any changes made to the unit will void the user's authority to operate the unit.

Stanley Door Systems, Novi, MI 48083

DR28401-6/98

P.3/3