## Conditions specific to AB-Access Extender:

AB-Access Extender complies with Part 15 of the FCC rules. The device is specifically designed to be used under Part 15, Sub-part E of the FCC rules and regulations. Operation is subject to following conditions:

**IMPORTANT NOTE**: To comply with the FCC RF exposure compliance requirements, the following antenna installation and device operating configurations must be satisfied –

• The device to utilize a fixed mount antenna, for use on a permanent outdoor structure.

• The device to be installed by qualified installation/deployment personnel, and a minimum of 1.5 meters of separation must exist between the device and persons, when the device is operating.

• The device installers and operators should be aware of the transmitter operating conditions, specified in the AB-Extender installation manual and other associated user documentation, as well as the antenna co-location requirements of Part 1.1307 (b) (3), of the FCC rules, pertaining to RF exposure.

- The device may not cause harmful interference.
- The device must accept interference received, including interference that may cause undesired operation.

The device is intended to be used only when installed in accordance with instructions outlined in this manual. Failure to comply with these instructions may void the user's authority to operate this device and/or the manufacturer's warranty. Furthermore, any unauthorized modification or changes to this device without the express approval of Adaptive Broadband Corporation may also void the user's authority to operate this device.