

Car Message Sign

Express your emotions while driving!
Car to car driver expression!

Car Message Sign instructions.
Read, keep and understand before using product.



Smiling Face



Frowning Face



Thanks



Idiot Face



Contents of box include:

- Remote control
- Main display unit
- 2 suction cups

Warning: to reduce the risk of fire or shock hazard, do not expose this equipment to rain, any liquid or moisture.

- All operating & use instructions must be followed.
- Before battery installation, wipe with a soft dry cloth to ensure clean/good contact.
- Keep product away from water, moisture &/or any liquids at all times.
- **Only use batteries specified.**
- Attachments not recommended should not be used with the product. Such use will infringe product terms & conditions.
- Do not clean product while in use. De-install & clean with dry soft cloth in a stationary & safe environment.
- Do not use/place this product in with any unstable attachment, bracket, fixing, or any other item.



With the bracket unlocked, pull the remote control off.



Removing the bracket has 3 purposes.

- (1) To load batteries, 23A 12V alkaline
- (2) Fix the metal bracket to the front wind-screen first, then slot remote control onto bracket
- (3) Remote control can be used without the bracket, kept in a small compartment for example



Main Unit Batteries:
4 x AA alkaline (1500 mA min.) insert into battery cap on rear of unit.



Fix to rear window Slide suction cup in slider to suit angle of rear windscreen, so that main unit hangs vertical. Lightly wet suction cup press firmly to rear window & screw tight.



The remote control can be fixed to the front windscreen using the metal bracket supplied. Apply a little pressure as shown below to unlock the metal bracket from the remote control.

Do not use product in a dazzling &/or distracting manner. Keep product away from water. Clean with a soft dry cloth only. Keep product away from children. Do not expose product to extreme physical force &/or temperatures. Do not store batteries in either main unit or remote unit for longer than advised battery life (to avoid battery leakage & contamination).

Car Message Sign

Express your emotions while driving!
Car to car driver expression!

Remote control can be positioned anywhere, with or without its bracket. For fixing to the front window, remove bracket from the remote control & adjust suction cup to suit angle of front window. Fix bracket to window by tightening the suction cup (choose a position offering the best line of sight for signal communication with main unit). Slot remote control onto the bracket. Remote must be pointing at main unit in order to activate messages.



Do not position so as to be dazzling, distracting, blocking or obstructing view in any way.

Do not use this product if battery leak has occurred inside.
Do not shake product.
Do not disassemble product
Product performance is dependent on the batteries used to power it, which should be Alkaline.
Users are advised to keep spare batteries at hand.

FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT



=

Smiling Face



=

Frowning Face



=

Thanks



=

Idiot Face

Learn button symbols prior to installing & use. Pressing the corresponding buttons will activate the signs to display. Unit is not programmable.

Battery life (based on using 1.5V 1500mAh AA) Based on a daily usage of 10 times one day. Main unit lasts 60-90 days; remote control lasts 180 days. Automatic power saves. Main unit automatically shuts down into power save mode if no remote control signals.

This product has a year warranty active from the date of purchase and covering only genuine product faults. This warranty does not apply to improperly installed, handled, abused, and damaged. Batteries are not covered by warranty. This warranty applies only to Car Message Sign.