# Studio G2 HD

1

Quick Guide





# **ATTENTION**

- For instructions or any questions pertaining to phone usage, please click on the BLU Help icon
  on the home screen of the phone. Also included in BLU Help is a product registration link and
  technical support. You may also access the BLU help page by visiting the following address:
  manuals.bluproducts.com
- O Para obtener instrucciones o preguntas relacionadas con el uso del teléfono, por favor haga clic en el icono de BLU Help en la pantalla principal del teléfono. También se incluye en BLU Help un enlace para registro del producto y soporte técnico. Usted también puede acceder la página de BLU Help visitando la siguiente dirección: manuals.bluproducts.com
- Para obter instruções ou perguntas relacionadas ao uso do telefone, por favor, clique no
  ícone BLU Help na tela principal do telefone. Também incluído no BLU Help um link para
  registrar o produto e suporte técnico. Você também pode acessar a página de BLU Help
  visitando o sequinte endereco: manuals.bluproducts.com
- Pour des instructions ou pour toutes questions sur l'utilisation du téléphone, veuillez cliquer sur l'icône Aide BLU sur l'écran d'accueil du téléphone. L'Aide BLU comprend un lien pour enregistrer le produit et pour le soutien technique. Vous pouvez aussi accéder à la page aide BLU en visitant l'adresse suivante: manuals.bluoroducts.com

## SAFETY INFORMATION

## Transportation Safety

Please observe all transportation laws and regulations.

PLEASE DRIVE RESPONSIBLY - DO NOT TEXT & DRIVE

## **Hospital Safety**

Please follow hospital rules and limitations.

Please turn off your mobile phone when near medical instruments.

## Airport Safety

Remember to follow all airport and flight safety regulations.

## Water Hazard

Your phone is not waterproof. Keep your phone away from water or liquid to avoid damage.

## **Emergency Calls**

Make sure your mobile phone is switched on and in a service area. On home screen, tap the phone key and dial the emergency number.

## **Battery Usage**

For better performance and longer battery life, it is recommended that you charge the battery fully before using the mobile phone for the first time and that you initially complete two to three charge cycles.

BLU S0270UU V05

4

# **KEY FUNCTIONS**



5




Used to power on/off the device and to lock the screen.  Power On / Off  >> Long press the power button to power on  >> While the phone is powered on, long press to access the power off menu or click to lock the screen  Volume  Adjusts the ringer volume, call volume, and multimedia volume.  Home  The home button pauses any current action and returns to the home screen.  Recent Apps  Opens a list of recently opened applications that allows you to switch conveniently between them. This option can also close any open applications by swiping to the side.  Back  Returns to the previous screen; Closes the keyboard, any open program, or any menu option.  USB Port  Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port  Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera  A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera  A high-resolution rear camera to take pictures and video.  Flash  Provides light for pictures in low-light conditions. It also may be used as a flashlight.
Non/Off  None press the power button to power on None press to access the power off menu or click to lock the screen None Adjusts the ringer volume, call volume, and multimedia volume.  Home The home button pauses any current action and returns to the home screen.  Recent Apps Opens a list of recently opened applications that allows you to switch conveniently between them. This option can also close any open applications by swiping to the side.  Back Returns to the previous screen; Closes the keyboard, any open program, or any menu option.  USB Port Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera  A high-resolution rear camera to take pictures and video.
Wolume Adjusts the ringer volume, call volume, and multimedia volume.  Home The home button pauses any current action and returns to the home screen.  Recent Apps Opens a list of recently opened applications that allows you to switch conveniently between them. This option can also close any open applications by swiping to the side.  Back Returns to the previous screen; Closes the keyboard, any open program, or any menu option.  USB Port Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera
Home The home button pauses any current action and returns to the home screen.  Recent Apps Opens a list of recently opened applications that allows you to switch conveniently between them. This option can also close any open applications by swiping to the side.  Back Returns to the previous screen; Closes the keyboard, any open program, or any menu option.  USB Port Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera
Recent Apps Opens a list of recently opened applications that allows you to switch conveniently between them. This option can also close any open applications by swiping to the side.  Returns to the previous screen; Closes the keyboard, any open program, or any menu option.  USB Port Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera A high-resolution rear camera to take pictures and video.
option can also close any open applications by swiping to the side.  Back Returns to the previous screen; Closes the keyboard, any open program, or any menu option.  USB Port Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera A high-resolution rear camera to take pictures and video.
USB Port Charges the device and transfers data such as documents, music, and video between your device and a PC.  Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera A high-resolution rear camera to take pictures and video.
Headset Port Connect earphones to this port for hands-free capabilities. You may also to listen to music or FM radio.  Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera A high-resolution rear camera to take pictures and video.
Front Camera A high-resolution front camera to take pictures and video. This option is ideal for self-portraits.  Rear Camera A high-resolution rear camera to take pictures and video.
Rear Camera A high-resolution rear camera to take pictures and video.
•
Flash Provides light for pictures in low-light conditions. It also may be used as a flashlight.


## INTRODUCTION

Warning: Installation of the SIM Card the reach of children. The SIM card and its contact are easily

card. Note: শ্রীটেরঞ্জের বিধান কি স্কুল্মান ক্রিটার ক্রিক্স করিছে বিধান করিছে ক্রিটার ক্রিটার ক্রিটার ক্রিটার ক্রিটার করিছে করিছে বিধান ক

- Remove the rear cover. Insert the SIM card.
- Insert the SD card (For additional storage capacity)





O Replace the rear cover and power on the phone.

,

## DEVICE CONFIGURATION

When you initially power on your phone, there will be a series of steps to set up basic features.

#### INSERT SIM

Insert your SIM card so the phone can register to the network.

#### SELECT LANGUAGE

While on the Welcome screen, please scroll to select your language.

#### SELECT WI-FI

This process allows the device to connect to the internet. Click on the desired Wi-Fi network that the device that will be connected. Please note that any unsecured Wi-Fi networks can be connected to without credentials and any secured Wi-Fi networks require a password for credentials prior to connection. It is recommended that you connect to a Wi-Fi network to check for software updates prior to startup.

#### ADD YOUR ACCOUNT

Sign in to your Google™ account in order to keep accounts streamlined with Google services. Your Gmail™ account will be used for some Google programs that include Google Play™ Store, Google Drive™, Google +™ and Google Wallet™. If you do not have a Google account, click to create a new account.

#### GOOGLE SERVICES

Click to add or remove Google services that include Backup, Location Service, and Google Now<sup>TM</sup>. In this step, you can also setup payment info if desired.

#### **RESTORE APPS & DATA**

You can restore your previous applications and data that was stored from another device. You also have the option to setup the phone as a brand new device.

Google, Google Play and other marks are trademarks of Google Inc.

#### FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

## Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value