


## User Manual


### VoxTube™ 100 Bluetooth® Headset



### 1 Overview


Thank you for purchasing VoxTube 100. Before installing and using this product, please read the user manual thoroughly. Wish you a pleasant experience!

#### About VoxTube 100



### 2 Accessories

We have supplied you with 6 earbuds and 3 ear hooks. Try all the size, pick the one that is most comfortable and fit for you.




Micro USB Charging Cable

### 3 Specification

Model	BTV100
Talk time	Up to 4 hours
Standby time	Up to 4 days
Charge time	2 hours (for full)
Wireless range	33ft (10m)
Bluetooth	V3.0
Connection	Supports 2 active mobile devices at the same time
Voice quality	HD Audio (16KHz)
Weight	6g
Dimension	61.3(L)x14(W)x6(H)mm

### 4 Charging

Use the included USB cable to connect VoxTube 100 to any powered USB equipment.



#### Charge VoxTube 100

- When VoxTube 100 has low battery level, there will be "Battery low" voice prompt.
- Green LED is on during charging.
- LED is off when charging is completed.
- To fully charge VoxTube 100 takes 2 hours.
- If you charge VoxTube 100 without turning it off, it is still connected to your mobile devices.

### 5 Pairing


#### Pair VoxTube 100 with your FIRST phone

- Set the on/off switch to the ON position, green LED will flash three times, "Power On" will be heard; press multi-function button for 2 seconds, green LED will flash quickly, "Pairing" will be heard, pairing mode is activated (If VoxTube 100 is being used for the first time, just set the on/off switch to the ON position to enter pairing);
- Go to your phone's Bluetooth settings, ADD or SEARCH FOR DEVICES when "MIPOW\_Vox100" appears, select it or enter passcode "0000" if asked, announced "Beep" when paired.

(If your VoxTube 100 was connected before, then it will automatically reconnect with the last connected mobile device once powered on again.)

#### Pair VoxTube 100 with your SECOND phone

Battery capacity on iPhone shows up automatically after it is connected.



Pairing two phones for the first time

When VoxTube 100 needs to pair with a second device, it needs to be restarted and reactivate the pairing mode. And then you can pair it with your second phone following the first phone's pairing steps.

### 6 Talking

#### Talking

**POWER ON**  
Set the on/off switch to the ON position, green LED will flash thrice, "Power On" is heard, headset is in standby mode.

**POWER OFF**  
Set the on/off switch to the OFF position, "Power Off" is heard

**ANSWER A CALL**  
Tap Multi-function Button once, prompt tone is heard.

**HANG UP A CALL**  
Tap Multi-function Button once while on call, "Beep" tone is heard.

**REJECT A CALL**  
Double-Tap Multi-function Button to reject a call, prompt tone is heard.

**REDIAL LAST NUMBER CALLED**  
Double-Tap Multi-function Button to redial last number called when it is in standby mode.

**CANCEL A CALL**  
Tap Multi-function Button once to cancel a call when dial out a number.

### 6 Talking

#### INITIATE VOICE DIALING

While in standby mode, press & hold Multi-function Button for 2 seconds, and then speak a command. (support Bluetooth enabled mobile phone)

#### STOP VOICE DIALING

While in voice dialing, press and hold Multi-function Button for 2 seconds to stop voice dialing.

#### TRANSFER A CALL

When you are talking, press and hold Multi-function Button for 2 seconds to transfer the call between the phone and headset.

#### ANSWER CALLS FROM TWO PHONES

Tap Multi-function Button once to answer a call from either one of the connected phones.

While on a call, tap Multi-function Button once to end it and answer the other incoming call.

If you want to hold a call and answer the other incoming call, tap Multi-function Button twice.

**NOTE**  
When connected to multiple phones, Redial and Voice Dial will work on the first connected mobile phone

### 7 Other Functions

#### Play Music

VoxTube 100 is capable of streaming over Bluetooth either from a mobile phone or any other Bluetooth device supporting A2DP. Once you have paired your VoxTube 100 with your mobile phone or Bluetooth music player, use your phone or music player to play and pause. When you receive call, the music will automatically be suspended and you will be able to answer or reject a call through the VoxTube 100. Once you end a call, the music should recommence.

#### Charge to reset

If you charge VoxTube 100 without turning it off, it is still connected to your mobile devices.

#### Exit pairing mode

Under the pairing mode VoxTube 100 will deactivate the mode if there is no connection in 90 seconds.

#### Auto power off

After 5 minutes connectionless mode, VoxTube 100 will auto power off.

### 8 LED Indicator

Connected	LED blinks twice every 7 seconds
Disconnected	LED blinks twice every 2 seconds
Coming call	LED blinks continually
Talking	LED blinks once every 7 seconds
Turn on	LED blinks thrice
Pairing mode	LED blinks quickly
Music play	LED blinks once every 7 seconds
Charging	LED is on
Finished charging	LED is off

### 9 FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

### 9 FCC Statement

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

**Caution**  
The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

### 10 Troubleshooting & FAQ

#### I hear crackling noises

For the best audio quality, always wear your headset on the same side of your body as your mobile phone.

#### I cannot hear anything in my headset

- Ensure that the headset is paired with the phone.
- Make sure that the phone is connected to the headset-if it does not connect either from the phone's Bluetooth menu or by pressing the Multi-function Button, following the pairing instructions in Section 5.

#### I have pairing problems

you may deleted your headset pairing connection in your mobile phone. Follow the pairing instructions in section 5.

#### Will the VoxTube 100 work with other Bluetooth devices?

The VoxTube 100 is designed to work with Bluetooth mobile phones. It can also work with other devices that are compliant with Bluetooth version 3.0 and support a headset, hands-free profile, A2DP music play.

#### I cannot use reject call, redial or voice dialing, battery App meter

These functions are dependent on your phone supporting them. Please check your mobile phone's manual for further details.

### 11 Maintenances

#### VoxTube 100

- Always store the VoxTube 100 with the power off and safely protected.
- Avoid storage at extreme temperatures (above 45°C or below -10°C). This can shorten battery life and may affect operation.
- Do not expose the VoxTube 100 to rain or other liquids.

#### Notes on Environmental Protection

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collection points that are set up for this purpose or designated points of sale.

However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations.

By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution in protecting our environment.

### Warranty Card


Thank you for your purchase of MIPOW's product. MIPOW warrants that the product is at the time of its original purchase free of defects in workmanship and material. This Limited Warranty for the product shall last for twelve(12) months from the date of original purchase.


This original warranty card and original invoice must be presented at the time you require warranty service or such warranty will be voided.

This limited warranty is valid only if the product is used for the purpose for which it was designed. It does not apply to damage or loss caused by negligence, physical abuse, misuse; accident; exposure to moisture; dampness or extreme thermal; unauthorized modifications; unauthorized opening or repair; forces of nature; or other actions beyond the reasonable control of MIPOW.

In case of when the warranty does not apply, a repair or replacement charge will be incurred. The customer shall be responsible for sending the defective product to and collecting the repaired or replaced product from the service center.

NB: MIPOW reserves the right to interpret the terms and conditions contained herein; and the right for any changes without prior notice.





### Service Centre

**Bluetooth** **MIPOW**  
**使用手冊**

**VoxTube™ 100 藍牙耳機**




V1.0

**1 產品介紹**  
VoxTube 100  
感謝購買VoxTube 100藍牙耳機。使用之前請仔細閱讀該手冊。祝您有愉快體驗！

**VoxTube 100產品展示**




**2 產品配件**  
VoxTube 100  
特別設計6種耳帽和3個耳掛,方便選取最合適的一款佩戴。



**3 產品規格**  
VoxTube 100

產品型號	BTV100
通話時間	4小時
待機時間	4天
充電時間	2小時
無線傳輸距離	10米(max)
藍牙	藍牙 3.0
連接	同時連接兩部手機
音質	高品質音質 (16KHz)
重量	6克
尺寸	61.3(L)x14(W)x6(H)mm

**4 充電**  
VoxTube 100  
將USB充電線的一端插入電腦或適USB輸出端接口,另一端插入藍牙耳機Micro USB充電端口。



**VoxTube 100充電**

- 當VoxTube 100的電量低時,語音提示“Battery low”。
- 使用USB充電線給VoxTube 100充電。
- 充電過程中VoxTube 100上的綠色指示燈常亮。
- 充電完成時VoxTube 100上的指示燈熄滅。
- 充電時間大約需要2小時。
- 充電時VoxTube 100不復位關機,會保持與設備的連接。


**5 藍牙配對**  
VoxTube 100

**將VoxTube 100與一部手機配對**

- 撥動開關到ON檔,綠燈閃爍3次,有開機提示音“Power On”,再長按功能鍵2秒,會看到綠燈快閃,有提示音“Pairing”,表明藍牙耳機在匹配搜尋狀態(如果VoxTube 100是第一次使用,只需將開關撥至ON,即進入配對。);
  - 點擊添加或搜索藍牙設備,搜索到“配對設備:“MIPOW\_Vox100”後選中它(如果要求輸入密碼請輸入“0000”),音調提示。然後在手機的藍牙設置中點選連接到VoxTube 100,語音提示“嚶”。
- (如果藍牙連接過手機,那麼開機後會自動重連最後一次連接的手機)

**將VoxTube 100與二部手機配對**

與iPhone藍牙配對後螢幕上自動顯示VoxTube 100剩餘電量



首次連接兩部手機  
當VoxTube 100需要連接第二部手機時,需重新開啟VoxTube 100並進入配對模式,然後參照第一部手機的配對步驟進行配對。

**6 通話**  
VoxTube 100

**通話**

- 開機** 撥動開關到ON檔,綠燈閃爍3次,有開機提示音“Power On”即為開機。
- 開機** 在開機狀態下,撥動開關到OFF檔,有關機提示音“Power OFF”。
- 來電接聽** 外部來電時,短按多功能鍵,接聽來電,有提示音。
- 掛斷電話** 通話中短按開機鍵,聽到“嚶”提示音即掛斷電話。
- 來電拒接** 外部來電時,雙擊多功能鍵,拒絕來電,有提示音。
- 尾效重撥** 在待機狀態下,雙擊多功能鍵,會撥出最後撥出過的一組號碼。
- 取消撥號** 在撥出電話時,短按多功能按鍵,取消正在撥出的電話。

**6 通話**  
VoxTube 100

**通話**

- 語音撥號** 連接好藍牙手機,待機條件下,長按功能鍵2秒就可以語音撥號了(需要手機藍牙的支持)
  - 停止語音撥號** 在語音撥號狀態下,長按功能鍵2秒可結束語音撥號。
  - 聲音切換** 在通話狀態下長按多功能鍵2秒,將聽到的一聲,這時聲音,就從耳機轉到手機上。同樣的操作可以將聲音就從手機轉回到耳機上。
  - 一拖二** 當1個手機通話,另一個手機來電,短按功能鍵可接過來電,掛斷第一個通話;當1個手機通話,另一個手機來電,雙擊功能鍵可接過來電,保持第一個通話。
- 提示** 當VoxTube 100與多部手機連接時進行重撥和語音撥號控制的是最先連接的那個手機

**7 其他功能**  
VoxTube 100

**音樂播放**

設備上的音樂將VoxTube 100與手機或藍牙音樂播放設備連接配對後可以通過VoxTube 100來控制播放/暫停音樂,音樂播放過程中如有電話打入,VoxTube 100將暫停播放音樂方便通過VoxTube 100撥號接聽/掛斷電話,通話完畢後VoxTube 100自動播放音樂

**充電復位功能**

充電耳機不復位關機,充電時耳機與手機保持連接

**退出配對模式**

90秒退出配對模式,處於無連接待機狀態

**自動關機**

無連接約5分鐘自動關機

**8 LED指示燈閃爍狀態**  
VoxTube 100

耳機連接狀態LED指示	7秒閃2次綠燈
耳機無連接狀態	2秒閃2次綠燈
來電LED	綠燈閃爍
通話LED	7秒閃1次綠燈
開機	綠燈閃爍3次
配對模式	綠燈快閃
播放音樂	7秒閃1次綠燈
充電中	綠燈常亮
充電完成	綠燈熄滅

**9 FCC 聲明**  
VoxTube 100

任何未經負責合規性檢查方明確批准的變更或修改行為都將取消使用者操作該設備的權利。

聯邦通信委員會合規性聲明  
依照聯邦通信委員會條款第15部分規定,該設備經測試證實符合B類射頻設備標準。該限制條款對該設備應用於家用裝置中可能造成的危害性干擾提供了合理的保護措施。該設備會生成、使用並放射出射頻能量,如果不按照說明書上的方法進行安裝和使用,則可能對無線通訊造成危害性的干擾。但不保證在特殊情況下沒有干擾。

若該設備對收音機、電視之收訊造成有害干擾(可開/關設備之電源確認),建議使用者以下列一種或多種方式改善干擾狀況:

1. 重新調整或安置接收天線。
2. 增加該設備與接收裝置間的距離。
3. 將該設備連接與該接收裝置不同回路的電源插座。
4. 諮詢經銷商或向資深廣播電視技術人員尋求說明。

**9 FCC 聲明**  
VoxTube 100

該設備符合聯邦通信委員會條款第15條規定。其操作需依照以下兩個條件:

- (1) 該設備不得產生有害干擾,且
- (2) 該設備必須接收任何其干擾,包括產生非預期操作之干擾。

警告  
該生產廠家將不對任何因未經許可而對該設備進行修改所產生的收音機、電視干擾負責。該修改行為可能導致該使用者操作本設備的權利被取消。

**10 故障排除與常見問題解答**  
VoxTube 100

**耳機聲音伴有噪音**

為了保障最好的音訊效果,請將VoxTube 100和手機戴同邊。

**耳機沒有任何聲音**

- 確保VoxTube 100已與手機連接配對。
- 如果VoxTube 100已經與手機連接配對仍然沒有聲音,請重複第4部分重新配對連接。

**無法與藍牙設備配對**

斷開手機藍牙連接,按照第4部份的步驟重新配對。

**VoxTube 100 是否可以與其他藍牙設備兼容**

VoxTube 100 專為藍牙移動設備設計,它同時能與其他兼容藍牙3.0的設備兼容。

**無法使用VoxTube 100掛斷電話、重撥、語音撥號,手機上無法顯示VoxTube 100電量**

以上這些功能取決於手機是否支持,請查閱手機說明書以獲取相關信息。

**11 保養說明**  
VoxTube 100

- 不使用VoxTube 100的時候將其關機後妥當放置
- 避免極端天氣時使用VoxTube 100(大於45°C或低於-10°C),否則會縮短電池續航能力或者影響VoxTube 100功能
- 不要將VoxTube 100暴露在雨和液體中

**環保條款**

在歐盟指令2002/96/EU生效後根據法律規定電器和電子設備應和生活垃圾分開處理。在電器和電子設備超過使用壽命後消費者應將此類產品送到專門電子回收站或指定銷售點。然而,此類產品的處理回收則因所在國家的法律規定而異。產品、使用手冊和包裝上的環保標識根據各個國家的具體規定而異。我們提倡對此類電子設備進行回收再利用操作或用於其他途徑,每個人的小小步都能成就環保事業的一大步。

**Warranty Card**

有限保養  
多謝選購MIPOW產品。MIPOW保證:本產品于購買時並無任何材質或製品上的瑕疵。本產品的有限保養自購買起十二(12)個月內,當需要保養服務時,顧客必須出示保養證正本和發票正本,否則保養將被作廢。保養服務只限於產品在正常使用下有效。此有限保養不適用於因人為疏忽、粗魯的操作、不正確的使用、意外事故、暴露於濕氣之下、潮濕或過度高溫、未經授權的修正、未經授權的開改或修復、不可抗力;或其它MIPOW無法合理控制行為所造成的損壞或損失。如損壞未能合乎本保養條例,顧客將被收取維修或更換零件的費用。顧客必須自行將有瑕疵的產品交到客戶服務中心,並自行取回已修復或更換的本產品。注:MIPOW擁有對本人所述的條件和條件之最終裁決權,及有權隨時對條款和條件作出更改,而無需另行通知。



**MIPOW**  
MAKE IT DIFFERENT

**Service Centre**

型号	BTV100	物料名称	说明书(英+繁)	物料编码	BTV100-SMS-0108
版本号	V1.0	日期	2014.1.3	材质	
工艺		制作	陈新民	品质	
研发(销售)		批准		备注	