



MPow M2
Bluetooth Headset

Specification

- SKU: BTX200
- Talk Time: 15 hours
- Standby Time: 25 days
- Charging Time: 1.5-2 hours
- Wireless Range: 10m (33ft)
- Bluetooth: V4.2
- Weight: 18g
- Size: 185(L)x175(W)x30(T)mm

Accessories

- Micro USB charging cable
- 3.5mm stereo cable
- Boxset

Charging

Use the included Micro USB charging cable to connect the MPow M2 to any USB powered computer or wall charger.

When the MPow M2 has low battery, Battery Low voice prompt can be heard and the white LED indicator will flash. The MPow M2 takes 1.5-2 hours.

Pairing

Under standby mode, press & hold the Next Song button and tap the Multi-Function button. The LED indicator will flash green and white alternately. Put on your device's Bluetooth settings, and search for devices when the MPow M2 appears, select it and pair your device.

On/Off

Set the On/Off Switch to ON. Red LED indicator lights up for 3 seconds, with tone prompt. If the MPow M2 was disconnected with your device before, the last tone can be experienced when MPow M2 is on standby.

Auto-Off

If it will automatically power off if there is no connection for 3 minutes.

Answer Call

Under pairing mode, tap Multi-Function button to answer an incoming call, a prompt tone can be heard.

End Call

While on a call, tap Multi-Function button to end the call, prompt tone can be heard.

Reject Call

Under pairing mode, double tap Multi-Function button to reject an incoming call, prompt tone can be heard.

Music Play

In pairing mode, simultaneously tap the Previous Song and Multi-Function button to initiate a choice that only available for Bluetooth enabled cellphones.

Play/Pause

While listening to music, tap Multi-Function button to play/pause the music.

Volume Up/Volume Down

During a call or music play, tap "+" button to volume up and "-" button to volume down. (The highest and lowest volume will be prompted)

Previous/Next Song

While listening to music, tap "<" button to play previous song, prompt tone will be heard. Tap ">" button to play next song, prompt tone will be heard.

EQ Switch

While playing music, press & hold Multi-Function button to switch between different EQ types. A prompt tone will be heard.

Bluetooth Status Indicator

- Connection: LED indicator every 1 second
- Disconnection: LED indicator every 3 seconds
- Pairing: LED indicator every 1 second
- Full: LED indicator every 2 seconds
- Music: LED indicator every 2 seconds
- Charging: LED indicator on
- Charging complete: LED indicator on

Battery Status Indicator

- There shall be "Battery Low" voice prompt when the battery voltage is between 3.0V and 3.3V. LED indicator will flash red.
- When fully charged, the battery voltage is lower than 3.0V, it will automatically power off.

Wired Connections

While in wired connections, the MPow series in iOS system and Android system.

By standby mode, connect MPow M2 to any audio device via the included 3.5mm jack stereo cable.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference and
- This device must accept any interference received, including interference that may cause undesired operation.

Caution: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Warranty Card

Limited Warranty

Thank you for your purchase of MPow's product. MPow warrants that the product is as the one of the original purchase type factory, workmanship and material. This limited warranty for the product and the (or relevant) months from the date of original purchase. The repair or replacement cost of parts, labor and shipping shall be covered only if the product is used for the purpose for which it was designed. It does not apply to damage or loss caused by negligence, accident, fire, flood, lightning, theft, misuse, or maintenance, damages or adverse natural, abnormal, unpredictable, unauthorized opening or repair, removal of casing, or other reasons beyond the reasonable control of MPow. In case of such the warranty does not apply. A request for replacement charge will be included. The customer shall be responsible for returning the defective product to and collecting the repaired or replaced product from the service center.

MPow reserves the right to interpret the terms and conditions contained herein, and the right for any change without prior notice.

Service Centre

MPow Stereo Bluetooth Headphone MPow M2 Bluetooth

