


### MPOW M3 Bluetooth Headset



#### Specification

SKU: BTX500  
Talk Time: 15 hours  
Standby Time: 25 days  
Charging Time: 2-3 hours  
Wireless Range: 10m(33ft)  
Bluetooth: V4.0  
Weight: 26.5g  
Size: 200(L)x175(W)x45(T)mm

#### Accessories

- Micro USB charging cable
- 3.5mm stereo cable
- pouch

#### Charging

Use the included Micro USB charging cable to connect the MPOW M3 to any USB powered computer or wall charger.

When the MPOW M3 is in low battery, Battery Low voice prompt can be heard and the red LED indicator flashes quickly. Fully charge the MPOW M3 for 2-3 hours.

#### Pairing

Under standby mode, press & hold the Multi-Function button and the MPOW M3 LED indicator will flash blue and white alternately. Then open your device's Bluetooth settings, add or search for devices which "MPOW M3" appears, select it and pair your device.

Under standby mode, press & hold the Multi-Function button and the MPOW M3 LED indicator will flash blue and white alternately for 3 seconds, with turn-off prompt.

#### Call Answer

Under pairing mode, tap Multi-Function button to answer an incoming call, a prompt tone can be heard.

While on a call, tap Multi-Function button to end the call, prompt tone can be heard.

Under pairing mode, Double tap Multi-Function button to reject an incoming call, prompt tone can be heard.

#### EQ Switch

In pairing mode, double tap Multi-Function button to select the last number you called.

#### Play/Pause

While listening to music, tap Multi-Function button to play/pause the music.

#### Volume Up/Volume Down

During a call or music play, tap "+" button to volume up and "-" button to volume down (the highest and lowest volume will be prompted).

While listening to music, tap "C" button to play previous song, prompt tone will be heard. Tap "N" button to play next song, prompt tone will be heard.

#### Switch Callphone & MPOW M3

During a call, press & hold Multi-Function button for 2 seconds to switch the call from MPOW M3 to callphone or from callphone to MPOW M3, a "beep" tone will be heard.

#### Bluetooth Status Indicator

Connection: LED flashes blue every 7 seconds  
Reconnection: LED flashes blue every 2 seconds  
Pairing mode: LED flashes blue every 7 seconds  
Music play: LED flashes blue every 3 seconds  
Battery low: LED flashes blue every 3 seconds  
Charging: LED on  
LED off

Battery Status Indicator:  
1. There will be "Battery Low" voice prompt when the battery voltage is between 3.0V and 3.2V, LED on  
2. When the battery voltage is lower than 3.0V, it will automatically power off.

#### Wired Connections

While in wired connections, the operation varies in OS system and Android system.

PC and Notebook, Tablet, Phone, MP3

While in standby mode, pull out the 3.5mm jack stereo cable to connect with your device.

#### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to use the equipment. This equipment has been tested and found to comply with the requirements for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
1) This device may not cause harmful interference, and  
2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

#### Warranty Card

Thank you for your purchase of MPOW product. MPOW warrants that the product is all the work of original programming, assembly, workmanship and material. This limited warranty for the product is valid for 12 months from the date of original purchase. This warranty does not cover any damage caused by misuse, accident, fire, flood, theft, or any other cause. This warranty is void if the product is used for purposes for which it was not designed. It does not apply to damage or loss caused by fire, flood, theft, or any other cause. Accidental damage to moisture, dampness or other external weather conditions, unauthorized opening or repair. MPOW is not responsible for any other cause beyond the reasonable control of MPOW. In case of which the product does not comply with the manufacturer's change will be covered. The customer must be responsible for returning the defective product to and obtaining the replacement product from the service center.

NB: MPOW reserves the right to change the terms and conditions contained herein, and the right for any change without notice.

#### Service Centre



**產品規格**

產品型號: M3K500  
 通訊時間: 15小時  
 待機時間: 25天  
 充電時間: 2.5小時  
 無線傳輸距離: 10米(33英尺)  
 驅動器: 32mm  
 重量: 255克  
 尺寸: 200(L)x175(W)x45(T)mm

**產品配件**

Micro USB 充電線  
 3.5mm音頻線  
 收納袋

**充電**

將USB充電線的一頭插入電腦或USB輸出裝置，另一頭插入藍牙耳Micro USB充電線口。

**當電量低電時**

藍牙會自動開啟，藍牙會自動開啟，暫停播放。當電量低於15%時，耳機會自動開啟，且自覺快沒電時會自動開啟充電，在2-3小時內完成充電。



**自動開機**

將藍牙開關撥至ON位置開機，藍牙電量2秒，耳機顯示燈，位於藍牙開關處，耳機會自動開機並連接手機。

**暫停/播放**

觸摸耳罩，當藍牙多功能鍵不亮，然後短按一下按鍵，再進入播放狀態。此時藍牙會自動暫停/播放。當藍牙在播放/暫停狀態，打斷手機藍牙功能，再按耳罩，藍牙會自動開機。

**藍牙開關**

已連接手機情況下，有外掛充電時，短按多功能鍵，藍牙開關，有顯示燈。

**EQ切換**

在音樂播放狀態下，短按多功能鍵，EQ相互切換，同時有顯示燈。

**藍牙指示燈狀態**

連續播放狀態：● 播放/暫停  
 未連接狀態：● 播放/暫停  
 藍牙狀態：● 播放/暫停  
 播放狀態：● 播放/暫停  
 暫停狀態：● 播放/暫停  
 藍牙狀態：● 播放/暫停  
 充電狀態：● 播放/暫停

**電池狀態指示**

1.電池電量小於3.3v大於3.0v時低電警告，白燈快閃並有聲音提示。  
 2.電池電量小於3.0v時自動關機。

**從耳機到手機的聲音轉換**

在播放狀態下長按多功能鍵3秒，將聽到第一聲，這時會自動從耳機轉到手機上可播放的動作可以從藍牙從手機轉回耳機上。



**FCC 聲明**

任何未經核准的修改或更改均可能導致性能降低或行為錯誤，且可能導致產品損壞。請務必按照說明書中的說明進行操作。任何未經核准的修改或更改均可能導致性能降低或行為錯誤，且可能導致產品損壞。請務必按照說明書中的說明進行操作。任何未經核准的修改或更改均可能導致性能降低或行為錯誤，且可能導致產品損壞。請務必按照說明書中的說明進行操作。

**藍牙立體身耳機 MIPOL M3 Bluetooth**

**保養**

請務必按照說明書中的說明進行操作。任何未經核准的修改或更改均可能導致性能降低或行為錯誤，且可能導致產品損壞。請務必按照說明書中的說明進行操作。

**Service Centre**

MIPOL