

Next the transceiver needs to be locked into place. This is done by first tightening the black cradle locking knobs located on the front of the docking station. Once these have been tightened the heat sink can also be locked into place by first ensuring that the heat sink fins on the docking station line up with the gaps on the transceiver's heat sink, then pulling down the black heat sink locking clips.



This completes the process of docking the PRC-2090 transceiver into the docking station.



Removable Display Vehicle Mounting Bracket Assembly (2090-05-04)

The removable display mounting bracket enables the LCD unit and handset of the PRC-2090 transceiver to be mounted away from the main body of the PRC-2090 manpack or PRC-2090 vehicle docking station.

Steps to assemble the bracket.



Display vehicle mounting bracket kit.



If the RAM mount is to be used then it must be screwed to the display vehicle mount before the LCD unit is inserted.