



Beatbox Portable™ User Guide




= Spot gloss varnish
DO NOT print Cyan

-- "b" logo should be a spot gloss varnish
-- Matte finish for entire manual




Table of Contents

EN	LED Indicators	4
	Remote Functionality	5
	Important Safety Information	7
	Speaker Placement	9
	FCC Statement	11
FR	Indicateurs DEL	13
	Fonctions de la télécommande	14
	Renseignements de sécurité importants	16
	Positionnement des haut-parleurs	18
	Énoncé de la CFC	20
ES	Indicadores LED	22
	Funcionalidad remota	23
	Información importante sobre la seguridad	25
	Colocación del parlante	27
	Declaración FCC	29
	COFETEL/NOM	30
PT	Indicadores LED	31
	Funcionalidade Remota	32
	Informações Importantes de Segurança	34
	Posicionamento do Alto-Falante	36
	Declaração da FCC	38




1 - Plug in Power




2 - Install Batteries

Batteries must be recycled or disposed of properly.
Les piles doivent être recyclées ou jetées de manière adéquate.
Los baterías deben reciclarse o desecharse de forma adecuada.
As baterias devem ser recicladas ou descartadas adequadamente.




3 - Power On



4 - Initiate Pairing




5 - Activate Pairing



Auto detects docked device when connected
Détection automatique du rattachement de l'appareil une fois connecté
Detecta automáticamente el dispositivo acoplado cuando se conecta
Detecta automaticamente o dispositivo acoplado quando está conectado

6 - Choose Source




7 - Change Source





English

LED Indicators



- Solid: Unit Powered On
- Blink: Pairing Initiated
- Blink (x1): Switching Input



English

Remote Functionality

