

User manual

Model:Remote controller

Bluetooth remote control

Operation manual Android

A:MUSIC MODE

@+A: single hand operation, joystick UP--fast forward, joystick down--Rewind, joystick left -- Last song, joystick right -- next song, C--V+,D--V-, L and A-- play, B-- home page, R-- silent mode

B: game mode (horizontal)

@+B: Horizontal hands operation, joystick UP--left, joystick down--right, joystick left -- down, joystick right -- up, B and C--Enter,A and D-- return, L and R no function;

C: game mode (vertical)

"@+C" : single hand operation, joystick corresponding the keys- up/down/left/right, C--Enter, A/B/L/R--return, D--V-

D: Mouse mode

"@+D" : 360 degree rotation, C--V+, D--V-, L and A--Cursor position, R and B--Return

IOS

A:MUSIC MODE

@+A: single hand operation, joystick UP--fast forward, joystick down--Rewind, joystick left -- Last song, joystick right -- next song, C--V+,D--V-, L and A-- play, B-- home page, R-- silent mode

B:Game MODE

"@+B or C" : Hands operation, joystick UP--aq, joystick down--dc, joystick Left--xz, joystick Right--we, A--uf, B--hr, C--yt, D--jn, L--lv, R--og(Horizontal use in game mode)

D-Default: mode

"@+D" : single hand operation, joystick UP--fast forward, joystick down--Rewind, joystick left -- Last song, joystick right -- next song, C--V+,D--V-, A-- play, B-- home page

360 degree bar

Function switch key

Open key

function selectors (game mode)

function selectors (music, video mode)

function selectors (mouse, self timer mode)

function selectors (VR, self timer, video mode)

ESC

Enter

Android/ios switch (slide around) key figure

Technical parameter

Product model: CASE VR
Product size: 118*33*42mm
Wireless protocol: Bluehooth 4 compliant
Support system: Android Android /IOS apple /pc
Support the game: Android /pc (GAMEPAD): NES/GB/SMD
PSX/GBC/N64/MAME; AndroidAPK game apple /IOS:
Icade game
Battery: 1.5V AAA Battery*2
Working current: 0.5-8mA paternity machine current: 0.5-1mA
Shutdown current: 0
Continuous game time: About 40-120 hours

Common problem:

- 1 appear remote rod is not sensitive, may be less battery power, please replace the battery
- 2 when the connection is not connected with the Bluetooth, please re open the phone to connect
- 3 the use of WIFI will affect the Bluetooth connection
- 4 some brand mobile phone keyboard settings may exist non standard Android System keyboard, the Bluetooth handle for the standard Android system developed in this Circumstances may exist after the connection is not very flexible or performance does not match the use of.Please select @ key +A, B, C, D any one key test match.
- 5 if there is a crash, please unplug the battery to re install.
- 6 suitable for games such as: robot, Miku sound angry,The PC version of warriors and so on forever.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction