


9039URF III Quick Installation Guide

Hardware Installation

1. During initial installation of the USB device, the system will automatically detect a new hardware being added, and then bring up "Add New Hardware Wizard" dialogue box. Please follow the Wizard's USB driver installation steps. Once this installation step is completed the basic functions of the USB device will work under the operating system.
2. Make sure the batteries of the keyboard are installed correctly. Please follow the polarity signs in the battery compartment.



Pairing Procedure


The wireless kit can operate out of the box immediately. If it can't work, please follow the steps below to process ID setting of the Wireless Kit.

The ID-recognition function helps to protect against interference from other RF products in the same environment. **Remember to pair ID when other RF products affect your keyboard kit.**

1. Press the pairing/connect button on right-bottom of the PC.
2. Next, press and hold the pairing/connect button on the bottom of the keyboard at least 10 seconds.
3. Receiver LED indicator flashes 3 times rapidly as indication it's paired with this keyboard.



Pairing/connect button on top of the receiver (With a LED indicator under the pairing/connect button)






Pairing/connect button on the bottom of the keyboard

Note:

- The whole procedure should be completed **within 60 seconds**.
- Make sure your PC is on and running when doing the pairing procedure.
- You don't have to pair ID again after changing batteries.

Battery Low Alarm

- There are 4 different levels for battery power indication. The battery low icon  will show in the Windows system tray when keyboard batteries are low (at Level 3 and Level 4).
- The current status of battery power will show up on the Windows system tray when moving cursor on the KeyMaestro driver icon .
- The battery low icon  will disappear when you change the batteries.

Battery Information

1. We recommend using alkaline batteries for a longer battery life.
2. Always change batteries when battery low alarm appears, otherwise the keyboard will shut down once the battery voltage is too low.
3. Don't mix different types of batteries or new and old batteries together. Always replace old batteries with new and same type batteries.
4. Remove batteries after long periods of non-use. Battery leakage or corrosion may damage the device quality and cause danger.



FCC GUIDELINES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- w Reorient or relocate the receiving antenna.
- w Increase the separation between the equipment and receiver.
- w Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- w Consult the dealer or an experienced radio/TV technician for help.
- w Use only shielded cables to connect I/O devices to this equipment.

FCC Warning: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Information to user: The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment is intended for use in the following countries EU 18 countries:

Austria, Belgium, Denmark, Finland, France, Germany, Ireland, Italy, Luxembourg, Netherlands, Spain, Sweden, United Kingdom, Portugal, Greece, Switzerland, Norway, and Iceland.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

低功率電波輻射性電機管理辦法：

第十二條：經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條：低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電信。

低功率射頻電機需忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

