
CALF SPEAKER MICROPHONE C12 User Manual







Accessories Introduction

USB charging cable Connect it to power bank, computer USB port or power adapter to charge the product.

Some devices common to Android and Apple

systems need it to be used with an adapter cable



2. Speaker volume control button Microphone volume control button

Button Introduction

- 4. Original sound cancel button
- 5. Power button / sound effect control button

Bluetooth reset button 7. 3.5mm earphone cable port 9. Audio cable port

8. USB cable port

Button Introduction

- - mode → original mode, and the factory default is the singer effect.

6. Bluetooth reset button

Button Description

The white indicator light turns on (off) as the power is

turned on (off): the red indicator light turns on when

It includes volume plus and volume minus buttons,

which controls speaker volume across eight grades.

It includes volume plus and volume minus buttons.

which can adjust the microphone's pickup volume

the microphone is charging

across eight grades.

original sound function.

2. Speaker volume control button


3. Microphone volume control button

4. Cancel the original sound button

Press and hold the button for 3 seconds to reset Bluetooth of the product.5

Bluetooth Instructions

Press the button for a short time to turn on/off the



Press and hold the button for 2 seconds to turn on, press and hold it for 3 seconds to turn off; in poweron state, click thebutton, the microphone goes into the next grade in the sequence of: original mode → super reverb mode → singer mode → pop music mode → folk or military music mode → host mode → anime mode → monster mode → electronic

the white indicator will keep being on after the

The first connection, After hearing the prompt tone indicating CALF speaker microphone has been turned on, open the Bluetooth of your phone and search fo the equipment. Then, click "CALF speaker

Bluetooth Instructions

Press and hold the power button for 2 seconds to

enable the power supply, and the white indicator will be on. When the audio cable port is not

connected. Bluetooth mode is a default for CALF

[Radio Frequency Shielding] microphone C12" for connection. When it is [Outer diameter of the capsule] successfully connected, the equipment will give a corresponding prompt tone that says "Bluetooth [Sound head type]

prompt tone is given.

. Bluetooth mode:

speaker microphone.

. Indicator description: When the Bluetooth is not connected, the white

indicator will keep blinking for 1 minute, and it will then be always on. When the Bluetooth is connected

[Frequency response] [Directionality] [Speaker power

[Product Model]

[Reverb Mode]

[Bluetooth version]

[Digital equalization

[Recording Mode]

[Battery capacity] [Charging power supply]

Technical Parameters

-- XiaoChang C12

-- EQ adjustment

interference

20Hz ~ 20kHz

Supercardioid

-Listening Wet, Recording Drv

---- Anti-cell phone / SMS

- Bluetooth 5.2

Reverb

Special instruction: To prevent secondary playback of the amplified music

for 2 seconds

Press and hold the power button for 2 seconds

4. Turn on Changba or other music player APP, then

adjust the phone or speaker to a proper volume;

to be picked up by the microphone which impairs sound

quality, the microphone pickup function may be directly

turned off by pressing and holding the volume button

microphone is successfully turned on;

3. Connect your phone through Bluetooth;

the microphone pickup function

5. Play the music and enjoy using it

the white indicator light will be on, indicating the

Turn the microphone volume to the lowest to disable

to select the appropriate sound effect 4. Open Changba or other music player APP, adjust the microphone to a proper volume, play the music and

connect to the Bluetooth:

the light on to turn on the device

Wireless Hi-Sing Mode

1. Press and hold the power button for 2 seconds until

2. Turn on the Bluetooth of the mobile phone, search for

"CALF speaker microphone C12" and click it to

- Switch on the power of two CALF microphones
- 3. Adjust the power button / sound effect control buttor
 - - 2. Press and hold the Bluetooth reset button to

disconnect the microphones and other equipment

Wireless Duet Mode





Equipment Charging

- -← 2 F
- the Bluetooth connection (only can sort out one 5. Open Changba or other karaoke apps on your phone and adjust to the proper volume:

click "CALF speaker microphone C12" to enable

Wireless Duet Mode

two microphones as the main microphone for

seconds and the work indicator will flash quickly.

4. Turn on the Bluetooth on your phone, search and

3. Press and hold the "volume+" button on either of the

When the two microphones simultaneously prompt

"duet mode on", and the main microphone prompt

"please connect your phone", the two microphones

Start singing together with friends.

are successfully paired:

Special Note:

- Wireless Duet Mode requires two CALE speaker. microphones, and does not support pairing of more
- than two devices: 2. After the two microphones are paired successfully. shutting down or resetting any one of the
- microphones will disconnect the pairing state. 3. Wireless duet mode does not support Bluetooth

If you turn on the power switch when charging, the indicator will be in white and red (in a pink light

the charging is completed.

1. In the power-on state, when the power of

- . To use the power adapter for charging, you
- should purchase a power adapter that has obtained CCC certification and meets the standard requirements. It is recommended to choose a 5V 1A power adapter for charging: 3. Do not charge the battery when the temperature
- cause the battery damaged. . You can charge your microphone by portable 4. Batteries must not be exposed to excessive heat power source, computer USB port or power adapter;
- 2. During the charging progress, the indicator will be in

3. When charging finished, the indicator will be off.

Equipment Charging

It is recommended to keep the microphone off until

microphone is less than 10%, the red indicator light flashes, indicating that the power is low. and you can hear the prompt voice of low power:

- is below 0, because the low temperature may
- such as sunlight, fire, etc.

board

Declaration

Toxic and Hazardous Substances or Elements

: Indicates that the content of the toxic and hazardous substances in the homogeneous material of the part is below the limit requirements specified in GB/T26572-2011 "Limited Requirements for Restricted Substances in Electrical and Electronic Products". X: Indicates that the content of the toxic and hazardous

substances in at least one homogeneous material of the component exceeds the limit requirements specified in GB. T26572-2011 "Limited Requirements for Restricted Substance in Electrical and Electronic Products", and there is currently no mature alternative in the industry scheme, in line with the environmental protection requirements of the EU RoHS

Note: The radio type approval CMIIT ID is on the product namenlate Copyright @ Beijing Changba Science and Technology Co., Ltd. All

CALF

CALF products are covered by an 12-month limited

Contact Us

Customer Service:

warranty from the date of its original purchase. If any problems occur. please contact our support team.

We can only provide after sales service for products that are sold by CALF or CALF authorized retailers and distributors. If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

Website: http://www.calfglobal.com

Mail Support: support.global@changba.com

Beijing Changba Science and Technology Co., Ltd http://www.changba.com

Within 7 days from the date of purchase, if CALF speaker

Warranty Regulations

flood, lightning stroke, etc.;

microphone has quality defect, the customer may choose to refund the purchase at the invoice price or replace it with a new one of the same model and specification.

Within 15 days from the date of purchase, if CALF speaker microphone has a quality defect, the customer may choose to replace it with a new one of the same model and specification: The period of warranty services (repair, replacement and refund) for CALF speaker microphone is one year. The warranty will be invalid if it is altered.

Warranty

When there is no warranty card, or the valid receipt is lost, or hewarranty period has expired;

When the damage is caused by failure to use, maintain or store the product as required by the instruction;

When the damage is caused by force majeure such as fire disaster, Means of purchase:

Warranty Card

Phone number:

Product model:

Factory number:

Date of purchase:

Customer address:

When the product model or code on the warranty card is not in

line with the product;

When the damage is caused by disassembly and repair by non-

CALF authorized service personnel;

Please understand that any product failure caused by customer's

own reason does not fall into the scope of after-sale service.

In cases mentioned above, the consumer may seek a solution

from related responsible party or choose paid service: Normal discoloration, wear or consumption generated by the use of the product are not faults included in the warranty scope

Warranty Records Record of first service

Delivery time

Fault handling

ertificate of retur

nd replacement

The date of handover

examination

Signature of the

naintenance stuff

Fault handling Certificate of return nd replacement The date of handove Signature of the Record of second service ault condition upon delivery

the following

FCC Statement:

This device complies with part 15 of the FCC rules. Operation

subject to the following two conditions: (1) this device may not

cause harmful interference, and (2) this device must accept any

approved by the party responsible for compliance could void the

interference received, including interference that may cause

This equipment has been tested and found to comply with the

limits for a Class B digital device, pursuant to part 15 of the FCC

against harmful interference in a residential installation. This

equipment generates uses and can radiate radio frequency

energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio

will not occur in a particular installation. If this equipment doe

Rules. These limits are designed to provide reasonable protection

communications. However, there is no guarantee that interference

cause harmful interference to radio or television reception, which

can be determined by turning the equipment off and on, the user

is encouraged to try to correct the interference by one or more of

undesired operation. Changes or modifications not expressly

user's authority to operate the equipment.

Regrient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from

EU Declaration of Conformity

following internet address:

http://www.calfglobal.com

BY AN INCORRECT TYPE

TO THE INSTRUCTIONS.

volume levels for long periods.

RISK OF EXPLOSION IF BATTERY IS REPLACED

DISPOSE OF USED BATTERIES ACCORDING

CAUTION:

Hereby, Beijing Changba Technology Co., Ltd. declares that the

radio equipment type is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the

To prevent possible hearing damage, do not listen at high

that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help

condition without restriction.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure

The normal working temperature of the product is 0-40°C

- Please use USB2.0 and below ports for power
- warning signal.

defeat a safeguard.

Safety information:

- 6. Don't charge the battery under the following conditions: A:in direct sunlight, temperatures below 5°C B:The maximum battery surface temperatures 52°C

UC CC Environmentally friendly disposal, Old electrical

appliances must not be disposed of together with

the residual waste, but have to be disposed of

separately The disposal at the communal collecting

point via private persons is for free. The owner of old

points With this little personal effort, you contribute to

recycle valuable raw materials and the treatment of

appliances is responsible to bring the appliances

to these collecting points or to similar collection

- 7. If you listen at a high volume for a long time, there will be

toxic substances.

transportation and -20-60°C in storage.

leakage of flammable liquid or gas.

1. The temperature range of the battery is -20-60°C in

Don't leave a battery in an extremely high temperature

Don't low than 86kPa air pressure that may result in an

explosion or the leakage of flammable liquid or gas.

5. Don't replace the battery pack with an incorrect type that can

2. Don't put the battery into fire or a hot oven, or mechancially

crushing or cutting a battery, that can result in an explosion

surrounding environment that can result in an explosion or the