


产品介绍




- ① 音量+
- ② 音量-
- ③ 亮度+
- ④ 亮度-
- ⑤ 扬声器
- ⑥ Type-C线缆
- ⑦ 屈光度调节旋钮
- ⑧ 鼻托
- ⑨ 接近传感器
- ⑩ 摄像头
- ⑪ 光学模组

使用方法

本产品是即插即用式产品，眼镜不含电池。通过 Type-C 线缆连接视频输出的设备，达到使用效果。

佩戴方法：
建议镜腿完全打开后从头上往下佩戴，并将线置于耳后，可以使用夹夹将手机数据线夹在衣领或其他适当位置从而提供更好的佩戴体验。

- 镜腿向外打开，请勿强行弯折镜腿。
- 镜腿完全打开后佩戴，以免夹手或头发。



* Type-C接口视频输出的设备：华为 Mate 系列、P 系列、荣耀 RZ、三星手机、Macbook、联想 Legion、联想 ThinkPad、P80X(自研)、华硕迷你主机 (Type-C 带 DP 输出) 等。

按键操作

部件名	功能说明
音量+	短按可提高喇叭音量
音量-	短按可降低喇叭音量
亮度+	短按可提高屏幕亮度
亮度-	短按可降低屏幕亮度
	长按可切换显示2D/3D模式 (3D模式需佩戴左右各一只偏光镜)




休眠模式

休眠模式会使 PGLASS 的屏幕变灰，工作功耗降低。
PGLASS 休眠模式：摘下眼镜后静置 20s，PGLASS 会自动进入休眠模式（再次戴上眼镜后可自动唤醒）。

屈光度调节

本产品支持 $-5D \sim 0D$ 的屈光度调节，无需额外佩戴近视眼镜。

1. 打开屈光度调节旋钮盖子。
 2. 将包装箱内的调节螺钉插入旋钮中。
 3. 旋转螺丝调节并调整至合适的刻度，顺时针旋转到 0D，逆时针旋转到 $-5D$ 。
- * 屈光度和近视度数的换算关系： $-1D=100$ 度 $-2D=200$ 度 以此类推。



注意事项

- 请勿拉扯 USB 线的方式摘下产品。
- 请勿将产品放在包裹内或置于任何外来物上，以免损坏产品可承受重量极限。
- 建议经常保持本产品清洁及干燥。
- 请勿打开产品外壳或自行拆卸本产品。


- 请勿用力挤压或震动本产品，请勿置于尘土过多、温度或湿度变化较大环境中。
- 不要让本产品承受强烈的冲击或震动。
- 请勿将本产品放于温度过高或过低的环境。
- 请勿将本产品长时间暴露在阳光下直接照射的环境下。
- 请勿用腐蚀性清洁剂清洗本产品。
- 使用本产品观看影像时，若一边行走，请注意周围环境。
- 若您对光线敏感或感到恶心，请勿使用本产品，否则已存在的症状可能会加重。
- 使用本产品前，请先消除身上的静电，方避免触电；可用小金属物件（如钥匙）、棉抹布等产品型号标识不符，或保修卡被涂改；
- 擅自拆卸、维修产品，或浸水、摔坏产品；
- 不可抗力造成的损坏。

产品有害物质说明

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
线材	*	○	○	○	○	○
本体	*	○	○	○	○	○

有害物质 SVT / T 11364 的限值控制
* 表示含有有害物质且含量超过材料中的含量或在 GB/T 26572 规定的限值以上。
○ 表示有害物质含量少于限值的第一组材料中的含量或在 GB/T 26572 规定的限值以下。且符合 RoHS 指令或限制材料的要求。符合 RoHS 指令的部件除外。

Product Description




- ① Volume+
- ② Volume-
- ③ Brightness+
- ④ Brightness-
- ⑤ Speaker
- ⑥ Type-C cable
- ⑦ Diopter adjustment knob
- ⑧ Nasal button
- ⑨ Distance sensor
- ⑩ Ink lens
- ⑪ Optical module

Instructions

This product is a plug-and-play product, and the glasses do not contain batteries. Connect devices with video output through Type-C cables to achieve the effect of screen projection.

Wearing method:
It is recommended to wear the temples from the top of the head when the temples are fully opened and place the cord behind the ears. The cable clip can be used to clamp the mobile phone data cable to the collar or other appropriate position to provide a better wearing experience.

- Open the temples outward, please do not bend the temples forcibly.
- Wear the temples after they are fully opened to avoid pinching hands or hair during the process.



* Devices with Type-C interface with video output: HUAWEI Mate series, P series, SMARTV AN R2, SAM-SUNG mobile phones, Macbook, LENOVO Legion, LENOVO ThinkPad, P80X (self-developed), ASUS mini host (Type-C with DP output), etc.

Key operation

Part name	Function Description
Volume+	Short press to increase speaker volume
Volume-	Short press to decrease speaker volume
Brightness+	Short press to increase screen brightness
Brightness-	Short press to decrease screen brightness
	Long press to switch display 2D/3D mode (3D mode needs to wear 3D video glasses with left and right eye lenses)




Sleep mode

Sleep mode will turn off the screen of PGLASS and reduce working power.
PGLASS sleep mode: After taking off the glasses and letting it stand for 20s, PGLASS will automatically enter the sleep mode (you can automatically wake up after putting on the glasses again).

Diopter adjustment

This product supports diopter adjustment from $-5D$ to $0D$, no need to wear additional glasses for myopia.

1. Open the lid of the diopter adjustment knob.
 2. Insert the screw adjustment rod included in the package into the knob.
 3. Turn the screw adjustment rod to adjust to the appropriate scale.
- The clockwise knob is 0D, the counterclockwise knob is $-5D$.
- * The conversion relationship between diopter and myopia: $-1D=100$ degrees, $-2D=200$ degrees and so on.



Precautions

- Do not unplug the USB cable by pulling it.
- Do not put this product in a bag or expose it to any foreign objects, so as not to exceed the load bearing limit of this product.
- Recommended to keep it clean and dry.

- Do not open the product shell or disassemble the product by yourself.
- Do not squeeze or shake the product forcibly, and do not place it in an environment with excessive dust and large temperature or humidity changes.
- Do not subject this product to strong shock or vibration.
- Do not place this product in an environment where the temperature is too high or low.
- Do not use this product to direct sunlight for a long time.
- Do not wipe the product with corrosive cleaning agents.
- When using this product to watch images, please pay attention to the surrounding environment if you are walking while walking.
- If you are sensitive to light or feel nauseous, do not use this product, otherwise the existing symptoms may be exacerbated.
- Before using this product, please eliminate static electricity from your body. To avoid static electricity, small metal devices (such as keys), cotton wipes, etc., first touch the door, doorknob, faucet, etc. to eliminate static electricity, and then touch it with your hands.

Product hazardous substance description

Part name	Harmful Materials					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Host	*	○	○	○	○	○
Cable	*	○	○	○	○	○

保修说明

一、消费者自购买之日起 1 年内，本产品出现性能故障的情况，经由售后服务中心检测确定，可免费享受维修服务。

二、有下列情况之一者，消费者不能享受保修权益，将实行合理的收费维修。

1. 用户使用不当造成损坏或者超过保修期的产品需维修；
2. 无保修卡及有效发票，但能够证明产品在保修期内的除外；
3. 保修卡与产品型号标识不符，或保修卡被涂改；
4. 擅自拆卸、维修产品，或浸水、摔坏产品；
5. 不可抗力造成的损坏。

This form is compiled in accordance with SJ/T 11364-0, indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement of GB/T 26572. * indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirement of GB/T 26572, and there is no mature alternative in the industry, which meets the environmental protection requirements of the EU RoHS directive.

Warranty description

I. Consumers, if the product has performance failures within 1 year from the date of purchase, are confirmed by the after-sales service center, and they can enjoy free repair services.

II. In one of the following situations, consumers cannot enjoy the warranty rights, and reasonable maintenance fees will be implemented.

1. Products that are damaged due to improper use by the user or exceed the warranty period shall be repaired.
2. No warranty card and valid invoice, except those that can prove that the product is within the warranty period;
3. The warranty card does not match the product model identification, or the warranty card is altered;
4. Unauthorized disassembly and repair of the product, or soaking or breaking the product;
5. Damage caused by force majeure.

FCC Statement:

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID:2AXW3-HOARL1