

QODE

MOBILE WIRELESS KEYBOARD
CLAVIER NOMADE SANS FIL
TECLADO INALÁMBRICO MÓVIL



1

CHARGE BEFORE FIRST USE
CHARGER AVANT UTILISATION
CÁRGUELO ANTES DE USARLO



Artwork on this
side of the
green line

KEYBOARD ON/OFF
ALLUMER/ÉTEINDRE LE CLAVIER
ENCENDIDO/APAGADO DEL TECLADO



SELECT DEVICE 1
SÉLECTIONNER L'APPAREIL 1
SELECCIONE DISPOSITIVO 1

SELECT DEVICE 2
SÉLECTIONNER L'APPAREIL 2
SELECCIONE DISPOSITIVO 2



? www.belkin.com/support



BLUE TOOTH® PAIRING
COUPLAGE BLUETOOTH®
ENLACE BLUETOOTH®

ADD SECOND DEVICE
AJOUTER UN DEUXIÈME APPAREIL
AGREGUE EL SEGUNDO DISPOSITIVO



1



2



3



BELKIN MOBILE WIRELESS KEYBOARD
CLAVIER NOMADE SANS FIL BELKIN
TECLADO INALÁMBRICO MÓVIL DE BELKIN