

Welcome to WeMo. Bienvenue à WeMo.

Additional Information:

Caution: Make sure device is off before plugging in any electronics.

Operating Condition: This device is designed for operation between 32 to 104°F (0 to 40° C) and at or below an altitude of 6,562 ft (2,000 m).

Care: Unplug device prior to cleaning. Use dry cloth on exterior of the device. To avoid shock hazard and/or damage to device, DO NOT use any liquid solution.

Micro-USB Output: 5VDC, 0.5A.

F7C0291c • 88300105146 Rev. A10

belkin.com/WeMo




WeMo INSIGHT SWITCH








Quick Install Guide


Guide d'Installation Rapide

- 

1  →  Plug in.
Branchez.
- 

2  or  →  Download & Install latest WeMo App.
Téléchargez et installez l'application WeMo à jour.
- 

3  or  →  In Settings, select Wi-Fi.
Connect to WeMo network.
Dans Réglages, sélectionnez Wi-Fi.
Connectez-vous au réseau WeMo.
- 

4  →  Launch the WeMo App to complete the setup.
Lancez l'application WeMo pour terminer la configuration.