


belkin.com/WeMo

How to connect a device to WeMo Maker. Comment connecter un appareil à WeMo Maker. Ein Gerät an den WeMo Maker anschließen.

Make sure the device is disconnected from any power sources. Assurez-vous que l'appareil est débranché de toute source d'alimentation. Stellen Sie sicher, dass das Gerät von allen anderen Stromquellen getrennt ist.


Connect relay leads. Branchez les fils du relais. Schließen Sie die Relaisleitungen an.

Note: Do not connect any device with voltage higher than 24VDC or 24VAC. Remarque: ne branchez pas d'appareil dont la tension dépasse 24 V c.a. ou 24 V c.c. Hinweis: Schließen Sie kein Gerät mit einer Spannung von mehr als 24 V Wechselspannung oder 24 V Gleichspannung an.



Connect sensor leads. Branchez les fils du détecteur. Schließen Sie die Sensorleitungen an.

Note: 5VDC at 100mA max. TTL Logic: Normally High, Triggered Low. Remarque: 5 VCC à 100 mA en sortie, max. TTL Logic: normalement haut, déclenché bas. Hinweis: 5 V Gleichspannung/100 mA Ausgangsstrom, max. TTL-Logik: Normally High, Triggered Low.



Reconnect device connected to the Maker to its power source. Re-branchez l'appareil connecté au Maker à sa source d'alimentation. Schließen Sie das Gerät, das an den Maker angeschlossen ist, wieder an die entsprechenden Stromquellen an.

Translations for Dutch, Spanish, Italian, Portuguese, Russian, and Afrikaans. Each section includes the language name and a list of instructions and notes.

Translations for Swedish, Czech, Polish, Macedonian, and Persian. Each section includes the language name and a list of instructions and notes.

Translations for Spanish, Italian, Portuguese, Russian, and Polish. Each section includes the language name and a list of instructions and notes.

