

Start  
Here

TuneCast® Universal  
Quick Start Guide

**BELKIN®**

**BELKIN®**  
www.belkin.com


**Belkin Tech Support**  
US: <http://www.belkin.com/support>  
UK: <http://www.belkin.com/uk/support>  
Australia: <http://www.belkin.com/au/support>  
New Zealand: <http://www.belkin.com/au/support>  
Singapore: 1800 622 1130  
Europe: <http://www.belkin.com/uk/support>

© 2010 Belkin International, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.


8820-00576

F8M066-P


#### Car Installation




1. Plug adapter into car's cigarette-lighter outlet.




2. Plug headphone plug into media player's audio jack.



3. Find a frequency without a station on it. A good frequency will be between other stations, with a lot of static. To identify the best available frequencies in your area, visit [www.belkin.com/mybestfm](http://www.belkin.com/mybestfm).




4. Match station using up and down buttons.




5. Play music.

#### Storing Frequency (optional)



1. Press and hold the MI or MII button for two seconds to store station. When the MI or MII icon blinks, release the button.



2. To recall a stored station, simply press the same MI or MII button.