

BELKIN®www.belkin.com**Belkin Tech Support**

US: 800-223-5546, ext. 2263
310-898-1100, ext. 2263
UK: 0845 607 77 87
Australia: 1800 235 546
New Zealand: 0800 235 546
Singapore: 65 64857620
Europe: www.belkin.com/support

Belkin International, Inc.

501 West Walnut Street
Los Angeles, CA 90220, USA
310-898-1100
310-898-1111 fax

Belkin Ltd.

Express Business Park, Shipton Way
Rushden, NN10 6GL, United Kingdom
+44 (0) 1933 35 2000
+44 (0) 1933 31 2000 fax

Belkin B.V.

Boeing Avenue 333
1119 PH Schiphol-Rijk, The Netherlands
+31 (0) 20 654 7300
+31 (0) 20 654 7349 fax

Belkin Ltd.

4 Pioneer Avenue
Tuggerah Business Park
Tuggerah, NSW 2259, Australia
+61 (0) 2 4350 4600
+61 (0) 2 4350 4700 fax

Audio

Setup Instructions

1. Open the battery cover on your TuneCast II Mobile FM Transmitter. Install the included AAA batteries and replace the battery cover.
2. Plug the 3.5mm connector into your iPod player or other portable music device.
3. The AUTO ON feature will power on the FM Transmitter when the unit detects an input signal. Your FM Transmitter's "AUTO ON/OFF" feature uses your audio player's volume level to automatically power on and off. For best results, keep your player set at a medium volume level. NOTE: Setting your device volume very low may cause the FM Transmitter to turn off, even if the audio player is on. You can also press and hold both ▲ and ▼ buttons simultaneously for two seconds to turn on the unit. To turn off the unit, press and hold both buttons simultaneously again for two seconds.

Note: To conserve power, the FM Transmitter will automatically turn off when there is no input audio signal for 60 seconds +/- 10 seconds.

4. Tune your car or home stereo frequency to a channel with a weak broadcast signal. The ideal channel is one that is not broadcasting a radio program, or is doing so weakly. To identify the best available frequencies in your area, visit www.belkin.com/mybestfm.
5. Press the ▲ or ▼ button on the FM Transmitter to select the transmission frequency chosen in step 4, on your car or home stereo, for broadcast. Press and hold either button for fast-forward or backward tuning.
6. To memorize a specific frequency (four stations maximum) for easy selection:
 - a. Select the desired frequency using the ▲ or ▼ buttons.
 - b. Press and hold "mem" (memory) button for two seconds. The icon M1 will blink; then release it.
 - c. Press the ▲ or ▼ button to select one of the memory slots M1, M2, M3 or M4 for storage. The active memory slot icon will blink.
 - d. Press the "mem" button again to store the frequency and return to normal operation mode.
 - e. In operation mode, pressing the "mem" button will toggle among the four memory slots to retrieve the memorized frequency.

NOTE: When there is no key press for a duration of 10 seconds, the FM Transmitter will return from memory mode to operation mode.

7. Adjust the volume on your MP3 player or other audio source to a medium level.
8. Adjust the volume of your FM radio to the desired listening level.*

Mobile Power Cord Included for Extra Power

Connect one end of the cable into the DC port located on the bottom of the FM Transmitter. Plug the other end of the cable into the cigarette lighter port in your car

Once the cable is plugged into the FM Transmitter, the unit will shut off. You will need to manually turn on the unit.

NOTE: This cable will NOT charge the TuneCast II Mobile FM Transmitter. It only provides power in order to preserve battery life while in the car.

For best results:

- Try to keep the FM Transmitter close to the antenna of your FM radio. While the FM Transmitter often works at distances of 30 feet or more, a distance of 10 feet or less will minimize interference and provide the strongest signal.

- Keep fresh batteries in the FM Transmitter. When the batteries become very low, the transmission strength will weaken.

*Due to characteristics of FM transmission, you will experience better sound quality by adjusting the volume on your home or car stereo when necessary, and by leaving your iPod or other portable music player volume at a medium level.

Information

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Belkin International, Inc., is not responsible for any interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment.

IC

This Class B digital apparatus complies with Canada RSS-210.

Belkin International, Inc., Limited 3-Year Product Warranty

What this warranty covers.

Belkin International, Inc. ("Belkin") warrants to the original purchaser of this Belkin product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Belkin warrants the Belkin product for three years.

What will we do to correct problems?

Product Warranty.

Belkin will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty?

All above warranties are null and void if the Belkin product is not provided to Belkin for inspection upon Belkin's request at the sole expense of the purchaser, or if Belkin determines that the Belkin product has been improperly installed, altered in any way, or tampered with. The Belkin Product Warranty does not protect against acts of God such as flood, lightning, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

How to get service.

To get service for your Belkin product you must take the following steps:

Compton, CA 90220, Attn: Customer Service, or call (800)-223-5546, within 15 days of the Occurrence.

Be prepared to provide the following information:

- a. The part number of the Belkin product.
- b. Where you purchased the product.

c. When you purchased the product.

d. Copy of original receipt.

2. Your Belkin Customer Service Representative will then instruct you on how to forward your receipt and Belkin product and how to proceed with your claim.

Belkin reserves the right to review the damaged Belkin product. All costs of shipping the Belkin product to Belkin for inspection shall be borne solely by the purchaser. If Belkin determines, in its sole discretion, that it is impractical to ship the damaged equipment to Belkin, Belkin may designate, in its sole discretion, an equipment repair facility to inspect and estimate the cost to repair such equipment. The cost, if any, of shipping the equipment to and from such repair facility and of such estimate shall be borne solely by the purchaser. Damaged equipment must remain available for inspection until the claim is finalized. Whenever claims are settled, Belkin reserves the right to be subrogated under any existing insurance policies the purchaser may have.

How state law relates to the warranty.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF BELKIN. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR, EXCEPT AS REQUIRED BY LAW, IMPLIED, INCLUDING THE IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL BELKIN BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL OR MULTIPLE DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY BELKIN PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental, consequential, or other damages, so the above limitations may not apply to you.