DIE LAYOUT

200gsm SBS Coated 2-sides

316.01
[12+7/16]

Front
135.7
[5+11/32]

belkin INNOVATION CREATIVE GROUP   295800

wemo

Stage
Smart Scene Controller

Setup Guide

Works with
Apple HomeKit

What's in the box

Cradle and faceplate
(for optional wall-mounting)

Controller

CR2032 battery
(install + side up)

What you'll need

To control Wemo Stage, you'll need an iPhone or iPad and a HomePod, Apple TV, or iPad set up as a home hub. Make sure your devices have the latest software and operating system updates.

Works with
Apple HomeKit

• How to set up a home hub: **support.apple.com/en-us/HT207057**
• HomeKit-compatible devices: **apple.com/ios/home/accessories**

Quick setup

Use the Apple Home app to:

1
Add Wemo Stage as an accessory

2
Create scenes that control your smart devices

3
Assign scenes to buttons on Wemo Stage

1 Adding to Apple Home

1. Install battery into the controller with the positive side facing up

2. Wait for the controller to enter setup mode (light blinks yellow and green)

3. Launch the Apple Home app

4. Hold your phone near the controller and follow the prompts when they appear

For iPhone X or below, you'll need to add (+) Wemo Stage as an accessory in the Home app.

2 Creating scenes

Scenes allow you to automatically control single or multiple smart devices with the touch of a button.

Creating scenes in the Home app

1. Add a scene (+) from the Home app

2. Choose a scene name or create a custom name

3. Add accessories (smart devices) to the scene

4. Assign actions to these accessories (example: turn on/off a light)

3 Assigning scenes

Your Wemo Stage can trigger up to 6 scenes. Each button can be assigned a scene for a short press or long press.

Assigning scenes to buttons in the Home app

1. Tap your Wemo Stage from the list of accessories

2. Decide which button you want to assign the scene to, then choose short press or long press

3. Assign your scenes

316.01
[12+7/16]

Back
135.7
[5+11/32]

Example scenes

Bedtime: Place Wemo Stage on your bedside table. Before sleeping, press to turn off all your home lights and turn on your security system.

Entertainment: Place Wemo Stage on your coffee table. When ready to party, press to dim the lights and turn on the music or TV.

Guest room on/off: Give guests control of smart lights, fans, blinds, and other devices in their room.

Status light

● **Off**
Working normally; press any button to show status

● **Green**
A scene has been triggered or setup has just completed

● **Yellow**
Low-battery level

● **Blinking Yellow**
An error has occurred

● **Yellow and Green (Alternating)**
Ready for setup

Installing or changing battery

Remove the cover on the back of the controller

Install CR2032 battery in the compartment positive (+) side up

Replace back cover

Troubleshooting

Restart
Having setup or control issues? Remove and re-insert the battery to restart.

Factory restore
If a restart doesn't help, factory restore your controller.

1. Press and hold Restore button for 5 seconds

2. Wait for the light to blink yellow, then green and release

3. Re-add your Wemo Stage to Apple Home and reassign scenes to buttons

Restore button

CR2032

Wall-mounting

Thoroughly clean wall surface. Remove the paper from the adhesive strips on the back of the cradle.

Attach the cradle to the wall

Snap the faceplate onto the mounted cradle

A magnet in the controller holds it to the wall mount

Have questions?

HomeKit Setup Code

Keep this HomeKit Code handy in case you need it for setup later

Wemo Stage Support

Visit **wemo.com/stage** for support with your Wemo Stage or call us at **1-844-745-WEMO**.

For warranty information, go to **wemo.com/warranty**

8820-03033 Rev A00

Business Unit: Belkin

Program Manager:

Packaging Engineer: Caleb Nelson

Retail Outside Dimension (Including Hang Tab)
L x W x D (in):
L x W x D (mm):

DIE/MATERIAL SPECS:

Material: Please refer to drawing

Blank Size (in): 316.01 x 308.70
Blank Size (mm): 316.01 x 308.70

This dieline works for following skus (if any):

WSC010

Unit: IN/MM

Side Shown: PRINT SIDE

Flute/Grain: horizontal

Tolerance: +/- 1/32" - 0.8mm

Drawing Scale 1:1

RELEASE DATE: 12/15/2020

DIELINE:
Caleb Nelson

PRINT SPECS:

Color Plates:
C M Y K
PMS 7488

Finish:
OVERALL PP COAT

Notes:
ALL TEXT AND GRAPHIC ELEMENTS COLOR: CMYK, PMS 7488C

DO NOT PRINT
DIE LINES, PRINTERS NOTES