


Chapter 0: Quick Installation for Win31 and Win95 (for advanced user)

About StarMedia:

The StarMedia Display Utility is an integrated set of utilities which you can use to configure and adjust your graphics display card for optimal usage under Microsoft Windows 3.x, Windows for Workgroup and Windows 95. The StarMedia features monitor Plug & Play support, on-the-fly resolution switching, on-the-fly refresh rate changing, monitor centering, custom cursor color, multi-media playback programs and support localized language.



Desktop: Configures the desktop size, color-depth, font size and refresh rates. You can change the desktop settings without restarting Windows.

Monitor: Detects your monitor and displays the resolutions and refresh rates which your monitor supports. The monitor centering facility let you adjust the screen position.


Cursor: Lets you choose your favorite cursor color.

DPMS: Configures your monitor for power-saving purpose.

Chapter 1: StarMedia Display Utility

StarMedia Introduction

The StarMedia Display Utility, is an integrated set of utilities you can use to configure and adjust your graphics display card for optimal usage under Microsoft Windows 3.x, Windows for Workgroup and Windows 95. The StarMedia features monitor Plug & Play support, on-the-fly resolution switching, on-the-fly refresh rate changing, monitor centering, custom cursor color and a variety of productivity enhancing features.



StarMedia Operational Guide

Desktop

The Desktop dialog, (for a S3 VIRGE VGA card installed under Windows 95 platform, if a different card is installed, e.g. an ET16000 card, then the window will be displayed as ET16000 Setup, but the contents on the window are almost the same.) allows you to configure your desktop size, color depth, font size and refresh rate.

MultiMedia

The MultiMedia page shows 3 buttons which will launch Microsoft(TM) CD player, Media player and Active Movie respectively. Sometimes some of the buttons will be grayed when the specific program(s) is not installed on your computer.

CD Player:

CD music playback.

This control lets you play audio compact disc.

It has functions such as playing a CD, pausing and resuming a CD, playing tracks in random order & playing multiple discs.


Media Player:

Video and audio files playback.

This control lets you play audio, video and animation files. It has functions such as playing a multimedia file, rewinding & fast-forwarding a multimedia file.

Active Movie:

Move and video and audio files playback. This control lets you play a MPEG file, a video CD(DAT file) and Quick Time(QT file) and movie file(MOV file).



Options (For S3 VGA cards on Windows 3.x only)

This window provides you the flexibility to optimize the graphic and video performance or to void some compatibility issues by some hardware dependent parameters. For the best performance, you need to check most of the check boxes. However, in case you encounter some compatibility problems, you need to disable one or more parameters.

Info. (Information)

This window shows the resolution, color-depth, font size and refresh rate for current desktop setting, the graphic chipset, the versions of the BIOS and Windows driver, and also the total video memory size on your graphic card.