

CAR MULTIMEDIA Jamaica 970



Enjoy it.

Operating instructions



- 1 Microphone
- 2 Reset Hole
- 3 [**小**] Button Switch on/off device
- 4 [合] button Call up main menu

- 5 [←] button Returns to previous screen
- 6/7 [₄+]/[₄-] Button Adjust volume
- 8 Touchscreen user interface

Safety notes	4
Symbols used	4
Road safety	4
General safety notes	4
Declaration of conformity	4
Cleaning notes	4
Disposal notes	4
Software update	4
Placing the device in operation	5
Switching on/off	
Volume	
Operation	5
Touchscreen	
Main Menu	
Starting radio playback	
USB data carrier	

Safety notes

The car sound system was manufactured according to the state of the art and established safety guidelines. Even so, dangers may occur if you do not observe the safety notes in these instructions.

These instructions are intended to familiarise you with the most important functions. Detailed information can be found on the Internet under www.blaupunkt.com.

- Read these instructions carefully and completely before using the car sound system.
- Keep the instructions at a location so that they are always accessible to all users.
- Always pass on the car sound system to third parties together with these instructions.

In addition, observe the instructions of the devices used in conjunction with this car sound system.

Symbols used



These instructions employ the following symbols:

DANGER!



Warns about injuries



DANGER!

Warns about high volume

The CE mark confirms the compliance with EU directives.

- Identifies a sequencing step
- Identifies a listing

Road safety

Observe the following notes about road safety:

- Use your device in such a way that you can always safely control your vehicle. In case of doubt, stop at a suitable location and operate your device while the vehicle is standing. As the driver, you may not use the applications that will distract you from traffic (depending on the scope of functions of the device, e.g. viewing videos, entering a destination).
- Follow the driving recommendations during the route guidance only if you are not

- violating any traffic regulations! Traffic signs and traffic regulations have always priority over driving recommendations.
- Always listen at a moderate volume to protect your hearing and to be able to hear acoustic warning signals (e.g. police sirens). During mute phases (e.g. when changing the audio source), changing the volume is not audible. Do not increase the volume during this mute phase.

General safety notes

Observe the following note to protect yourself against injuries:

Do not modify or open the device.

Use as directed

This car sound system is intended for installation and operation in a vehicle with 12 V vehicle system voltage. Observe the output limits of the device. Repairs and installation, if necessary, should be performed by a specialist.

Declaration of conformity

The Blaupunkt Technology GmbH declares that the device complies with the basic requirements and the other relevant regulations of the directive 1999/5/EC.

The declaration of conformity can be found on the Internet under www.blaupunkt.com.

Cleaning notes

Solvents, cleaning and scouring agents as well as dashboard spray and plastics care product may contain ingredients that will damage the surface of the car sound system.

Use only a dry or slightly moistened cloth for cleaning the car sound system.

Disposal notes



Do not dispose of your old unit in the household trash!

Use the return and collection systems available to dispose of the old device, the remote control and exhausted batteries.

Software update

Under www.blaupunkt.com, you will find the latest software for your device, including instructions for the software update.

Software updates are located at:

http://www.blaupunkt.com/en/servicesupport/caraudio/downloads/updates/

Placing the device in operation Switching on/off

Switching on/off with the rotary/pushbutton

- ► Press 🖰 button to turn on the unit.
- When on, press button to turn off the unit.

Switching on/off via vehicle ignition

If the car sound system is connected with the vehicle ignition and it was switched off with the \circ button, it is switched on or off with the ignition.

Volume

Adjusting the volume

You can adjust the volume in steps from 0 (off) to 40 (maximum).

Press [♣+]/[♣-] to change the volume.

Operation

Touchscreen

Important note:

Do not use any pointed or hard objects, such as ball point pens or fountain pens, to operate the touchscreen.

The device features a capacitive touchscreen that provides a remote control and device buttons (see the section "Controls" at the beginning of these instructions) and allows operating the device.

Tapping

To activate a control, e.g. a button, a slight touching of the display surface is sufficient. You do not have to exert any pressure on the display surface.

Short tap:

A short tap on the display surface is sufficient for activating most of the controls.

Long tap:

Some functions require a long tap. Rest your fingertip on the display surface for approximately 1 second.

Swiping/scrolling

Some functions require swiping across the display surface, e.g.

- scrolling in lists,
- adjusting sliders.

Tap on the display surface and rest your finger on the surface. Next, move your finger over the surface.

Zooming

When displaying maps (navigation) and images, you can enlarge or reduce the view (zoom):

Tap on the area of the map display with two fingers and rest your fingers on the surface. Move your two fingers closer together (zoom out/reduce) or further apart (zoom in/enlarge).

Main Menu

Press the \(^\) button to enter main source menu. Touch the icons to access corresponding modes.

Starting radio playback

In the main menu, press the [Radio] button. The radio playback menu is displayed.

USB data carrier

This device features two USB ports:

- USB1 and USB2 port at the rear of the device.

 Notes:
 - Use the USB1 ports for USB data carriers with media contents.
 - Use the USB2 port for the supplied WLAN USB stick.

Connecting a USB data carrier

Insert the USB data carrier in the USB socket. The device automatically switches to USB mode. The data are read, the playback starts with the first media file recognized by the device.

Removing a USB data carrier

- Turn off the car sound system.
- Disconnect the USB data carrier.

FCC Statement

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 centimeters between the radiator and your body.

