

User Manual
Model: iTouch 3360
Brand: iTouch

PLEASE BE SURE TO READ THIS INSTRUCTION MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING YOUR iTOUCH WATCH.

Thank you for choosing the iTOUCHSmartWatch. Please read the manual before you begin using your iTOUCH. This manual will help you to understand the full functionality and simple operation of your device. The main function of this SmartWatch is as a notifier for your email, text messages and social media apps. It can synchronize your phonebook and offers a variety of practical services to make work and leisure activities that much more enjoyable.



iTOUCH Configuration:

- LED: Bright LED backlit screen
- Power/HOME key: hold down to power device on or off. Press once to return to the home interface and to activate LED backlight.
- Back: Tap once to move back to previous menu.
- Dial/Keypad: Tap to bring up dial pad while in standby.
- Ok/Answer: Tap to bring up the menu while in standby, confirm key while in the main menu, and answer key when receiving a call.
- Microphone
- Micro USB plug: for charging your device using the included micro USB cable.
- Speaker
- Battery: Rated Voltage: 3.7V
capacity :230mAh

Getting Started:

- Turn on your iTOUCH watch by pressing the Power button.
- The language option screen will appear. Select your preferred language.
- Connect iTOUCH to smart phone by Bluetooth using the following instructions:

iPhone™:

- Begin by downloading and installing the iTOUCH SmartWatch app from the App store.
- Activate Bluetooth on your phone. Go to your Settings menu>>Bluetooth>> and switch Bluetooth on (if not already on).
- Once you have confirmed that Bluetooth is on, the iTOUCH should appear in your phone's Bluetooth Devices list as iTouch3360.
- On your iTOUCH watch, select the Bluetooth icon and then select SearchBT.
- The name of your phone will appear in the device list on your iTOUCH.
- Press on your phone's name in the list to select it. The iTOUCH will show "Pairing".
- On your phone, a dialog box will appear requesting permission for iTOUCH to pair. Select "Pair".
- A blue BT icon should now appear on the top left corner of your iTOUCH.
- On your phone, open the iTOUCH app.
- On app home screen, there is an orange Bluetooth logo on the bottom right-hand side. Press on this orange icon.
- The app's search screen will open. Press start to begin searching for devices.
- The iTOUCH 3360 will appear in the device list. Press on iTouch360 to pair with app.
- A dialog box will appear requesting permission for iTOUCH to pair. Select "Pair".
- The iTOUCH will automatically open the Notifier screen.
- Press the "Back" button on the bottom right of your watch face to return to the iTOUCH home screen.
- The Bluetooth logo in the upper right-hand corner of the iTOUCH home screen should be half blue and half green, confirming that your iTOUCH is now fully connected.

ANDROID™:

- Begin by downloading and installing the iTOUCHSmartWatch app from the Google Play store.
- In your phone settings, activate Bluetooth and check the box to allow your phone to be visible to other devices.
- On your iTOUCH watch, select the Bluetooth icon and then select SearchBT.
- The name of your phone will appear in the device list on your iTOUCH.
- Press on your phone's name in the list to select it. The iTOUCH will show "Pairing".
- On your phone, a dialog box will appear requesting permission for iTOUCH to pair. Select "Pair".
- A blue BT icon should now appear on the top left corner of your iTOUCH.

- On your phone, open the iTOUCH app.
- On app home screen, there is an orange Bluetooth logo on the bottom right-hand side. Press on this orange icon.
- The app's search screen will open. Press start to begin searching for devices.
- The iTOUCH 3360 will appear in the device list. Press on iTouch360 to pair with app.
- A dialog box will appear requesting permission for iTOUCH to pair. Select "Pair".
- The iTOUCH will automatically open the Notifier screen.
- Press the "Back" button on the bottom right of your watch face to return to the iTOUCH home screen.
- The Bluetooth logo in the upper right-hand corner of the iTOUCH home screen should be half blue and half green, confirming that your iTOUCH is now fully connected.

- **Functions requiring iTOUCHSmartwatch app**

ANDROID: Camera Remote, Music Remote, Find Phone, SMS, Mail, and Social Media Notifications, Pedometer/Sleep Monitor Sync, Weather, Lost Alert, and Voice Assist

iOS: Camera Remote, Music Remote, Find Phone, SMS, Mail, and Social Media Notifications (only supports notification, cannot reply to texts or mail), Pedometer/Sleep Monitor Sync, Weather, Lost Alert, and Voice Assist.

iTOUCH Watch Menu Functions and Instructions

- **Bluetooth:**

Search BT: search and pair with other Bluetooth enabled devices.

- **Contacts:** When the iTOUCH is fully connected with the smart phone (half-blue, half-green Bluetooth icon), the contacts stored on your phone are visible here and can be synced when updated (can display up to 1,000 contacts)

- **Messaging:** You must have the iTOUCHSmartwatch application installed and be fully connected to use this function. This menu will not be active for iOS, as all messages for iOS are shown under the Notifier menu.

- **Phone Dialer:** When the iTOUCH and your phone are connected, you can pull up the dial pad to make phone calls from your iTOUCH.

- **Call Logs:** Opening this function will show all calls. Green Arrow – incoming calls, Orange Arrow – outgoing calls, Blue Question Mark – missed calls.

- **Music:** When completely connected (half-blue, half-green Bluetooth icon) you can use your watch as a remote and control the music playback on your phone.

- **Notifier:** Click on this icon to see your 10 most recent incoming notifications including your iOS messages.

- **CameraRemote:**

To use your iTOUCH as a camera remote with your phone (for iOS or Android phones):

- 1) Please be sure that you have fully connected your phone to the iTOUCH via Bluetooth (half-blue, half-green Bluetooth icon).
- 2) Open up your phone's camera app.
- 3) Go to the main menu on your iTOUCH and navigate to the Camera icon and select it.
- 4) The iTOUCH will then connect directly to the phone's camera and you can tap the 'Capture' button in the center of the screen to take photos and to start and stop video from your phone's camera.

- **Lost Alert:** iTOUCH will sound an alarm after you have moved approx 33 feet away from your Bluetooth connected phone.

- **Settings:** Open this function to see the following menu

- 1) BT Settings: Set Bluetooth Power On/Off and set Bluetooth Visibility On/Off.
- 2) Clock: Select between 1 Digital and 2 Analog clock styles, Time sync: turn automatic Time Sync with phone On/Off, Date: Set date (when Time Sync is off), Time: Set time (when Time Sync is off), Time Format: Select between 12hr and 24hr format (when Time Sync is off)
- 3) Sound: Select your ringtones, alert types and notification tones.
- 4) Volume: Increase or decrease the volume for your Multimedia, Ringtone and Notification sounds
- 5) Display: Make adjustments to your Main Menu Style, adjust Brightness of the screen and adjust Screen Timeout time.
- 6) International: Auto Sync allows you to sync whatever language you are using on your phone to the iTOUCH. Language allows the user to manually choose their preferred language (when Auto Sync is off). Name Display allows you to select the format that names are shown in your Contacts list.
- 7) Units: Select between metric or imperial units for the watch display.
- 8) Motion: Turn the following motion sensitive functions on/off - *Mute incoming*: flip your wrist to mute your incoming calls, *Mute Alarm*: flip your wrist to stop your alarms, *Wake*: Flip your wrist to wake your phone from sleep, *Wake-up Gesture*: shake your wrist to return to the main menu, *Shake to Answer Call*: Shake your wrist to answer incoming calls.
- 9) Reset: Erase all the data from your iTOUCH
- 10) About: General information about your iTOUCH.

- **FindPhone:** Use iTouch to activate phone alarm or use iTouchSmartwatch app to activate watch alarm.

- **Alarms:** Set up to 5 individual alarms.

- **Sedentary:** Keep yourself from being too inactive by setting alerts to get up and move around. Set a timer to let you know when it's time to get some activity going!

- **Sleep:** Monitors the quality of your sleep. Swipe up to turn the sleep monitor On and Off and to see your Sleep history.

- **Pedometer:** Keeps track of steps taken throughout your day and syncs with your iTOUCH Smartwatch app.

- **Stopwatch:** Use your iTOUCH's built-in Stopwatch.

- **Weather:** When iTouch is fully connected to your phone, you can see current weather and future weather forecast on your watch.

- **Calculator:** Use your iTOUCH's built-in calculator.

- **Calendar:** Use your iTOUCH's built-in Calendar function. You can see today's date and by tapping on the round icon on the bottom, you will see the entire month and scroll up and down to past or future dates.

- **Voice Assist:**

iOS – When connected to an iOS powered phone, you can access Siri functions. Just select the Voice Assist icon on your watch and tap the screen to activate Siri and wait for the audio prompt. You can now speak your voice command into your watch.

Android – When connected to an Android powered phone, you can use OK Google (Google App) or S Voice. Just select the Voice Assist icon on your watch and wait for the audio prompt. You can now speak your voice command into your watch.

Note: Your iTOUCH's battery is not removable. If the watch is idle for more than a month, it may not be able to power on because the battery has fully drained. Please connect your watch to the charger. It should power up after a few seconds of charging.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.