

# Bluetooth® Hands-free Car Kit

**Best voice links you and me**


Ver. 06-01-16

## Introduction

This car kit is base on *Bluetooth* wireless technology connects to a compatible phone without wires. To enjoy its convenience, just plug it into the cigarette power jack, and pair with your mobile phone. You can easily answer your call and always keep your eyes on the road.

The LCD display can show the caller ID on incoming call. So, you know who is calling without looking your phone. Its internal DSP automatically performs noise reduction and echo cancellation. You are assured of optimum audio quality. It has been designed for professional life style. It allows you to transfer the voice between it and your mobile phone, even during talking, for your privacy.

## Keys and Parts



## Operation

### 1. Power on

1. Plugs it into your car's cigarette lighter.
2. LCD shows "**Welcome**" for 3 seconds, then show "**Blue Voice**". It means the power is on, and it stays at stand-by mode.
3. Blue LED flash once .

### 2. Pairing

1. Long press on "**NO**", it enters pairing mode.
2. Active your bluetooth function on your mobile phone, and search for new device. Select **Blue voice**.
3. Enter the pin code "**1234**" on your phone, and then connect to your mobile phone.
4. Short press the "**NO**" bottom to escape from the pairing mode.

### 3. Operation

1. Answer
  - ◆ During incoming call, the car kit rings, and the LCD will show the phone number or user name of the call.
  - ◆ Press "**YES**" button to answer the call.
2. Reject an coming call
  - ◆ During incoming call, press "**NO**" to reject
3. Terminate a call
  - ◆ During active call, press "**NO**" to terminate.
4. Voice dialing:
  - ◆ Active the voice function on your phone.
  - ◆ In standby mode, long press "**Vol(-) button**", wait for the tone, and say the name as you recorded on your phone.
5. Redial:

During the standby mode, press and hold "**Vol(+)** button" to redial the last dialing number.
6. Voice transfer
  - ◆ Press "**Yes**" to transfer voice between the CarKit and your phone, during an on-going call, for your privacy.
  - ◆ This function is not guarantee with every phone.

## 7. Adjusting the Volume

- ◆ To increase the volume, press "**Vol(+)** button" in talking mode.
- ◆ To decrease the volume, press "**Vol(-)** button" in talking mode.-

## 8. Mute

- ◆ Press and hold "**Vol(-)** button" to enable Mic mute function in during an on-going call.
- ◆ Press and hold "**Vol(+)** button" to disable Mic mute function in during an on-going call.

## 9. Connection

- ◆ In any disconnected mode, short press **YES** to connect.
- ◆ In connection mode, long press **NO** to disconnect.

## **Warning**

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the installation. , May cause harmful interference to radio communication. However, there is no guarantee that interference Will not occur in a particular installation. if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

- Consult the dealer or an experienced radio / TV technician for help

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## 藍芽顯示器車用免持聽筒

### 產品介紹：

此藍芽車用免持聽筒使用了藍芽無線通訊技術，可無線連接到藍芽手機上。產品設計顧慮到使用者之方便性，只要將此產品插入點煙器的接頭並和您的手機配對，您就可以輕鬆接聽您的來電。

液晶顯示器可以在來電時顯示來電號碼，所以你不需要看手機就知道來電者。內部聲音數位處理器(DSP)會自動消除回音和減低噪音，保持良好的聲音品質。此藍芽車用免持聽筒是為專業人士設計，為保持通話隱密性，可以在通話中自由的在手機和車用免持聽筒間作切換。

### 外觀說明：



**操作：**

**1. 開機：**

- 1.將此藍芽車用免持聽筒插進你車上的點煙器
- 2.顯示屏會顯示“Welcome”三秒鐘，然後顯示“Blue - Voice”。即表示電源開啟，保持待機狀態。
- 3.LED 閃爍一次。

**2. 配對：**

1. 長按” NO” ，此藍芽車用免持聽筒進入配對模式
2. 啟動手機上的藍芽功能，並操作手機搜尋新的藍芽裝置，選擇 Blue - Voice。
3. 在手機輸入密碼“1234”，就會連結到手機。
4. 過程中可輕按” NO” 就會離開配對模式。

**3. 操作：**

1. 接聽：

- ◆ 來電時車用免持聽筒會響，LCD 會顯示來電號碼或是來電者名稱。
- ◆ 按” YES” 鍵接聽電話。

2. 拒聽來電：

來電時按” NO” 拒接來電。

3. 掛斷：

通話中按” NO” 。

4. 語音撥號：

- ◆ 啟動您手機上的語音撥號功能
- ◆ 待機模式中，長按” V- “，等聽到嗶聲後，說出您記錄在手機上的語音命令

5. 重撥：

在待機模式下，長按” V+” 重撥上一通撥出電話。

6. 聲音移轉：

通話中按” YES ” 可以讓你在手機和車用免持聽筒間作切換。

7. 調整音量：

- ◆ 通話時按住降低音量按鈕來降低音量
- ◆ 通話時按住提高音量按鈕來提高音量

8. 靜音：

- ◆ 通話時長按住降低音量按鈕麥克風來進入靜音模式
- ◆ 通話時長按住提高音量按鈕麥克風來退出靜音模式

9. 連線：

- ◆ 在斷訊狀態下，短按” YES ”鍵，以連線通訊。
- ◆ 在連結狀態下，長按 “ NO “鍵，將會斷訊。