

Introduction:

Before using your BOOMBUDS earphones for the first time, please take a few moments to read through the user manual.

In the box:

2 x BOOMBUDS ear pieces.
1x BOOMBUDS charging carry case
1x Charging USB micro to USB cable.
2 x wing tip sizes x 2 colours
3 x Sets of silicone ear tips
1x manual.

fitting:

To ensure the best sound please choose from the 2 wingtips & 3 ear tip sizes. To change size gently remove and then simply replace.

**Boompods Tip:**

The tighter the fit in the ear the better the sound will be.

Controls:

On/Off - press & hold MFB for approximately 3-4 seconds

Play - press MFB once

Pause - press MFB once

To skip song forward - press MFB twice quickly

To skip song backward - press MFB three times quickly


Siri - press hold MFB for 2 seconds.

Calls:

To take a call quickly - press the MFB once.

To reject a call - press and hold MFB for approximately 1-2 seconds

To end call, short press MFB



To turn off simply place into the charging case, or press either of the multi-function buttons until you hear "GOODBYE" or the light has turned red.

Pairing & Bluetooth connection:

1. Remove your Boombuds from the case, press and hold the multi-function buttons for approximately 3 seconds, or until you see the lights go red, if you have them in your ears when you do this a voice will prompt; "HELLO", "CONNECTED" this means they are now connected to each other and ready to pair to your Bluetooth device.

2. Now open your Bluetooth device menu and look for the words BOOMBUDS in the menu, select this then you will be prompted "PAIRED" the light will now flash slowly green, you are now connected and ready to play music and receive calls. Some devices will automatically request to be paired as soon as you have switched on your Boombuds and open Bluetooth device menu, simply select "Pair".

3. Once paired to your Bluetooth device next time you use your BOOMBUDS it will remember and all you need to do is press both MFB for no more than 3 seconds & they will automatically pair to each other and the Bluetooth device.

4. If you want to pair to a new Bluetooth device you will need to remove from the old device and start the pairing sequence again with the new device.

Charging:

1. Before using for the first time please fully charge the case with supplied USB cable, insert the micro USB end to the case (1) and the USB end (3) to your USB socket. This will only take approximately 2hrs. When fully charged 4 blue LEDs (4) will be lit.

2. To charge ear pieces insert into the case this will take approximately 40mins, the light will be RED whilst charging and turn GREEN once charged.

Specification:

IPX4 Water & Sweat Resistance.

Bluetooth: 5

Frequency: 2.402GHZ-- 2.480GHZ

Driver size: 6mm

Transmission range: Up to 10meters or 33 feet (open space)

Receive sensitivity: -90dBm

Battery capacity: earphone 50mAh

Work time: 5 hours, 15 hours with charging case.

Charging box: 500mAh, can charge 3-4 times.

Charging time: 1-2 hours

General guidelines:

Keep away from high temperature or prolonged exposure to direct sunlight.

Do not get wet or submerge in water. If using during exercise, wipe any moisture away from with a soft cloth before folding.

Do not disassemble.

Do not drop the product.

Keep out of reach of children.

Do not use at full volume for long periods of time.

Do not use whilst operating machinery, driving or any activity that requires alertness to surroundings and/or could compromise safety.

Exposure to loud sounds can cause damage to hearing.

Warranty:

Your BOOMPADS product is guaranteed against any defects in material or workmanship for one full year from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage such as a knock or immersion in water, etc.

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.