


Instruction :



- 1) Mic : Microphone for hand-free answering of a phone call through Bluetooth
- 2) Bluetooth LED light
- 3) Backward : to search backwards for radio channel or previous of a song
- 4) Play/ Phone : to play music file from audio player though Bluetooth . Hand-free answering of a phone call though Bluetooth.
- 5) Forward : to search forwards for the radio channel or next of a song
- 6) Aux jack : connect the AUX cable (excluded)
- 7) DC jack : plug of the AC adaptor (excluded) on the side of the unit ,plug the AC adaptor to the wall outlet.
- 8) Function knob : Off / Bluetooth / Fm radio
- 9) Battery compartment : into C size for 8pcs battery (excluded)
- 10) Speakers
- 11) Volume : adjust sound volume

CAUTION :

Splash resistant. Do not use this unit under direct water flow.

This can with stand only small splashes. It is not waterproof. Do not immerse in water.

BATTERY OPERATED


Cooler box requires C SIZE/LR14 batteries. Alkaline battery

recommend.(EXCLUDED)

Installing the batteries :

The battery compartment is located on top.

Open the battery compartment cover by turning the knob counter clockwise from LOCK to OPEN.



Lift off the cover as shown above.

Insert the batteries according to the markings inside the battery compartment.

Replace the cover and turn the knob clockwise from OPEN to LOCK.

We recommend the use of Alkaline batteries.

CAUTION

1. When radio is not in use for a long time, remove the batteries.
2. Do not dispose batteries by fire as they may explode. Do not mix battery type such as alkaline and standard.

FM radio







- a) Function knob set to “ FM “ (8) position.
- b) Short press ◀◀/▶▶ to select previous or next channel .
- c) Adjust the sound volume (11) to min or max.

NOTE : FM mode ▶||/🔊 have not function.


Bluetooth pairing




- a.) Function knob set to 📶 (8) position .
- b) Turn Bluetooth terminal (mobile phone) Bluetooth function, find the device
- c) A short tune will sound if connection is successful, then the blue light will long bright.
- d) It has been successfully paired with the unit disconnected from the terminal, you need to reconnect just open a terminal’s Bluetooth feature, you can completed the

automatic connection.

- e) Using another Bluetooth device paired with this unit : disconnect the first unit's power, pairing repeat the above steps.
- f) Press   to go to the next or pervious piece of music.
- g) Press   will pause and play or answering of a phone though Bluetooth
- h) Playing music when have a calling, the music will Pause and blue light on flash press   to answer, end of call will automatically playing music.

AUX

- a) Function knob set to  or FM (8) connect the AUX cable (excluded) to the AUX port of a mobile phone or an audio player. Set the mobile phone or and audio player to play the music file.
- b) Adjust the sound volume (11) to min or max.

NOTE : When connect the AUX mode    have not function.

Turn OFF the Bluetooth of mobile phone / tablet before AUX operation.

CARRYSTRAP

Your cooler radio has a adjustable length carry strap attached and can be carry by hand or shoulder.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specification

Power supply

Batteries : 8 x 1.5v C size (LR14)Alkaline battery recommend(Excluded)

Bluetooth : version 2.1

Output power : 3W x 2

AC adaptor : 12V --- 1A (Included)