

Brookstone®

TOWEL SPA®

Towel Warmer

ADD LUXURIOUS WARMTH TO TOWELS, ROBES AND MORE



TABLE OF CONTENTS

Warnings and Cautions2-4

Location of Controls..... 5

Preparing Towel Spa® for Use 5

Towel Spa® Operation..... 6

Care and Maintenance..... 7

Troubleshooting 8

Warranty.....9-10

IMPORTANT SAFEGUARDS

When using electrical appliance, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not immerse in water, otherwise it may cause the risk of electric shock.
3. Caution—hot, do not touch metal surfaces.

CAUTION

- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. THERE ARE NO SERVICEABLE PARTS INSIDE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the unit’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

IMPORTANT SAFETY INSTRUCTIONS

All the safety and operating instructions should be read, adhered to and followed before the unit is operated.

DANGER

NOTE: As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of electric shock, burns, fire or injury:

1. Always unplug the unit from the electrical outlet immediately after using.
2. Do not use appliance for other than intended use.
3. Do not place or store unit where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. Do not reach for unit that has fallen into water. Unplug it immediately.
6. Care should be taken so that objects do not fall into and liquids are not spilled onto the unit.

WARNING

1. This unit should never be left unattended when plugged in.
2. Close supervision is necessary when this unit is used near children or disabled persons.
3. Use this unit only for its intended use as described in this manual.
4. Never operate this unit if it has a damaged cord or plug; if it is not working properly; or if it has been dropped, damaged or dropped in water.
5. Keep cords away from heated surfaces. Do not wrap cord around exterior of appliance or let cord hang over edge of table or counter.
6. Do not use outdoors.
7. Do not alter the Safety Plug or use an extension cord with this device.

8. Do not operate with a voltage converter.
9. Do not touch hot surfaces.
10. Do not use accessory attachments not recommended by manufacturer as this may cause injuries.

POWER CORD INSTRUCTION

SHORT CORD INSTRUCTION

A short power-supply cord should be used to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Extension cords are available and may be used if care is exercised in their use. If extension cord is used: the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance; and the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally. If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord.

POLARIZED PLUG


This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

SAVE THESE INSTRUCTIONS

FOR HOUSEHOLD USE ONLY

LOCATION OF CONTROLS

1. HEAT LIGHT
2. ON/OFF
3. HOT SURFACES
CAUTION LIGHT



PREPARING TOWEL SPA® FOR USE

1. Open the cover and remove any contents.
2. Place the Towel Spa® on a dry, level and hard surface.
3. Insert the Ground Fault Safety Plug into a standard 120V AC outlet.
4. Press the red reset button on the ALCI (Appliance Leakage Current Interrupter). This is located on the plug at the end of the power cord.
5. IF THE GREEN INDICATOR LIGHT ILLUMINATES, allow the Towel Spa® to complete its heating cycle and cool down completely.
6. IF THE GREEN INDICATOR LIGHT DOES NOT ILLUMINATE, the appliance is ready for normal use.

TOWEL SPA® OPERATION

SELECTING A TOWEL

Your Towel Spa® will warm 2 bath sheets measuring approximately 40" x 70". For best results use 100% cotton or cotton blend towels.

1. Insert the power cord into an electrical outlet.
2. Open the lid and place your towel inside.
3. Close the lid.
4. Press the button on the front of the unit. The GREEN INDICATOR LIGHT illuminates, indicating the unit is warming your towel.

NOTE: The RED CAUTION LIGHT will eventually illuminate, indicating that the inside surfaces of the Towel Spa® are hot to the touch. Handle the Towel Spa® carefully when the RED CAUTION LIGHT is illuminated.

5. The GREEN INDICATOR LIGHT will go off after approximately 8 minutes, indicating that the internal heater has automatically switched off. You may use your towel at this time, or leave your towel in the warmer for up to 20 minutes before using.

NOTE: The Towel Spa® must cool down, and the RED CAUTION LIGHT must go off, for Towel Spa® to be used to heat additional towels.

CARE AND MAINTENANCE

CLEANING

- Your appliance is maintenance free.
- If cleaning becomes necessary, disconnect the appliance from the wall outlet and wipe with a soft, dry cloth.

STORAGE

- When not in use, unplug your appliance.
- Allow the appliance to cool and store out of reach in a safe, dry location.
- Handle cord carefully to prolong life. Firmly grasp plug (or ALCI) when removing from the wall outlet. Do not pull plug from wall outlet using the cord.

TROUBLESHOOTING

PROBLEM	SOLUTION
My Towel Spa® failed to turn on.	<p>Make sure the Towel Spa® is properly plugged into a wall outlet. Be sure the Appliance Leakage Current Interrupter (ALCI) is functioning properly.</p> <hr/> <p>NOTE: To test the ALCI for proper function, turn on the appliance connected to the ALCI. Press the TEST button and the appliance should immediately turn off. Pressing the RESET button will restore power to the appliance or circuit.</p> <hr/> <p>Also, be sure the lid of the Towel Spa® is securely closed.</p>
My Towel Spa® is taking too long to warm towels.	<p>Be sure to only use dry towels; using damp towels will greatly extend the recommended 20-minute warming cycle.</p>
My Towel Spa® will not work two times in a row.	<p>If your Towel Spa® does not function properly after a towel warming cycle, allow the Towel Spa® to cool down before subsequent uses, and make sure RED CAUTION LIGHT is off.</p>

If you are still having problems with your Towel Spa® after trying the above tips, please call Brookstone® Customer Service at 1-800-846-3000.

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser,

but Brookstone, in so far as permitted by law, provides these products “as is.” This warranty does not apply to: a) damage caused by failure to follow instructions relating to product’s use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold “as is” including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Brookstone®

A WORLD OF INNOVATION

Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

Merrimack, New Hampshire USA 03054 • 800-846-3000 • www.Brookstone.com

634063