
Manual structure

A User's Guide and a Software Guide are provided on the CD-ROM included with this printer.

User's Guide

The User's Guide provides precautions for using this printer, details on the printer's setup.

Software Guide

The Software Guide describes the procedures for installing and uninstalling the software onto a Windows® PC or onto a Windows Mobile® device and their printing procedures.

Enclosed accessories

MW-260 mobile printer



Paper cassette

filled with C-211 thermal paper (50 sheets).



Rechargeable Lithium-Ion Battery (BT-200)

Brother Industries, Ltd.



Charger

(AC adapter: AD-210US)
Brother Industries, Ltd.



USB cable



CD-ROM

(contains the software, the User's Guide and the Software Guide)



Quick Guide (This guide)

