



Bluetooth Speaker / BARREL USER MANUAL

Warranty Conditions

This product is guaranteed for 2 years against defects in manufacturing or assembly.

This guarantee only applies to the primary purchase by the end user. It does not cover issues related to improper handling by the user. Proof of purchase is required in order to render the warranty valid.

The warranty does not cover problems associated with improper use, whether it is a result of negligence, processing, failure to store properly (excessive heat or humidity), improper installation or unauthorized repairs.

The manufacturer is contractually required to repair or replace the defective product. ALTEC LANSING is under no financial obligation to pay any amount in excess of that paid by the end user.

Reasons for warranty exclusions:

- Expired warranty period
- No proof of purchase
- Visible damage / breakage
- Oxidation
- Improper use
- Use of non-approved accessories
- Product altered, repaired or modified by an unauthorized third party
- Missing or altered serial number
- Warranty voided due to broken or altered packaging
- Damage due to accident, neglect, improper maintenance/care or force majeure
- Damage due to the installation of third-party software or a virus

Safety Precautions

Read these safety instructions before using your device and store them for possible future reference.

- The device is not intended for use by persons (including children) with reduced
 physical, sensory or mental capacity. Persons who have not read the manual, unless
 they have received explanations by a person responsible for their safety and
 supervision should not use this unit.
- Children should be monitored to ensure that they do not play with the device.

- The device should always be readily accessible.
- The device should not be exposed to dripping or splashing water.
- No objects filled with liquids such as vases shall be placed on the device.
- Always leave a minimum distance of 10 cm around the unit to ensure sufficient ventilation.
- Open flame sources, such as candles, should not be placed on top of the device.
- The device is intended for use only in a temperate climate.
- At full volume, prolonged listening to the portable audio device may damage the user's hearing and cause hearing troubles (temporary or permanent deafness, hearing drone, tinnitus, hyperacusis).
- So we recommend not to listen to the portable audio device at high audio volume and no more than one hour per day at medium audio volume.

SWITCH OFF IN RESTRICTED AREAS

• Switch the device off where the use of the device is not allowed or where there is a risk of causing interference or danger, for example on board an aircraft, near medical equipment, fuel, chemicals or blasting sites.

ROAD SAFETY COMES FIRST

Check the current laws and regulations regarding the use of this device in the areas where you drive.

- Do not handle the device when driving.
- Concentrate fully on the driving
- Radio signals could affect some of the car's electronic systems such as the audio stereo and alarm systems.

INTERFERENCE

- All wireless devices are susceptible to interference which may affect their performance.
- All our device conform to international standards and regulations, and if need be national ones, with a view to limiting user exposure to electromagnetic fields. These standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile headset and any adverse effects on health if the device is used in accordance with standard practices.

AUTHORISED PERSONNEL

Only qualified people are authorized to install or repair this product

ACCESSORIES

Only use batteries, chargers and other accessories which are compatible with this
equipment. Do not connect incompatible products.

KEEP THE EQUIPMENT DRY

• This equipment is not water proof. Keep it dry.

CHILDREN

• Keep your device in a safe place, out of the reach of young children. The device contains small parts that may present a choking hazard.

Declaration of conformity RTTE:

Market Maker Brand Licensing, herby declares that this equipment conforms to the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of Conformity can be viewed at the following address:

Market Maker Brand Licensing

79/81 ANCIENNE ROUTE NATIONALE 7 69570 DARDILLY

1. Features and Specifications

- Bluetooth version: V4.1
- Operation range: about 10M
- Radio frequency: 2402-2480MHz
- Frequency Response: 150Hz-18kHz
- □ RMS: (THD=10%)
- Driver: 52mm
- Power Supply: USB, DC 5V 500mA
- Distortion: <u>≤</u>1%
- S/N: ≥65dB
- Battery type and Capacity: Battery Li-Ion 3.7V 400mAh
- Battery Play Time: up to 2 hours
- Battery Charging Time: 1-1.5 hours
- Aux in: 3.5mm

- Product Size: 85x85x65mm
- Product Weight:80g
 - 2. Package Contents
- 1. Speaker BARREL
- 2. User Manual
- 3. USB to Micro-USB Cable
- 4. 3.5mm Audio Cable

3. Charging the Speaker

Before using the speaker for the first time charge it for at least 24 hours.

- 1. Plug the micro-USB cable into the port of the speaker.
 - Plug the opposite USB end into the USB port of a computer or compatible AC wall adapter.
- 2. The red LED turns on to indicate that the unit is charging.
- 3. Once fully charged, the red LED turns off.

4. Pairing the Device

- 1. Place speaker within 30ft of the Bluetooth-enabled device.
- 2. Slide the ON/OFF button to ON. The blue LED flashes 3 times slowly, then flashes quickly to indicate Bluetooth pairing mode.
- 3. Follow the instructions of your device to search for the speaker.
- 4. The speaker is called "Barrel." If a PIN is required, enter "0000."
- 5. The blue LED flashes slowly when pairing is complete.

5. Basic instructions

To turn the speaker on, slide the ON/OFF button to

ON. The speaker beeps and a blue LED flashes slowly.

The blue LED stays on when playing music.

To turn speaker off, slide the ON/OFF button to OFF.

6. LED indicator

Charging: Red LED on Fully


Charged: Red LED off

Pairing Mode: Blue LED flashes quickly

Connected: Blue LED on

Playing: Blue LED flashes slowly

7. Speaker button functions



- 1. LED Red/Blue
- 2. Power On/Off
- 3. Micro USB Use a computer USB port/AC power adapter with USB When the battery is low, approximately 1.5-2 hours of charging time is necessary to recharge the battery.
- 4. 3.5mm audio input (line-in)



The European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain, and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected.

To avoid possible hearing damage, do not listen at high audio volume for long periods of time.

Please visit www.alteclansing.com

MARKET MAKER BRAND LICENSING 79/81 Ancienne Route Nationale 7 69570 DARDILLY – FRANCE HELPLINE 0811 482 202

Product features, specifications and appearances are subject to change without notice.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

©2017 AL Infinity, LLC.

All rights reserved.

ALTEC LANSING, HORN Design and related logos are registered trademarks of AL Infinity and used under license.