

# Product Manuals

This product is Bluetooth Speaker for home or office use

## Precautions:

When being recharged the speaker will get warming slightly, which is normal phenomenon. When cleaning the product please cut off the power supply and all the external connections first. Please use the product in dry and clean environment.

Please don't let fall or tread on the speaker but lay it on an even flat surface to use it.

Please don't use chemical liquid such as ethyl alcohol or benzene to clean the speaker body;

Please don't put the speaker close to too hot or too cold objects;

Please use the accessories from our company with this product

Please don't take the liberty to disassemble the product

## Accessories:

AUX cord      1 pc  
USB cable      1 pc  
Instruction/warranty card      1 copy

## Function diagram

1. Microphone
2. Volume "+"
3. Single click: last one  
Long press: fast reverse
4. Single click: play, pause, receive and answer  
Long press: cut off Bluetooth
5. Single click: next one  
Long press: Fast forward
6. Volume "-"
7. AUX audio input
8. Power Switch
9. Micro USB recharge port

## Definition of press buttons:

- 1."+" indicates volume up by single click or long press, under AUX mode it doesn't work;
- 2."" under Bluetooth single click indicates playing last piece while long press indicates fast backward, under AUX mode it doesn't work;
- 3."" Under Bluetooth it indicates play/pause, when there is a call coming in to the connected device the speaker will stop playing with a warning beep sound at the same time the mobile will ring, click this button to answer the phone and one can answer the call through the MIC of the speaker. Long press this button one can cut off the Bluetooth connection between the mobile and the speaker to use the mobile to communicate directly. Under Bluetooth playing mode long press of this button indicates starting searching Bluetooth device and matching with it.
- 4."" Under Bluetooth mode single click indicates play next one, long press indicates Fast Forward, under AUX mode it doesn't work;
- 5."-" indicates volume down by single click or long press, long press indicates Fast Forward, under AUX mode it doesn't work.

## Function Introduction

Play music: Bluetooth wireless playing, AUX input playing

Hand free answer: to answer the mobile's incoming call by click the answer button on the speaker

Built in battery: built in 800MAH polymer battery, ultra-long standby capability

Eco-friendly and energy saving: If standby state lasts over 10 seconds the speaker will shut down automatically

Turn on/off

Power on/off witch can be found at the back of the speaker. When switched to "on" position the system will be started with flashing of the blue LED, while to "off" position the system will be shut off;

Bluetooth mode

Bluetooth mode is the default start on mode of the speaker with flashing of blue LED and beep sound when not connected to the AUX cord. Under this mode press "search" button the device named "C8" will appear, then press "match" button the matching process will start and succeed with a beep sound to be ready for playing music. If need to switch to another receiver device, one need to cut off the current connection. Once matching of device succeeds the speaker will

remember the device of this Bluetooth connection and next time when powered on the system will automatically search for it and match with it within 3 seconds if it's still there.

#### AUX mode

Turn on the power switch at the back of the speaker while connecting it to the device at the AUX port. The system will be switched to AUX mode with a flashing blue LED and ready to play the music through the connected device.

#### Recharge through MIC USB

This product is provided with a USB cable for connecting it with a PC. When the red LED lights on continuously, the built-in battery of the speaker is being recharged, which is a slow way of recharging and takes about 12 hours for full charging, while if it's recharged through an adapter like a mobile's (5V, 0.5A), the whole process will only take about 3 hours. During recharging, the speaker still works as usual.

### **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **RF warning statement:**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.