

版本	更改内容	日期
A		
B		
C		

42.5mm

45mm

### Rugged Fabric Waterproof Bluetooth® Speaker

Instruction Manual  
7198-44

- Power ON/OFF
- Mode (Play/Pause/Call Button)
- Vol+ / Next Track
- Vol- / Prev Track
- Reset Button
- Charging Port
- AUX Line-In
- LED Indicator
- Microphone

**What's included:**  
 1 x Bluetooth® Speaker  
 1 x USB to Micro-USB Charging Cable  
 1 x 3.5mm Audio Cable  
 1 x Instruction Manual

**Tech Specifications:**

- Playing Time: 4 hours (at max volume)
- Battery Capacity: 2000mAh/3.7V
- Charging Time: 2.5 - 3 hours
- Pairing Name: "Rugged BT"

**LED Indicator:**

- Charging: Red ON
- Fully Charged: LED OFF
- Pairing Mode: Blue LED Flash
- Connected: Blue LED ON
- Playing: Blue LED Slow Flash

**Instructions:**

- Charging the speaker:
  - Using a Regulated USB Adapter: Connect the provided USB cable to a regulated USB adapter. Connect the opposite, Micro-USB end of the cable to the charging port on the speaker. Plug the USB adapter into the outlet to begin charging.
  - Using a Computer: Connect a USB cable to a USB outlet on your computer. Using the Micro-USB connector, connect the other end of the USB cable to an charging port on the speaker. Make sure the computer is on to begin charging the speaker.
    - Red LED ON when charging & OFF when fully charged.
- Power ON/OFF & Bluetooth® Connection: Press and hold the Power button until the Blue LED begins flashing. Once on, the speaker will enter Bluetooth pairing mode. Using a Bluetooth enabled device, search for "Rugged BT" from the list of available devices. Blue LED will illuminate fully indicating a successful pairing. Press and hold Mode button to unpair.
  - Using the speaker:
    - When receiving a phone call, press Mode button to answer and again to hang up.
    - Double press to redial the previous number.
    - Single press Mode to Play/Pause audio.
    - Long press to disconnect paired device.
    - Short press Vol+ to increase volume.
    - Long press Vol+ to skip to the next track.
    - Short press Vol- to decrease volume.

**SAFETY PRECAUTIONS:**

- WARNING—When using this product, basic precautions should always be followed, including the following:
  - Read all the instructions before using the product.
  - Charge the speaker completely before initial use to ensure battery life.
  - If the device does not respond once it is powered on, the battery capacity may be low.
  - Do not over charge the internal battery.
  - Do not immerse into liquids or expose to moisture or weather conditions.
  - Do not drop, knock, or shake. Rough handling can damage the internal precision component and its boards.
  - Keep away from children, this device is not a toy.
  - Keep away from fire or other sources of heat. Exposure to high temperatures may cause explosion or injury.
  - Do not short-circuit to avoid damage to the unit.
  - Unauthorized changes or modifications may void your right to use this product.
  - While using, always comply with any special regulations that may apply to the area you are in and always turn off your mobile device when its use is prohibited.
- Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC Warning:**  
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 • Reorient or relocate the receiving antenna.  
 • Increase the separation between the equipment and receiver.  
 • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 • Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**FC**  
MADE IN CHINA



**制作工艺:**

尺寸: 85 x 90mm 折后尺寸 : 42.5 X 45MM

材质: 105G单铜

印刷: 单黑印刷

表面处理: 折页 正反面印

色相正确、印迹牢固、套印准确、各色套印  
不露杂色，套印误差 ≤ 0.1mm

size:85 x 90mm  
 105G单铜  
 单黑印刷  
 折页 正反面印  
 折后尺寸 : 42.5 X 45MM

技术要求(包装物料)	默认公差尺寸表						<b>深圳市鼎诚泰富电子科技有限公司</b> SHENZHEN DCTF CEAUDIO ELECTRONICS CO LTD	初创日期	20180117				
	尺寸 (mm)	>0-10	>10-20	>20-50	>50-100	>100-200		>200	文件比例	1:1			
	公差 (mm)	0.5mm	1.0mm	1.0mm	1.25mm	1.50mm		1.75mm					
纸张厚度标准: • 铜版纸类印刷品: 纸张克重依据印刷行业行业标准 • 坑纹纸类印刷品: 破裂强度及边压强度依据印刷行业行业标准							MODEL_NAME (机型名称)	<b>F400</b>		PART_NAME(零件名称)	<b>说明书</b>		
							PO No. 生产订单号	<b>DC171125-001</b>		PART_NO.(物料编号)	<b>416-0F400091-00R</b>		
							NUMBER 用量	<b>1PCS</b>		美工	刘杨	电子	审核