


Sporty Bluetooth Ear Buds

Item #:CPP-4499



Instructions :

1. Charge the product
 - a. Charge Bluetooth ear buds before use.
 - b. Connect Bluetooth ear buds to power source with USB cable provided.
 - c. Red LED indicates charging. It takes 1.5-2hr to fully charge the ear buds.
2. Bluetooth Connection
 - a. Slide the switch to the right to turn on power. Blue light indicates power is on. Blue light will flash when ready to pair.
 - b. Activate Bluetooth on device to be paired.
 - c. Select "CPP-4499" for pairing.
 - d. Bluetooth Ear Buds will automatically pair. Flashing blue light turns solid blue after paired successfully.
 - e. Bluetooth Ear Buds will pair automatically next time they are turned on.

Important Safety Precautions

1. Loud noises and sounds can damage hearing. Use this product with caution. Set the volume low and gradually increase.
2. Keep away from high temperatures or prolonged exposure to direct sunlight.
3. Do not expose to liquids, drop or disassemble.
4. Low battery will unpair the Bluetooth connection.
5. Do not charge Bluetooth ear buds while in use.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks (D026370) is under license. Other trademarks and trade names are those of their respective owners.

MADE IN CHINA

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.