# Bluetooth speaker

MODEL:C26

Get beautiful sound wirelessly

Precaution

1. It is a normal phenomenon that the speaker will have a bit fever when normally operated or charged.

2. If you need to clean the speaker, please turn off the speaker and disconnect it with all external devices before cleaning.

3. Don't use alcohol, benzene or other chemicals to clean the speaker.

4. Do not drop or trample the speaker.

5. Don't put the speaker near extreme cold or heat objects.

6. Please use the accessories provided by our company.

7. Don't dismantle the speaker by yourself.

Packing List:

AUX Cable × 1

Hook × 1

USB Cable × 1

Instruction × 1

Product Diagram

①AUX Input

②USB Charging Port

③Switch

④Mute

⑤Play/Pause/Handsfree

⑥Previous Record/Volume Down

⑦Next Record/Volume Up

⑧Flashlight Switch

Functions

1. Pairing

(1)Toggle the switch, blue indicator flashes fast means is in pairing mode.

(2) Turn on the Bluetooth of your phone and search for "C26", select it.

(3)It will automatically connect to the last paired phone when turns on. (Please make sure the Bluetooth function of your phone is on, and the speaker is in range.)

2.Playing

(1) Handsfree: When a call comes in, short press " ▷‖ " to answer it, long press to reject, and short press it again while you finish the call.

(2) Redialing: Short press " ▷‖ " twice to redial the last called number.

(3) If you don't want one to hear you during a call, press button "M" once, and press it again to unmute.

(4) Long press " ▷‖ " to disconnect the bluetooth after pairing.

(5) Long press the button "<" to turn down the volume, short press to skip previous record. Long press the button ">" to turn up the volume, short press to skip to next record.

3.Flashlight

Functions

Press the Flashlight Switch no matter the speaker is on or off to activate the flashlight function, long press 2 seconds to shut it.

4.AUX Input

Connect the speaker to your phone or other mobile devices with the provided AUX cable, then you can enjoy the music via the speaker.

5.Charging

When the sound begins to turn down and distort, it's time to charge the speaker.

Use the included USB cable to connect the speaker to the computer or an adaptor. The LED indicator remains red when charging, and the indicator will turn into blue when fully charged. It takes about 5-6 hours to fully charge through the computer, only takes 4-5 hours via an adapter (5V 1 A) . (In order to prolong the battery life, we highly suggest you do not use it while charging.)

Product overview:

1. The fashion designed Bluetooth speaker can offer you endless enjoyment when you are travelling outside.

2. Bluetooth function makes listening music wirelessly

3. With the Aluminum alloy hook, you can hang this Speaker on the mountaineering bag or other places conveniently.

4. Built-in MIC, you can pick up a call by this speaker in car, at home or office conveniently.

5. After the speaker is on and without any operation for 10 minutes, it will shut down automatically

Warranty Agreement

In order to let you enjoy the service better, Please read

following agreement:

The validity period of product warranty starts from the date

of sale ("three guarantees"). During the validity period of

 "three guarantees" , the malfunction of this product w ill be

solved according to the provision of "three guarantees" :

repair, replacement or return. During validity period of

product warranty, the Company provides free maintenance

service (exceeds the range of warranty). And, during the

 "three guarantees" period, the company will implement

the paid service for following cases:

1. Cannot show the original warranty and effective invoice

2. The malfunction and damage are caused by irresistible

factors and other reasons

3. The damage and failure are caused by your error in operation

 (not in accordance with the "manual" of normal operation)

4. The failure and damage are caused by the transportation

5. The failure and damage are caused by the fault disassembly

and maintenance without prior authorization of company. As

for fault repair, please return the warranty card and sale

invoice, and you need to deliver the warranty card and sales

 invoice together to after-sales service center and afford the

Specifications

Bluetooth Module: CSR 4.0

Output Channel : 2.0

Input voltage: DC-5V/1A

Output Power: 5W * 2 RMS (Audio)

Battery Specifications: 3.7V/2200MAH

Speaker: 45 mm * 2   4Ω/5W

S/N: ≥85DB

Size: 186mm (W) x 56mm (D) x 61mm (H)

Weight: 400g

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warranty Card

When purchasing the product, please immediately fill the card and put it away

Name		Age	
Tel no.		Postcode	
Gender		Purchase	
Date of buying		Product code	
Part no.		Sale No.	
Postal address			

Dealer stamp: User signature: