

IR/RF Internet Wireless Keyboard

Overview

System

Installation

Multimedia Button

Setting Program

Requirement

Functions

Overview

~~Congratulations on your purchase of the IR/RF Internet Wireless Keyboard. The IR/RF Internet~~
Wireless Keyboard combines a standard keyboard layout with 17 convenient Multimedia Buttons which control the following:

- CD control buttons: Play/Pause, Previous, Next, and Stop.
- Volume control buttons: Volume Up, Volume Down, and Mute
- World Wide Web site buttons: Internet browser, and E-mail.
- Re-defineable control buttons: The function of button can be re-defined

System Requirement

Before installing the IR/RF Internet Wireless Keyboard software, please make sure that the hardware connections of your keyboard are correctly set up. The following system specifications are required:

- IBM PC compatible system
- Microsoft® Windows® 95, 98, 2000 or NT4.0
- CD-ROM drive (for CD and Video operation)
- Standard sound card (for CD and Video operation)

When using the 3 power management buttons, particular requirements are needed:

- Microsoft® Windows® 98 or 2000 Operating System
- The system supporting ACPI or APM II
- ATX mother board and ATX power supply

Top

Installation

Installation for Windows operation system

Please follow the instructions below on how to install the IR/RF Internet Wireless Keyboard software to your PC system.

1. Please insert the CD included in your package, labeled "Multimedia Keyboard Driver" into your CD-ROM drive.
2. Simply double-click on the *setup.exe* to continue the installation procedure.
3. Follow all the on-screen instructions.

Uninstallation

1. From the Windows Start Menu, locate uninstall under Programs Files\Multimedia Keyboard V1.0\ , and double-click on *Uninstall Multimedia Keyboard* to uninstall the driver.

Top

Multimedia Button Functions

Multimedia hot keys Internet hot keys Customize hot keys

- | | |
|--------------------------|----------------------------|
| ☐ | CD Player / VCD Playe |
| | Windows CD Player / Winamp |
| ☐ | Previous Track |
| ☐ | Stop/Eject |
| ☐ | Play |
| ☐ | Next Track |
| ☐ | Volumn +/- |
| ☐ | Mute on/off |
| ☐ | Menu |
| ☐ | Close |
| ☐ | WWW |
| ☐ | Email |
| ☐ | Address Book |
| ☐ | WWW Search |
| ☐ | Help |
| ☐ | Dos Shell |
| ☐ | User Define |

Power hot keys

- | | |
|--------------------------|-----------|
| ☐ | Sleep |
| ☐ | Wake up |
| ☐ | Power off |

Pointing Devices

Mouse left key
Mouse right key

Pointing control
Scrolling Wheel

[Top](#)

Setting Program

Pop-up Menu

Once the software installation for the Multimedia Keyboard is complete, the icon  is shown on the Windows® taskbar. The setting program provides 17 graphic Multimedia Buttons on the screen. You can Re-defineable control buttons.

Graphic Multimedia Buttons



Left-click the icon  on the taskbar of Windows® to activate the graphic Multimedia Buttons. Once you place the pointer on a button, a tooltip dialog box will appear displaying the function of the particular button.

[Top](#)

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment