

CRE Technology Co., Ltd.

OVERVIEW

Congratulations on the purchase of the Multimedia Keyboard. It comes bundled with Multimedia Keyboard software. The Multimedia Keyboard features 23 easy-access hot keys for quick launching of programs such as CD player, Internet browser, the suspend system, etc. Plus, 10 of the 23 hot keys are user-definable allowing a more personal functionality in program control and launching.

A label containing the model name and serial number is located on the back of the keyboard. Please do not remove the label from the keyboard. The label information will be important for you to return the keyboard to manufacturer for repairing, when you have any problems with this keyboard.

It is recommended that the installation CD be stored in a dry, safe location for future use or reference.

FEATURES

The Multimedia Keyboard software includes the following features:

One-Touch Access to Multimedia Applications

The Multimedia Keyboard software provides quick access to audio and video CD's. Plus you can also control volume of playing music, forward to next track, backward to previous track, or record CD source to your hard disk.

Instant Access to Internet

The Multimedia Keyboard software launches your Internet browser at the stroke of a key. Simply press a hot key to jump to your favorite search engine, go to the next or previous page, or stop loading.

Launch Applications

The Multimedia Keyboard software may be customized to launch any application program such as Excel, Word, PowerPoint, etc.

Additional Applications

The Multimedia Keyboard software gives the user the ability to enter a suspend mode, screensaver mode, as well as activating the system calculator. It also gives you the added

CRE Technology Co., Ltd.

feature of transferring any calculated figure to an application of your choice.

INSTALLATION

The Multimedia driver and software are contained in one CD-ROM. To install, please follow the instructions below:

1. Turn on your computer and run either Windows 95 or Windows 98.
2. Place the Installation CD into your CD-ROM drive
3. Windows 95/98 has an auto-detect feature that will automatically launch the installation program. Follow all on-screen instructions.
4. If the auto-run feature has been de-activated, select the "My Computer" icon on your Desktop, double-click on your CD-ROM drive. Click on the "SETUP.EXE" file and follow all on-screen instructions.
5. After successfully installing the software, you will be asked to re-start the computer. Please select "OK" to re-start the computer. It is necessary to re-boot your computer before running The Multimedia Keyboard software.

Using The Multimedia Keyboard

Multimedia Keyboard Application software

After successfully installing the software and re-booting your computer, Multimedia will automatically load the Multimedia icon on the 'system tray' at the bottom right hand side of the screen. Double-click the icon to start the program. The On-Screen Display (OSD) keyboard is shown on the screen which resembles the corresponding keyboard hotkey layout.

Uninstalling the Multimedia keyboard software

To remove the Multimedia keyboard software from your computer, first close the Multimedia software by clicking the right mouse button on the 'system tray', and select 'exit'. Then, click "Start" button, and select "control panel". Click "Add/Remove program", then select "Multimedia" to remove the program from your computer.