

# Features and Functions Guide

## H605 Bluetooth® Handsfree Headset


**IMPORTANT:** Be sure to first follow the **MOTOSTART** Quick Start Guide on the reverse side of this guide to complete initial setup of your H605.

### TURNING ON AND OFF

To turn your headset on, press and hold the Call button until the indicator light flashes. Then, release the button.


To turn your headset off, press and hold the Call button until the indicator light flashes rapidly and then turns off.

To conserve battery power, turn off your headset when you don't plan to use it for a while.



### WEARING THE HEADSET


- 1 Place the end of the headset with the blue indicator light near the top of your ear.
- 2 Slide the headset down and around along the back of your ear so that the end of the headset with the blue indicator light faces out from the bottom of your ear.
- 3 Direct the speaker by tilting and rotating it toward the opening of your ear.



### CHANGING FOR USE ON OTHER EAR

You can wear your H605 headset on your left or right ear. The headset comes ready for the right ear. To change the headset for the left ear:

- 1 Rotate the speaker 180 degrees, turning counter-clockwise.
- 2 Direct the speaker by tilting and rotating it toward the opening of your ear.



### INDICATOR LIGHTS

The indicator light provides information about your headset status.

#### With the Charger Plugged In

Headset Indicator	Headset Status
On (steady)	Charging
Off	Charging complete

#### With No Charger Plugged In

Headset Indicator	Headset Status
Off	Power off
On (steady)	Pairing mode
10 rapid flashes	Pairing successful
Slow pulse (on a call)	Connected
Quick flash (not on call)	Standby

Note: After 5 minutes of inactivity, the light stops flashing to conserve power, but the headset remains in standby mode.

### MAKING CALLS

Function	Action
Make a voice dial call	Tap the Call button and speak the name after the tone
End a call	Tap the Call button
Receive a call	Tap the Call button
Reject a call	Press and hold the Call button until you hear a beep
Redial last call	Press and hold the Call button until you hear a beep
Answer a second incoming call	Press and hold the Call button (places first call on hold)

Note: Your H600 supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See your phone's user's guide for more information.

### MAKING CALLS CONTINUED

Function	Action
Toggle between two calls	Press and hold active the Call button
Join a 3-way call	Press and hold (Note: Feature is phone/network dependent.)
Put an active call on hold or resume a call you on hold	Press and hold Call button until you hear a beep
Transfer a call from the buttonphone to the headset	Tap the Call
Disable or enable the hold indicator light	Press and both Volume buttons for 3 to 4 seconds
Mute or unmute a call	Tap both Volume buttons

### AUDIO TONES

The audio tones provide information about your headset status.

Audio Tone	Headset Status
Single high tone when minimum pressing volume button	Volume at or maximum
Five rapid high tones every 60 sec.	Low battery repeated
No audio indications; rangedeteriorating quality	Out of
Ring tone	Incoming call
Single high tone	Pairing confirmation
Single low tone	Voice activation
Dual high/low tone recognized	Voice tag not

### AUDIO TONES CONTINUED

Function	Action
Single high tone	End call
Low to high tone	Phone network not available
Two ascending tones	Mute enabled
Two descending tones	Mute disabled


### FOR MORE INFORMATION ON USING YOUR MOTOROLA H605

Visit us at [www.hellomoto.com/bluetooth](http://www.hellomoto.com/bluetooth) and click Support.

### SUPPORT

If you need more help, contact us at 1-877-MOTOBLU.

SYN0986A / H605  
FCC ID: OHH-H300  
IC: 1090



Placeholder Graphic



This symbol on a Motorola product means the product should not be disposed of with household waste. Please do not dispose of mobile telephones or electric accessories, such as chargers or headsets, with your