



Quick Start Guide


- 1 Download and install the Nightingale app from your mobile app store.**

For Apple users, go to the Apple App Store. For Android users, go to Google Play.
- 2 Plug one Nightingale unit into an outlet in your room.**

Plug the other unit into a different outlet in this room. For better acoustic coverage, choose outlets on opposite walls. (Please do not plug units into each other.)
- 3 Launch the Nightingale app to configure your Nightingale units.**

You will need access to an active email account, to register the units. Once they are configured, you can control them through this app or through any supported browser at: www.controlnightingale.com

Technical Specifications



Physical Dimensions (each):

Height 4.3", Width 2.7", Depth 1.7"
(Depth is 1" when it is plugged in)

Weight: 5.5 oz.

Voltage (pass-through): 110 V

Amperage (pass-through): 15 A

Number of Speakers (each): 2

Masking Blanket Frequency Range:

500 Hz - 4 kHz @ 30 - 50 dB (SPL)

Sound Pressure Range:

0 - 60 dB (SPL)

Optimal Sound Pressure:

43 dB (SPL)

Radios:

(1) Wi-Fi: 2.4 GHz

(1) Bluetooth LE: 2.4 GHz

Communication Security:

AES

Coverage Area (per pair): 300 sq. ft.

Number of Sound Blankets: 15

Nightlight Colors:

White, red, yellow, blue, green

Patents & Trademarks:

U.S. Provisional Application

No. 62/219,536 (9/16/15)

U.S. Non-Provisional Application

No. 14/985,879 (12/31/15)

International Patent Application

No. PCT/US2015/068283

Warranty:

1-year limited warranty