

Shenzhen Carbos Electronic Technology Co.,Ltd.

Wireless Light-Up Mirror with Speaker

KBS1805



INSTRUCTION MANUAL

**PLEASE READ ALL INSTRUCTIONS CAREFULLY
& RETAIN FOR FUTURE USE**

Getting Started

Remove the product from the box.

Remove any packaging from the product.

Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

Smart Touch Wireless Light-Up Mirror with Speaker

USB charging cable

Instruction manual


Features

1. Perfect for your beauty regime with crystal clear reflection
2. Removable 10X magnifying mirror for up close precision
3. Hands-free speaker – phone Bluetooth microphone for hands free calls
4. 20 LED lights for even illumination
5. Smart touch screen with ON/OFF button
6. 180-degree rotating neck to suit your required angle
7. Built-in Bluetooth speaker; connect & stream wireless music
8. Integrated storage tray
9. Lightweight design
10. Built-in rechargeable battery

IMPORTANT SAFETY INFORMATION

1. Read all instructions before using this product.
2. Do not leave this product unattended while connected to the power supply.
3. Do not use if product has been dropped or damaged in any way.
4. Repairs to electrical equipment should only be performed by qualified personnel.
Improper repairs may place user at serious risk.
5. Place product on sound, even surface, free of vibrations and away from sources of heat.
6. Do not put objects into openings.
7. Keep free of dust, lint, hair etc.
8. Do not use this product for anything other than its intended use.
9. Keep this product out of reach of children.
10. This product is not a toy.
11. Do not play music at excessive levels especially near children, as damage to hearing may occur.

Description of Parts:



S. No.	Description	S. No.	Description
1	Mirror	8	Skip Backward / Volume Decrease
2	Smart Touch Button	9	Built-in Mic
3	20pcs LED	10	LED Indicator
4	ON/OFF Switch	11	Charging Port
5	Power Button	12	Rotary Neck
6	Skip Forward / Volume Increase	13	10X Magnifying Mirror
7	Play / Pause / Phone Button		

INSTRUCTIONS FOR USE

Charging the product

Note: For best results, fully charge the product before its first use.

1. Connect the USB charging cord (included) to the DC 5V charging port of the product and insert the other end into a port on your computer or similar power source.
2. Red LED glows indicating that the battery is being charged. Once it is fully charged, the Red LED will turn off. It will take 2 - 3 hours to fully charge the battery.

Turn On/Off the Product

Slide the ON/OFF switch to ON position. Press and hold the Power button for 2-3 seconds to turn on/off the product.

Pairing your device with Bluetooth Speaker

Your **Bluetooth Speaker** can wirelessly stream audio from any Bluetooth enabled device within the distance of up to 27-33 Feet. Simply follow the below steps.

1. Slide the ON/OFF switch to ON position. Press and hold the Power button for 2-3 seconds to turn on the product.
2. An indication tone would be heard, and the LED flashes blue rapidly. Your speaker is now ON and is entering “pairing” mode.
3. Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.
4. It will search for various devices.
5. The pairing name of our Bluetooth Speaker is “**SL SMART TOUCH**”, pair it with this device.
6. If required, enter the password ‘0000’ to confirm to finalize pairing.
7. Once paired successfully, you would hear another indication tone, and the blue LED stays on.
8. If you fail to pair it within the time frame or you want to pair it with a new device please follows the steps outlined above.

Select your favorite song at the Bluetooth device and music would now stream through Bluetooth speaker.

(Note: Speaker automatically pairs with the previously paired devices.)

Answering Phone Calls through the Bluetooth Speaker

Please ensure that your cell phone is paired with the Bluetooth Speaker to use the below functions.

Function	Operation	Button
Answer Incoming Call	Incoming Call	Short press the Phone button to answer an incoming call.
End Call	Incoming Call	After your phone conversation, short press the Phone button
Volume Increase	During a call	Long press on the Volume Increase button will increase the volume
Volume Decrease	During a call	Long press on the Volume Decrease button will decrease the volume

Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Increase / Decrease Volume	Playing music	Long press the Volume Increase button to increase the volume or long press the Volume Decrease button to decrease the volume
Pause	Playing music	Short press the Play / Pause button to pause the music
Play	Pause	Short press the Play / Pause button to resume the music
Skip Forward / Skip Backward	Playing music	Short press the Skip Forward button to skip forward the track. Short press the Skip Backward button to skip backward the track.

(Note: An indication tone will alert you when the volume is adjusted to the maximum level.)

Turning On/Off the 20 LED light

Slide the ON/OFF switch to ON position. Short touch the Smart Touch Button to turn on/off the 20 LED light. Long touch the Smart Touch Button to increase/decrease the light intensity level.

Do's and Don'ts

Do not play music at excessive levels. Damage to hearing and/or equipment may result.
Do not use outdoors in wet or in damp surroundings.

Specification

Bluetooth version: 4.2

Wireless Streaming Range Distance: 27-33 Feet

Speaker output: 2x3W

Unit Size: 7-1/4" L x 4-1/2" W x 11-1/2" H

Unit Weight: 27.4 Oz approx.

Charge Voltage: DC 5V (USB)

Charging Time: 2-3 hours

Play time: 2 hours

Built-In Rechargeable Battery: 3.7V / 500mAh

(Note: Battery life & charging time may vary based on usage, types of devices connected & Wireless distance.)

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low. Battery dead	Adjust source volume. Charge Battery.
Sound distorted	Battery nearly dead	Charge Battery.
No sound at all.	Source (Tablet, Mobile Phone, Laptop.) turned off. Speaker turned off. Volume turned down source. Media paused on source.	Turn the source on. Turn the speaker on. Adjust volume source. Play media from source.

Care and Maintenance

Clean the unit with a soft, damp cloth. Never use chemicals or hard abrasives.
Keep this unit away from wet or damp surroundings.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in USA, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.