

## 1.6 User Manual





Lieferumfang · Contents of package · Fournitures · Contenido del embalaje Contenuto della fornitura · Inhoud van de levering · Volume de fornecimento Leveransomfattning · Toimituslaajuus · Zakres dostawy · Szállítási terjedelem Vsebina pakiranja · Rozsah dodávky · Leveringsomfang Leveringsomfang · Παραδοτέος εξοπλισμός





| Montage- und Betriebsanleitung Technische und designbedingte Änderungen vorbehalten                       | 4  | D          |
|---|----|------------|
| Assembly and operating instructions Subject to technical or design-related modification                   | 8  | GB<br>USA  |
| Instructions de montage et d'utilisation Sous réserve de modifications techniques et des véhicules        | 12 | ·          |
| Instrucciones de montaje y de servicio Reservado el derecho a modificaciones técnicas o debidas al diseño | 16 | E          |
| Istruzioni per il montaggio e l'uso<br>Con riserva di modifiche tecniche e dovute al design               | 20 |            |
| Montage- en gebruiksaanwijzing Technische en door het design bepaalde wijzigingen voorbehouden            | 24 | NL         |
| Instruções de montagem e modo de utilização<br>Sujeito a alterações de design e técnicas                  | 28 | P          |
| Monterings- och bruksanvisning Tekniska och designrelaterade ändringar förbehållna                        | 32 | S          |
| Asennus- ja käyttöohje<br>Oikeudet teknisiin ja muotoilumuutosten aiheuttamiin muutoksiin pidätetään      | 36 | FIN .      |
| Instrukcja montażu i obsługi<br>Zastrzega się prawo do zmian technicznych oraz uwarunkowanych wzornictwem | 40 | PL         |
| Szerelési és használati utasítás<br>A műszaki és formatervezésből eredő módosítások joga fenntartva       | 44 | H          |
| Navodila za montažo in uporabo<br>Tehnično in oblikovno pogojene spremembe pridržane                      | 48 | SLO        |
| Návod k montáži a obsluze<br>Technické z designem podmíněné změny vyhrazeny                               | 52 | <b>©</b> 2 |
| Montajse- og bruksanvisning<br>Det tas forbehold om endringer i teknikk og design                         | 56 | N          |
| Monterings- og driftsvejledning Tekniske og designmæssige ændringer forbeholdes                           | 60 | OK .       |
| Οδηγίες συναρμολόγησης και λειτουργίας<br>Με την επιφύλαξη τεχνικών και σχεδιαστικών αλλαγών              | 64 | GR         |

0.000



#### Dear customer

Congratulations on purchasing a Carrera RC model car, manufactured in accordance with the latest technology. As it is our constant endeavour to develop and improve our products, we reserve the right to make modifications, either of a technical nature or with respect to features, materials, and design, at any time, and without prior notice. For this reason, no claims will be accepted for any slight deviations in your product from the data and illustrations contained in these instructions. These operating and assembly instructions are an integral part of the product. Non-observance of these operating instructions and the safety instructions they contain will render the guarantee null and void. These instructions are to be kept for future reference and in the event that the product is passed on to a third party.

## Guarantee conditions

A Carrera product is built to high technical standards and is to be treated with care. Please ensure that you observe all the instructions contained in this guide. All components have been subjected to careful inspection (technical modifications and alterations to the model for the purpose of product improvement are reserved).

Should any faults nevertheless occur, guarantee is assumed within the scope of the following conditions:

The guarantee covers demonstrable material or manufacturing defects that existed at the time that the Carrera product was purchased. The guarantee period is 24 months beginning with the date of purchase. The guarantee does not extend to wearing parts, damage caused by improper treatment or use, or unauthorised intervention. Repair may only be performed by Stadibauer Marketing + Vertrieb GmbH it self or by a company it has authorised to do so. Within the scope of this guarantee, either the product as a whole or only the defective components will be replaced or equivalent substitution performed, as deemed appropriate by Stadibauer Marketing + Vertrieb GmbH The guarantee does not cover transport, packaging or travel costs or any damage for which the buyer is responsible. These costs are to be covered by the buyer. Guarantee claims will only be accepted from the original purchaser of the Carrera product.

#### Guarantee claims can only be accepted when:

- The card has been filled in properly and sent in together with the defective Carrera product and the purchase receipt/invoice/cash-register receipt.
- No unauthorised alterations have been made by the buyer to the guarantee card.
   The tay has been trigged in accordance with the constitutions and.
- The toy has been treated in accordance with the operating instructions and subjected to its intended use.
- The damage/faulty operation is not due to acts of God or normal wear and tear.
   Guarantee cards cannot be replaced.

Note for EU countries: Reference is hereby made to the seller's statutory guarantee obligation, to the extent that this guarantee obligation is not restricted by the product guarantee.

## Declaration of conformity

Stadlbauer Marketing + Vertrieb GmbH hereby declares that this model including the controller conforms with the fundamental requirements of the following EC directives: EC 2009/48 and 2004/108/EC regarding electromagnetic compatibility and the other tree levant regulations of Directive 1999/5/EC (RATTE).

The original declaration of conformity can be requested from carrera-rc.com.





### Warning!

WARNING! This toy contains small parts which can be swallowed and is therefore not sultable for children under 3 years of age. WARNING! danger of pinching during operation! Remove all packaging materials and wire fastenings before handing the toy over to the child. Please retain the packaging and address for information and in the event of any questions





This symbol, showing refuse bins with a cross through them, denotes that empty batteries, rechargeable batteries, button cells, rechargeable batteries, disble battery packs, equipment batteries, disused electrical equipment, etc. should not be

disposed of in domestic refuse, as they are harmful to the environment and health. Please help to preserve environment and health and talk to your children about the correct disposal of used batteries and disused electrical equipment. Batteries and disused electrical equipment should be handed in to the usual collection points where they can be properly recycled. Do not mix dissimilar battery types or employ new and used batteries together. Empty batteries should be removed from the product. Do not attempt to recharge non-rechargeable batteries. Rechargeable batteries should only be charged under adult supervision. Exhausted batteries are to be removed from the toy. Rechargeable batteries should be removed from the product before charging. Supply terminal are not to be short-circuited. Only use the batteries recommended or equivalent types. If in regular use the charger must be examined for damage to the cord, plug, covers and all other parts. If any signs of damage are found the charger may only be used again after repair work has been completed.

### Requirement for FCC Part 15

Warning: Changes or modifications not expressly approved by the party responsible for compilance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver,
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Black Devil

1x Controller 1x Lanyard 1x Battery Charger
1x Rechargeable Battery
2x 1.5 V Mignon AA batteries
(non-rechargeable)

1



## Safety instructions



A Carrera RC vehicle is a remotecontrolled model car that uses special rechargeable batteries for this purpose. Only original Carrera RC Li-lon rechargeable batteries may be used.




The Carrera RC vehicle is designed for hobby use only and may only be operated on tracks and in spaces especially intended for this purpose.

CAUTION! Do not use the Carrera RC vehicle in road traffic.



Do not operate the car beneath overhead high-voltage cables or broadcasting masts or during a storm! Almospheric disturbances can affect the operation of the vehicle. When there a large temperature differences between your car's garage and the running track, please wall until the vehicle has had time to acclimatise. This will help prevent condensation forming and the possibility of malfunctions resulting.

Never operate the product on grass





Never use the Carrera RC vehicle outdoors during rain or snowfall.

The car must not be run through water, puddles and snow, and must always be kept stored in a dry place.



Never operate the vehicle near rivers, ponds or lakes, to avoid the risk of the Carrera RC car falling into the water. Avoid running on courses which are laid exclusively with sand.



Do not expose the Carrera RC vehicle to direct sunlight.

To avoid the electronics in the car overheating, when temperatures are above 35 °C, regular short pauses in operation are assential



Never subject the Carrera car to repeated changes of load - that means continuously reversing it.



Always place the car on the floor by hand. Never throw the car on the floor from a standing position.



Avoid jumping from jumps or ramps higher than 15 cm (0.49 ft.).



Never use strong solvents for cleaning the car.



To avoid malfunctions to the control system resulting in uncontrolled operation of the Carrera RC vehicle, check that the controller batteries and the rechargeable batteries in the vehicle have sufficient charge.



The Carrera RC vehicle must be inspected before and after operation, each time it is used, to ensure that it has not become disassembled. Any screws or nuts that may have become loosened during operation must be tightened.

9



## Charging the rechargeable battery



RED = Charging

First connect the Carrera RC rechargeable battery to the battery charger supplied. The connection terminals between the battery and the charger are designed to prevent connection with the wrong polarity. Connect the charger to a power source.

When the battery is property connected and


When the battery is properly connected and charging normally, the red LED is constantly it. Once the battery is fully charged, the red LED switches to green. The battery can now be disconnected and

The battery can now be disconnected and installed in the Carrera RC car. The car is now ready for use. After use, the battery must be allowed to cool down for at least 20 minutes before it can be fully recharged. Failure to observe this pause may damage the battery.


Always recharge the battery immediately after use to prevent its becoming deep discharged. Recharge the battery occasionally (suggested every 2-3 months). Fallure to treat the battery as described above can lead to its bec

## Installing the rechargeable battery

GREEN = Ready



Using a screwdriver, remove the cover of the battery compartment in the Carrera RC car.



Connect the end of the cable from the Carrera RC vehicle with the charged battery. Put the battery in place.

Replace the compartment cover using a screwdriver.

## Inserting the batteries





Open the battery compartment with a screwdriver and insert the batteries in the remote control. Please keep in mind the correct polarity. After having closed the compartment you can check all functions of the remote control with the help of the power-switch on the front. With the power-switch turned ON and proper functioning, the top center LED on the remote control will light up red.

## Now you can drive the car



The Carrera RC car and the remote control are bound as a factory setting.



Switch the car ON at the ON/OFF switch. The LED on top of the car will flash rhythmically.



Switch on the controller. The LED on top of the controller will flash rhythmi-


After a few seconds, the LEDs on the car and on the controller will light continuously, meaning the bind has been



Adjusting the steering

If the Carrera RC vehicle is found to pull towards the left or right while moving, use the adjuster control shown in the illustration to adjust the car's track precision. 


## Let's practise!



CAUTION! This vehicle reaches speeds up to 20 km/h (13 mph). Practice on an empty surface at least 2.5 metres (8.2°) square. When operating the model for the first time, be careful with the accelerator, as the car reacts very sensitively. You should practice slow running for at least two or three full battery charges before going on to faster manoeuvres.

10





Now it's time to practise! Set up a Carrera RC vehicle racing track in a large empty area, using cornerposts, empty cans, or similar objects. The basic tech nique to adopt when operating a Carrera RC is to drive fast on the straight sections and to slow down in the curves.

- When changing from the first battery to the second battery, you must stop running for at least ten minutes. At the next change, a pause of at least 20 minutes
- Avoid constant motor operation.
- If the car switches itself off several times one after another, the battery is dead. Please recharge the battery.
- After 30 minutes inactivity, the controller and vehicle switch off automatically.
   To restart, switch the ON/OFF switch on the controller & the car to OFF and then back to ON.
- To switch off after use, follow the steps in the reverse order.
- After use, remove or disconnect the battery. Always recharge the battery immediately after use to prevent its becoming deep discharged.
- Clean the Carrera RC car after use.



Right joystick: steering right and left with variable lock for precise steering





The joysticks are removable Alternatively, the vehicle can be controlled with a rocker.




The joysticks can be stored in the special compartment at the back of the controller.



Attach the lanyard to the eyelet on the

CAUTION! Danger of strangulation!





SERVO TRONIC You can use the joysticks to carry out precise steering and driving manoeu-

Left iovstick: forwards and backwards at different speeds

# Troubleshooting

| Problem                  | Cause   | Solution  |  |  |
|--------------------------|---|---|--|--|
| Car does not move        | Either the switch on the controller or the car is set to OFF.                               | Switch on.  |  |  |
|                          | There is no rechargeable battery in the car or the battery is too weak.                     | Insert charged battery.   |  |  |
|                          | The car has come to a stop at an obstacle.  | The voltage surge protector has switched the car off.  Turn the ON/OFF switch on the car to OFF, then back to ON, and place the car on a clear surface. |  |  |
|                          | The battery or rechargeable battery in the transmitter or model is too weak.                | Insert new battery or recharged battery.  |  |  |
|                          | The remote control is possibly not correctly frequency bound with the receiver on the model | Carry out a frequency bind between the model and the remote control as described in "Now you can drive the car"   |  |  |
|                          | The transmitter has switched itself off after 30 minutes.                                   | To restart, switch the ON/OFF switch on both controller & vehicle to OFF and then back to ON  |  |  |
|                          | The vehicle is very warm.   | Switch both car and controller off and allow the car to cool down for about 30 minutes.   |  |  |
|                          | The overheat protection has caused the car's motor to cut out due to excess temperature.    | Switch off the receiver.<br>Leave the RC car to cool down for approx. 30 minutes.   |  |  |
| Car cannot be controlled | Vehicle starts moving unintentionally.  | First turn on the transmitter, only then the vehicle.   |  |  |

For the latest version of these operating instructions and information on replacement and spare parts available, please visit carrera-rc.com in the service area.

Errors and changes excepted Colours / final design – changes excepted