



User Guide

ST30

True Wireless Earbuds

ST30

True Wireless Earbuds

User Guide

Precautions


1. The earbuds should be stored in a dry and ventilated environment, avoid water, moisture and dust which may affect the performance of the earbuds.
2. Avoid using organic solvents to clean the earbuds.
3. Taking the earbuds apart will void warranty. If you have any issues please contact the Warranty Team at 888-920-8680
4. Do not use any other charging cable, always use the USB cable provided.

FCC ID: 2AS50-056A

Specifications

Wireless version:	5.0
Frequency:	20Hz – 24KHz
Working distance:	10m / 30Ft
Charging time:	2-3 hours
Stand by:	Up to 50 hours

Parts and Features



Charging the Case

1. Connect the charging case via USB cable to charge the case.
2. During charging the LED light flashes. When charging is complete the lights will remain solid.

Charging the Earbuds

1. Place the earbuds into the charging case. The earbuds will be turned off automatically and will start to charge.

Operating Instructions:

Turning ON

Remove both earbuds simultaneously and insert into your ears. Press the function button for 2 seconds and you hear an ascending audible tone. The earbuds will power on and both earbuds will pair together. Now the earbuds are ready to pair to your device.

Pairing to Your Device

Turn on the Bluetooth® feature on your device, the device will search for all the Bluetooth devices (see the user guide of your phone for instructions). Select ST30 from Bluetooth device list. Once selected the device will pair with your ST30 earbuds.

Turning OFF

Press the function button for about 5 seconds, and you will hear a descending audible tone and the earbuds will power off. If the earbuds are away from your Bluetooth paired device for more than 5 minutes the earbuds will power off automatically, thus saving the life of the battery.

Phone Calls

Answering the Call

Press the function button to answer the incoming call.

Disconnecting the Call

To disconnect the call press any function button for 2 sec to disconnect.

RESET

Press and hold any function button for the earbuds to reset to factory settings.

Listening to Music

Play

Make sure your earbuds are connected to the device, once connected select the music from your device to play.

Play/Pause

While playing press any side function button once to pause and then press again to play.

Voice Assistant

Press any function button twice to enter into voice assistant mode.

Volume +

Press the right function button 3 times to increase the volume.

Volume –

Press the left function button 3 times to decrease the volume.

Next song

Press and hold the right function button for 2 sec to play the next song.

Previous Song

Press and hold the left function button for 2 sec to play the previous song.

Trouble Shooting

Trouble	Solution
Mobile device cannot find the earbuds	Check the earbuds are powered on.
Cannot turn the units on	Charge the units for 1- 2 hours.
Turning off automatically	Possible low battery. Charge the earbuds.
Noise when connected to a mobile device	Low battery, charge the earbuds. Obstruction between the device and earbuds. Distance between the Phone and earbuds is beyond signal range.

Warranty Information

1 YEAR LIMITED WARRANTY

The AT&T brands are used under license. Any repair, replacement, or warranty service, and all questions about this product should be directed to Concept 101 LLC at www.att.com/electronics or call **1(888) 920-8680** from the USA or Canada. Concept 101 LLC warrants that the product will be free from defects in material, parts and workmanship for the period of one (1) year from date of purchase. Concept 101 LLC agrees that it will, at its option, replace the defective product with either a new or remanufactured product equivalent to your original purchase during the warranty period. Please be advised the returned product must carry the proof of purchase.

EXCLUSIONS AND LIMITATIONS

Concept 101 LLC does not warrant that the product will work properly in all environmental conditions, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose other than the purpose identified within this user's manual. Concept 101 LLC has made every effort to ensure that this user's manual is accurate and disclaims liability for any inaccuracies or omissions that may have occurred. Information in this user's manual is subject to change without notice and does not represent a commitment on the part of Concept 101 LLC. Concept 101 LLC reserves the right to make improvements to this user's manual and/or to the products described in this user's manual at any time without notice. If you find information in this quick start guide that is incorrect, misleading, or incomplete, please contact us through our website.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure statement.

The device can be used in portable exposure condition without restriction

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment



www.att.com/electronics

©2020 Concept 101 LLC. All Rights Reserved. AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Concept 101 LLC, New York, New York 10018. Printed in China. Issue 1.1 AT&T 8/2020.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.