


# USER'S MANUAL


## Smart Projector F350

**Important items** Before you use the projector, please read this user's manual carefully and keep it in reserve.


### Important safety announcements




### The names and functions of the components of the projector



### The names and functions of the components of the projector



### Connect equipment and apparatus



4


### Installation and commissioning

#### 1 Projector installation

The projector needs to be placed on a horizontal table, not high on one side and low on the other



#### 2 Adjust focal length



**Focus:** When the image is blurred (as shown in the right diagram), the focus ring on the fuselage can be adjusted to obtain satisfactory image effect. If satisfactory definition cannot be obtained through adjustment, please move the projector forward or backward according to the actual situation.

**Keystone correction:** When the image appears keystone anamorphose (as shown in the right diagram), the user needs to use the "keystone correction function" to correct the image to ensure the image is a standard rectangle.

**Adjustment method:** By adjusting the keystone correction ring on the fuselage to adjust the physical position of the lens, the keystone correction can be achieved





Image fuzzy

5

### Installation and commissioning

#### 3 Projection distance reference



Screen size (inch)	Screen width X height (inch)	projection distance (m)
56 inches	height 0.75 m width 1.33 m	1.7 m
66 inches	height 0.87 m width 1.55 m	2.0 m
86 inches	height 1.05 m width 1.86 m	2.5 m
96 inches	height 1.2 m width 2.13 m	2.8 m

#### 4 Safety shutdowns

You can turn off the projector and safely store the equipment by following these steps.

1. Press the **Off** key on the projector operation panel or the **Off** key on the remote control to turn off the equipment according to the system prompt.
2. Screw the focus ring into the equipment to ensure that the lens is fully incorporated into the equipment.
3. Store the equipment in a dry and cool place.



6

### Chapter 1 Internet Connection

#### Wireless Network Connection

Before you use the product, you need to connect the product to the Internet.

Into the device WiFi, wait for about one minute, then nearby WiFi hot spots can be searched in the interface.

Choose your own WiFi access point.

Enter the WiFi password.

#### Chapter 2 Basic Setup

##### Language Setup

You may choose the system language by following these steps:

Home screen > Settings > language & input > language the default language is English, you may choose your current language and confirm.

##### Time zone setup

You should adjust the time zones according to your current location by the following steps:

Home screen > Settings > date & time > select time zone choose your time zone and confirm.

#### Chapter 3 Precautions

1. projector mainly used to watch native video or online video, can not be used as a phone or computer.

2. If the remote can't control the third-party APP when using, you need use USB mouse auxiliary operation.

3. Download the third-party video APP, please notice that you need download TV edition procedures, can't download phone or other edition procedures.

7

### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.