

Clemas & Co Ltd

Industrial Cleaning Equipment
Sales - Hire - Service

TENNANT F8 POLISHER PARTS MANUAL



Clemas & Co. Unit 5 Ashchurch Business Centre, Alexandra Way, Tewkesbury,
Gloucestershire, GL20 8NB.


Tel: 01684 850777

Fax: 01684 850707


Email: info@clemas.co.uk

Web: www.clemas.co.uk

F3 – Base Group



F3 – Base Group Cont'd




* = recommended spare parts


* = empfohlene Ersatzteile

* = pieces de rechange recommandée


F3+ - Base Group



F3+ - Base Group Cont'd




F3/F3+ – Handle Group




* = recommended spare parts
 * = empfohlene Ersatzteile
 * = pieces de rechange recommandées

F3/F3+ – Electrical Diagram




REF	English LEGEND	Deutsch SCHLÜSSEL	Fran aise LEGENDE	Nederlands LEGENDE	Espanol LEYENDA
S	= Switch for motor	Schalter Buerstmotor	Interrupteur	Schakelaar	Interruptor
R	= Relais	Startrelais	Relais	Relais	Relais
CA	= Capacitor	Anlaufkondensator	Capaciteur	Condensator	Condensador
CB	= Capacitor	Betriebskondensator	Capaciteur	Condensator	Condensador
M	= Motor	Motor	Moteur	Motor	Motor
MS	= Protective switch—gear of an engine	Motorschuttschalter	Disjoncteur		


F8 – Base Group




F8 – Base Group Cont'd



F8/F12 – Handle Group




F8 – Electrical Diagram



REF	English LEGEND	Deutsch SCHLÜSSEL	Francais LEGENDE	Nederlands LEGENDE	Espanol LEYENDA
S	= Switch for motor	Schalter Buerstmotor	Interrupteur	Schakelaar	Interruptor
R	= Relais	Startrelais	Relais	Relais	Relais
CA	= Capacitor	Anlaufkondensator	Capaciteur	Condensator	Condensador
CB	= Capacitor	Betriebskondensator	Capaciteur	Condensator	Condensador
M	= Motor	Motor	Moteur	Motor	Motor
MS	= Protective switch— gear of an engine	Motorschuttschalter	Disjoncteur		

F12 – Base Group




* = recommended spare parts


* = empfohlene Ersatzteile

* = pièces de rechange recommandée

F12 – Base Group Cont'd




F12 – Electrical Diagram




REF	English LEGEND	Deutsch SCHLUSSEL	Fran çais LEGENDE	Nederlands LEGENDE	Espanol LEYENDA
S	= Switch for motor	Schalter Buerstmotor	Interrupteur	Schakelaar	Interruptor
R	= Relais	Startrelais	Relais	Relais	Relais
CA	= Capacitor	Anlaufkondensator	Capaciteur	Condensator	Condensador
CB	= Capacitor	Betriebskondensator	Capaciteur	Condensator	Condensador
U	= Switch	Umschalter	Interrupteur	Schakelaar	Interruptor
M	= Motor	Motor	Moteur	Motor	Motor
TS	= Thermal switch	Thermoschalter	Thermostat		

Solution Tank Group (Option)



* = recommended spare parts
 * = empfohlene Ersatzteile
 * = pièces de rechange recommandée

F8/F12 – Spray Unit Group (Option)




* = recommended spare parts


* = empfohlene Ersatzteile

* = pièces de rechange recommandée


F8/F12 – Vacuum Unit (Option)



F8/F12 – Vacuum Unit (Option)



F8/F12 – Vacuum Unit (Option)



F8/F12 – Vacuum Unit (Option)

